# Installation and Operation Instructions LEDFLASHER1



### **WARNING!**

Failure to install or use this product according to manufacturer's recommendations may result in property damage, serious bodily/personal injury, and/or death to you and those you are seeking to protect!



# Do not install and/or operate this safety product unless you have read and understand the safety information contained in this manual.

- 1. Proper installation combined with operator training in the use, care, and maintenance of emergency warning devices are essential to ensure the safety of you and those you are trying to protect.
- 2. Exercise caution when working with live electrical connections.
- 3. This product must be properly grounded. Inadequate grounding and/or shorting of electrical connections can cause high current arcing, which can cause personal injury and/or severe vehicle damage, including fire.
- 4. Proper placement and installation are vital to the performance of this warning device. Install this product so that output performance of the system is maximized and the controls are placed within convenient reach of the operator so that s/he can operate the system without losing eye contact with the roadway.
- 5. Do not install this product or route any wires in the deployment area of an air bag. Equipment mounted or located in an air bag deployment area may reduce the effectiveness of the air bag or become a projectile that could cause serious personal injury or death. Refer to the vehicle owner's manual for the air bag deployment area. It is the responsibility of the user/operator to determine a suitable mounting location ensuring the safety of all passengers inside the vehicle particularly avoiding areas of potential head impact.
- 6. It is the responsibility of the vehicle operator to ensure during use that all features of this product work correctly. In use, the vehicle operator should ensure the projection of the warning signal is not blocked by vehicle components (i.e., open trunks or compartment doors), people, vehicles, or other obstructions.
- 7. The use of this or any other warning device does not ensure all drivers can or will observe or react to a warning signal. Never take the right-of-way for granted. It is your responsibility to be sure you can proceed safely before entering an intersection, driving against traffic, responding at a high rate of speed, walking on or around traffic lanes.
- 8. This equipment is intended for use by authorized personnel only. The user is responsible for understanding and obeying all laws regarding warning signal devices. Therefore, the user should check all applicable city, state, and federal laws and regulations. The manufacturer assumes no liability for any loss resulting from the use of this warning device.

#### **Specifications:**

Size: 3.90" X 3.00" X 0.875"

Input Voltage: 12.8VDC Output Voltage 12.8VDC

AMP Rating: 6AMP per output wire

## Installation & Mounting:

Select a mounting location for the unit on a flat surface. Using the unit as a template, drill a hole in mounting surface at each hole location. The unit can be mounted to any flat surface with # 6 or #8 screws.

# Wiring:

## **CAUTION:**

Important! This unit is a warning device and it must be connected to its own seperate, fused power point to assure its continued operation should any other electrical accessory fail.

All wiring should be a minimum of 16 AWG with the exception of the RED and BLACK wires.

RED WIRE: Connect to 12 volts to enable flasher. This is a low current connection and can be run with as small as 22 AWG wire.

BLACK WIRE: Momentarily touch to 12 volts to change flash pattern. This is a low current connection and can be run with as small as 22 AWG wire.

Use 6 wire harness supplied or a wire harness with corrosion preventative compound on the connector pins specifically designed for electrical contacts and switches.`




FIGURE 1

**Important!** This unit is a warning device, and it must be connected to its own seperate, fused power point to assure its continued operation should any other electrical accessory fail.

#### Flash Pattern Selection:

The LEDFLASHER1 can be configured to flash the following patterns (in the order shown) by momentarily touching the black wire to power. The unit must be powered through the ground and power wires to allow pattern selection.

The unit remembers the last pattern selected.

A momentary pushbutton switch may be used to change flash pattern.

FLASH PATTERN CHART				
PATTERN	FLASH PATTERN	FPM	SAE	R65
1	Random Level 4 (patterns 5-12, 4 times through)	N/A	N/C	N/C
2	Steady On	N/A	N/C	N/C
3	Random Level 10 (patterns 5-12, 10 times through)	N/A	N/C	N/C
4	Flasher	75 FPS	Χ	N/C
5	Double Flash	55	N/C	N/C
6	Quad Flash	65	Χ	N/C
7	Quintiple Flash	75	Χ	N/C
8	Mega Flash	250	N/C	N/C
9	Octa Flash	100	Χ	N/C
10	Phased Mega	360-1200	N/C	N/C
11	Deci Blast	85	Χ	N/C
12	Warble	250-500	N/C	N/C
13	Single	150	Χ	Х
14	Double Flash	150	Χ	Х
15	Quad Flash	150	X	Х

#### Electronics Controls Company "ECCO" (Manufacturer)

ECCO warrants that on the date of purchase, this product will conform to ECCO's specifications for this product (which are available from ECCO upon request). This Limited Warranty extends for sixty (60) months from the date of purchase.

DAMAGE TO PARTS OR PRODUCTS RESULTING FROM TAMPERING, ACCIDENT, ABUSE, MISUSE, NEGLIGENCE, UNAPPROVED MODIFICATIONS, FIRE OR OTHER HAZARD; IMPROPER INSTALLATION OR OPERATION; OR NOT BEING MAINTAINED IN ACCORDANCE WITH THE MAINTENANCE PROCEDURES SET FORTH IN ECCO'S INSTALLATION AND OPERATING INSTRUCTIONS VOIDS THIS LIMITED WARRANTY.

#### Exclusion of Other Warranties:

ECCO MAKES NO OTHER WARRANTIES, EXPRESSED OR IMPLIED. THE IMPLIED WARRANTIES FOR MERCHANTABILITY, QUALITY OR FITNESS FOR A PARTICULAR PURPOSE, OR ARISING FROM A COURSE OF DEALING, USAGE OR TRADE PRACTICE ARE HEREBY EXCLUDED AND SHALL NOT APPLY TO THE PRODUCT AND ARE HEREBY DISCLAIMED, EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ORAL STATEMENTS OR REPRESENTATIONS ABOUT THE PRODUCT DO NOT CONSTITUTE WARRANTIES.

#### Remedies and Limitation of Liability:

ECCO'S SOLE LIABILITY AND BUYER'S EXCLUSIVE REMEDY IN CONTRACT, TORT (INCLUDING NEGLIGENCE), OR UNDER ANY OTHER THEORY AGAINST ECCO REGARDING THE PRODUCT AND ITS USE SHALL BE, AT ECCO'S DISCRETION, THE REPLACEMENT OR REPAIR OF THE PRODUCT, OR THE REFUND OF THE PURCHASE PRICE PAID BY BUYER FOR NON-CONFORMING PRODUCT. IN NO EVENT SHALL ECCO'S LIABILITY ARISING OUT OF THIS LIMITED WARRANTY OR ANY OTHER CLAIM RELATED TO THE ECCO'S PRODUCTS EXCEED THE AMOUNT PAID FOR THE PRODUCT BY BUYER AT THE TIME OF THE ORIGINAL PURCHASE. IN NO EVENT SHALL ECCO BE LIABLE FOR LOST PROFITS, THE COST OF SUBSTITUTE EQUIPMENT OR LABOR, PROPERTY DAMAGE, OR OTHER SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES BASED UPON ANY CLAIM FOR BREACH OF CONTRACT, IMPROPER INSTALLATION, NEGLIGENCE, OR OTHER CLAIM, EVEN IF ECCO OR A REPRESENTATIVE OF ECCO HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. ECCO SHALL HAVE NO FURTHER OBLIGATION OR LIABILITY WITH RESPECT TO THE PRODUCT OR ITS SALE, OPERATION AND USE, AND ECCO NEITHER ASSUMES NOR AUTHORIZES THE ASSUMPTION OF ANY OTHER OBLIGATION OR LIABILITY IN CONNECTION WITH SUCH PRODUCT.

This Limited Warranty defines specific legal rights. You may have other legal rights which vary from jurisdiction to jurisdiction. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages.

833 West Diamond St Boise, Idaho 83705 Customer Service USA 800-635-5900 UK +44 (0)113 237 5340 AUS +61 (0)3 63322444 www.eccoesg.com

920-0195-00 Rev. D