

How to Remove and Reposition a Smart Doorbell Camera

Description

This page shows how to remove and reposition a Doorbell Camera



Please read through the directions in its entirety before commencing.

Instructional Video

This Video link illustrates how to re-install a Smart Doorbell Camera

TELUS | How to install your Doorbell Camera

Checklist: Ensure to have the following items before beginning

- 1. Power drill (bit size)
- 2. Screws and anchors

Removal of a Doorbell Camera

- 1. Turn electrical power off to the Doorbell Camera at the electrical panel
- 2. While holding the face of the Camera, remove screw located at the bottom
- 3. Pull the Doorbell Camera off the back plate by carefully pulling from the bottom up
- 4. Unscrew the back plate

- 5. Loosen the two screws on the back plate holding the wires in place
- 6. Pull wires off the screws
- 7. Be careful the wires don't slip back into the wall

Requirements Before Installing the Doorbell Camera

Doorbell Cameras will not work with a wireless doorbell and/or most intercom systems.

- 1. Pre-wiring for a doorbell via a low voltage power source (10-36AC or 12DC)
- 2. Minimum Wi-Fi 2.5Mbps per camera
- Digital door chimes require the SkyBell Doorbell Adapter accessory and on the Customer App activate the Digital Chime setting

Repositioning of a Doorbell Camera

- 1. Ensure power is off at the electrical panel going to the doorbell wires
- 2. Decide where the back plate for the Doorbell Camera will be placed and mark where the screws will be located
- 3. If mounting the Doorbell Camera on stone, brick or concrete, use a masonry drill bit and insert the anchors.
- 4. Slightly loosen the screws on the back plate
- 5. Place back plate on the exterior wall and pull wires through the hole
- 6. Loosely connect wires on the terminals
- 7. Make sure the wire connectors are on the bottom of the back plate so the doorbell will be right side up
- 8. Insert the wires beneath the screws and position the wires by pressing them down into the slots of the back plate
- 9. Tighten the screws so the heads are flush
- 10. Fit the wires neatly into the tracking on the back plate
- 11. Secure the back plate by screwing it into the anchors
- 12. Turn power back on
- 13. Position Doorbell Camera onto the back plate
- 14. Position the doorbell camera top first

- 15. Press down on the camera to secure it to the back plate while pushing the front of the doorbell camera toward the wall
- 16. Gently attach the screw to the bottom of the camera

Connecting Doorbell Camera to the Customer App via Wi-Fi

- 1. Log into Customer App
- 2. Select the menu on the top left corner
- 3. Select [Add Device]
- 4. Select [Doorbell Camera]
- 5. Select the Doorbell Camera you have
- 6. Click [Next]
- 7. Ensure Doorbell Camera is flashing red/green
 - a. If not flashing, press and hold the doorbell button down, until it begins to flash red/green and release
- 8. Click [Next]
- 9. Name your Doorbell Camera i.e. Front Doorbell
- 10. Minimize the App and go to your Phone Settings
 - a. Select Wi-Fi
 - b. Under Other Networks find Skybell
 - c. Select Skybell
- 11. Go back to the App
- 12. Find your Wi-Fi network name and Select
- 13. Enter your Wi-Fi network Password
- 14. Wait for Installation of Doorbell Camera to complete