



Development Kit User Guide

AirPrime HL Series



SIERRA
WIRELESS®

4114877
5.0
October 12, 2015

Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the Sierra Wireless modem are used in a normal manner with a well-constructed network, the Sierra Wireless modem should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Sierra Wireless accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the Sierra Wireless modem, or for failure of the Sierra Wireless modem to transmit or receive such data.

Safety and Hazards

Do not operate the Sierra Wireless modem in areas where cellular modems are not advised without proper device certifications. These areas include environments where cellular radio can interfere such as explosive atmospheres, medical equipment, or any other equipment which may be susceptible to any form of radio interference. The Sierra Wireless modem can transmit signals that could interfere with this equipment. Do not operate the Sierra Wireless modem in any aircraft, whether the aircraft is on the ground or in flight. In aircraft, the Sierra Wireless modem **MUST BE POWERED OFF**. When operating, the Sierra Wireless modem can transmit signals that could interfere with various onboard systems.

Note: Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. Sierra Wireless modems may be used at this time.

The driver or operator of any vehicle should not operate the Sierra Wireless modem while in control of a vehicle. Doing so will detract from the driver or operator's control and operation of that vehicle. In some states and provinces, operating such communications devices while in control of a vehicle is an offence.

Limitations of Liability

This manual is provided "as is". Sierra Wireless makes no warranties of any kind, either expressed or implied, including any implied warranties of merchantability, fitness for a particular purpose, or noninfringement. The recipient of the manual shall endorse all risks arising from its use.

The information in this manual is subject to change without notice and does not represent a commitment on the part of Sierra Wireless. SIERRA WIRELESS AND ITS AFFILIATES SPECIFICALLY DISCLAIM LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE OR ANTICIPATED PROFITS OR REVENUE ARISING OUT OF THE USE OR INABILITY TO USE ANY SIERRA WIRELESS PRODUCT, EVEN IF SIERRA WIRELESS AND/OR ITS AFFILIATES HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

Notwithstanding the foregoing, in no event shall Sierra Wireless and/or its affiliates aggregate liability arising under or in connection with the Sierra Wireless product, regardless of the number of events, occurrences, or claims giving rise to liability, be in excess of the price paid by the purchaser for the Sierra Wireless product.

Customer understands that Sierra Wireless is not providing cellular or GPS (including A-GPS) services. These services are provided by a third party and should be purchased directly by the Customer.

SPECIFIC DISCLAIMERS OF LIABILITY: CUSTOMER RECOGNIZES AND ACKNOWLEDGES SIERRA WIRELESS IS NOT RESPONSIBLE FOR AND SHALL NOT BE HELD LIABLE FOR ANY DEFECT OR DEFICIENCY OF ANY KIND OF CELLULAR OR GPS (INCLUDING A-GPS) SERVICES.

Patents

This product may contain technology developed by or for Sierra Wireless Inc.

This product includes technology licensed from QUALCOMM®.

This product is manufactured or sold by Sierra Wireless Inc. or its affiliates under one or more patents licensed from InterDigital Group and MMP Portfolio Licensing.

Copyright

© 2015 Sierra Wireless. All rights reserved.

Trademarks

Sierra Wireless®, AirPrime®, AirLink®, AirVantage®, WISMO®, ALEOS® and the Sierra Wireless and Open AT logos are registered trademarks of Sierra Wireless, Inc. or one of its subsidiaries.

Watcher® is a registered trademark of NETGEAR, Inc., used under license.

Windows® and Windows Vista® are registered trademarks of Microsoft Corporation.

Macintosh® and Mac OS X® are registered trademarks of Apple Inc., registered in the U.S. and other countries.

QUALCOMM® is a registered trademark of QUALCOMM Incorporated. Used under license.

Other trademarks are the property of their respective owners.

Contact Information

Sales Desk:	Phone:	1-604-232-1488
	Hours:	8:00 AM to 5:00 PM Pacific Time
	Contact:	http://www.sierrawireless.com/sales
Post:	Sierra Wireless 13811 Wireless Way Richmond, BC Canada V6V 3A4	
Technical Support:	support@sierrawireless.com	
RMA Support:	repairs@sierrawireless.com	
Fax:	1-604-231-1109	
Web:	http://www.sierrawireless.com/	

Consult our website for up-to-date product descriptions, documentation, application notes, firmware upgrades, troubleshooting tips, and press releases: www.sierrawireless.com

Document History

Version	Date	Updates
1.0	November 21, 2013	Creation
2.0	March 04, 2014	Added HL8548x support
2.1	March 10, 2014	Updated: • Board version number • Table 3 Available Connections • 3.8 UART0/SPI1
		Deleted obsolete connectors
3.0	December 12, 2014	Added Snap-in socket information; updated information for board version 1400897-I
		Removed socket board information
4.0	March 16, 2015	Added HL75xx, HL8518, HL8528, HL8529 and HL8549x support
5.0	October 12, 2015	Added HL6528RDx support
		Updated: • Table 2 Connector and Switch Description • Table 4 AirPrime HL Series Development Kit Test Ports



Contents

1. OVERVIEW	9
2. GENERAL DESCRIPTION	11
2.1. RoHS Compliance	11
2.2. Development Kit	12
2.2.1. Features	13
2.2.2. Connectors and Component Placement	13
2.2.3. Snap-In Connector	18
2.2.4. Test Ports	20
2.3. Special Solder for Jumper Solder Pads	22
3. INTERFACES	23
3.1. Power Supply	23
3.2. Control Functions	24
3.2.1. Power ON/OFF	24
3.2.2. ~RESET	24
3.3. USB0	25
3.4. USB1	25
3.5. Audio	26
3.6. SIM1 and SIM2	27
3.7. UART1	29
3.8. UART0/SPI1	30
3.9. GPIO Control	31
3.10. Current Measurement	31
3.11. JTAG	32
3.12. Antenna Connections	32
3.13. RTC Backup Battery	32
4. GETTING STARTED WITH THE HL SERIES DEVELOPMENT KIT	33
4.1. Setting Up the Development Kit	33
4.2. Switching the Development Kit On	36
4.3. RF Communications with the HL6528x	36
4.3.1. Configure the COM Port	36
4.3.2. Make a Voice Call	37
4.4. RF Communications with the HL75xx and HL85xxx	38
4.5. GPS Communications with the HL6528-G	40
4.6. GPS Communications with the HL854x-G	41
5. OTHER HARDWARE SETTINGS	42
5.1. Getting SpyTracer Debugging Data (for HL6528x only)	42

6. REFERENCE DOCUMENTS.....	46
7. DEV-KIT SCHEMATIC DIAGRAMS.....	47



List of Figures

Figure 1.	AirPrime HL Series Development Kit (board version 1400897-I).....	12
Figure 2.	Available Connectors and Components on the AirPrime HL Series Development Kit ...	14
Figure 3.	Snap-in Connector	18
Figure 4.	Module Position for HL6528x (without label).....	18
Figure 5.	Module Position for HL6528x (with label).....	19
Figure 6.	Module Position for HL75xx and HL85xxx	19
Figure 7.	Snap-in Connector with Embedded Module and Cover	19
Figure 8.	Jumper Solder Pad.....	22
Figure 9.	Power Supply Connector (CN402, CN401 and CN400)	23
Figure 10.	Power Source Selection (Schematic Diagram and Actual Development Kit Picture)	23
Figure 11.	PWR ON Pushbutton and CN601 Jumper	24
Figure 12.	~RESET Pushbutton	24
Figure 13.	USB0 Interface	25
Figure 14.	USB1 Interface	25
Figure 15.	Audio Interface	26
Figure 16.	4-pin RJ9 Connector for Audio Signals	26
Figure 17.	SIM1 and SIM2 Interface.....	27
Figure 18.	UART1 Connector	29
Figure 19.	UART0 Connector	30
Figure 20.	GPIOs Control Switches.....	31
Figure 21.	Jumper for Supplying the Development Kit Interfaces Separately.....	31
Figure 22.	JTAG Connector.....	32
Figure 23.	RF, 4G Diversity and GNSS Antenna Connectors.....	32
Figure 24.	RTC Coin Battery Location.....	32
Figure 25.	AirPrime HL Series Development Kit with an HL6528 Embedded Module Inside the Snap-in Connector	35
Figure 26.	CN601 and SW601	36
Figure 27.	D403 and D501	36
Figure 28.	AT Communication with the AirPrime HL6528x	37
Figure 29.	AT Communication with the AirPrime HL75xx and HL85xxx	39



List of Tables

Table 1.	Supported Module Variants.....	9
Table 2.	Connector and Switch Description	15
Table 3.	Available Connections	16
Table 4.	AirPrime HL Series Development Kit Test Ports	20
Table 5.	Audio Connector Pin Description	26
Table 6.	SIM1 Connector Pin Description	27
Table 7.	SIM2 Connector Pin Description	28
Table 8.	SIM Configuration.....	28
Table 9.	Pin Description of the UART1 Connector	29
Table 10.	UART0 Connector Pin Description.....	30

1. Overview

This document describes the AirPrime HL Series Development Kit (board version 1400897-I) and how it integrates with the AirPrime HL6528x, HL75xx and HL85xxx series of embedded modules via a specific Snap-in connector. It also briefly describes the different interfaces and peripheral connections supported by the HL Series Development Kit and provide schematics to facilitate the user's understanding and configuration of the development kit board for their own application use.

The AirPrime HL Series Development Kit may be used to develop both software and hardware applications based on embedded modules from the AirPrime HL series.

The following table enumerates the different HL6528x, HL75xx and HL85xxx variants that can be used with the development kit.

Table 1. Supported Module Variants

Series	Variant	Part Number	Description
HL6528x	HL6528	1102403	1.8V; GSM/GPRS capable
	HL6528-G	1102404	1.8V; GSM/GPRS capable with GLONASS support
	HL6528-2.8V	1102405	2.8V; GSM/GPRS capable
	HL6528-G2.8V	1102406	2.8V; GSM/GPRS capable with GLONASS support
	HL6528 AUTO	1102313	1.8V; GSM/GPRS capable (automotive grade)
	HL6528-G AUTO	1102314	1.8V; GSM/GPRS capable with GLONASS support (automotive grade)
	HL6528-2.8V AUTO	1102315	2.8V; GSM/GPRS capable (automotive grade)
	HL6528-G2.8V AUTO	1102316	2.8V; GSM/GPRS capable with GLONASS support (automotive grade)
	HL6528RD	1102609	1.8V; GSM/GPRS capable
	HL6528RD-G	1102610	1.8V; GSM/GPRS capable with GLONASS support
	HL6528RD-2.8V	1102611	2.8V; GSM/GPRS capable
	HL6528RD-G2.8V	1102612	2.8V; GSM/GPRS capable with GLONASS support
HL75xx	HL7518	1600601	1.8V; LTE (B4, B13) capable
	HL7519	1600570	1.8V; LTE (B2, B4, B13) capable
	HL7528	1600583	1.8V; LTE (B1, B3, B5, B7) capable
	HL7548	1600571	1.8V; LTE (B2, B4, B5, B17) capable
	HL7549	1600617	1.8V; LTE (B3, B7, B28A, B28B) capable
	HL7588	1600572	1.8V; HSPA+ (B2, B5)/LTE (B2, B4, B5, B13, B17) capable

Series	Variant	Part Number	Description
HL85xxx	HL8518	1600676	1.8V; GSM/GPRS/UMTS (B1, B8) capable
	HL8528	1600677	1.8V; GSM/GPRS/EDGE GSM 850/PCS 1900/UMTS (B2, B5) capable
	HL8529	1600678	1.8V; UMTS (B2, B5) capable
	HL8548	1102149	1.8V; EDGE/WCDMA/HSxPA capable
	HL8548-G	1102150	1.8V; EDGE/WCDMA/HSxPA capable with GLONASS support
	HL8549	1600556	1.8V; EDGE/WCDMA/HSxPA capable
	HL8549-G	1600557	1.8V; EDGE/WCDMA/HSxPA capable with GLONASS support

For more information about the HL series of embedded modules, refer to the product technical specifications listed in section 6 Reference Documents.



2. General Description

This section gives a brief overview of the AirPrime HL Series Development Kit and briefly describes the interfaces and special jumper pads available, and lists all available test points on the development kit board.

2.1. RoHS Compliance

The AirPrime HL Series Development Kit board is compliant with RoHS (Restriction of Hazardous Substances in Electrical and Electronic Equipment) Directive 2011/65/EU which sets limits for the use of certain restricted hazardous substances. This directive states that “from 1st July 2006, new electrical and electronic equipment put on the market does not contain lead, mercury, cadmium, hexavalent chromium, polybrominated biphenyls (PBB) or polybrominated diphenyl ethers (PBDE)”.

The AirPrime HL6528x, HL75xx and HL85xxx series of embedded modules are also compliant with this directive.

2.2. Development Kit




Figure 1. AirPrime HL Series Development Kit (board version 1400897-I)

2.2.1. Features


Interfaces available on the development kit board include:

- Power supply connectors
- ON/OFF switch and pushbutton
- Reset pushbutton
- Tests points (TP) to access all signals of the embedded module
- Main serial link RS232, UART1 with full signals including a Ring Indicator signal
- Auxiliary serial link RS232, UART0 with 4 signals
- Full Speed USB0 Connector (I²C signals conversion for GNSS on HL6528x-G modules)
- Full Speed USB1 Connector (for HL6528RDx, HL75xx and HL85xxx only)
- 2 SIMs (with SIM presence management)
 - SIM 1: selectable 1.8/3V or SON8 embedded SIM (unsoldered by default)
 - SIM 2: 1.8/3V SIM
- Audio connectors, selectable for PCM conversion output or analog output from the HL module
- GPIOs
- DIP switches for GPIO logic input/output control
- LEDs for several indications
- Automatic detection and adaptation to either 2.8V or 1.8V module variant (for HL6528x only)
- External board-to-board connectors (unsoldered by default)
- Back up battery and discharge circuit
- JTAG connector
- Main RF connector antenna
- Diversity 4G RF connector antenna
- GNSS connector antenna
- Snap-in connector (for plugging in the HL module; note that this connector is not applicable to the HL8549x)

Refer to section 3 Interfaces for detailed information about these interfaces.

2.2.2. Connectors and Component Placement

Refer to the following figure for the location of connectors and other components on the AirPrime HL Series Development Kit.



The following table describes the connectors and switches available on the development kit and the table after describe the different connections available.

Table 2. Connector and Switch Description

Connector / Switch	Description	HL6528x	HL75xx	HL85xxx
CN402	4V, 3.75A power jack	✓	✓	✓
CN401	3.7V, 4A positive lab power supply (+)	✓	✓ ¹	✓
CN400	Negative lab power supply (-)	✓	✓ ¹	✓
CN700	UART1 (main UART)	✓	✓	✓
CN602	UART0 (SPI to UART); SW Spytracer	✓ ⁵		
CN202	GPIOs (1 to 8)	✓ ⁵	✓	✓
	GPIOs (9 to 16) Multiplexed with other features; not compliant with HL6528x		✓	✓
CN902	USB0 (I ² C to USB, GPIO1 and GPIO5) GNSS NMEA for HL6528x-G, and as I ² C signals on USB for HL85xxx	✓		✓ ²
CN901	USB1		✓	✓
SW602	Reset	✓	✓	✓
SW601	Power on (POK_IN); low level active 2 seconds de-bouncing	✓	✓	✓
CN1105	Headset jack (RJ9). PCM Codec conversion output or analog audio output (for HL6528x only)	✓	✓ ³	✓
CN1100	Digital audio (PCM) for HL6528x, PCM signals probe for HL75xx and HL85xxx	✓	✓	✓
CN406	Real time clock backup battery	✓	✓ ¹	✓
CN300 (Pin 1)	ADC0 input, 0-3V	✓	✓ ¹	✓
CN300 (Pin 3)	ADC1 input, 0-3V	✓	✓	✓
CN800	SIM1	✓	✓	✓
CN802	SIM2	✓	✓ ¹	
CN1200	JTAG	✓ ⁶	✓ ¹	
CN202 (Pin 24)	PWM; multiplexed with GPIO12	✓		✓ ²
CN202 (Pin 46)	VGPI0 – reference voltage output	✓	✓	
CN202 (Pin 52)	2G RF transmit signal (Transmit ON for LTE)	✓	✓	
U200	Snap-in connector	✓	✓	✓ ⁴
CN303	2G/3G/4G RF main connector	✓	✓	✓
CN304	GNSS connector	✓		✓ ²
CN302	2G/3G/4G RF diversity connector		✓	
CN200 and CN201	Board to board connector (development kit to socket board connection) (unsoldered)			

- 1 This feature is only available on the HL7528 and HL7549.
- 2 This feature is not available on the HL8518, HL8528 and HL8529.
- 3 This feature is not available on the HL7518, HL7519 and HL7548.
- 4 This connector is not applicable for the HL8549x.
- 5 This feature is not available on the HL6528RDx.
- 6 This feature is not available on the HL6528RD and HL6528RD-G.

Table 3. Available Connections

Connector/Switch	Connection
CN1103	Positive audio line - Connect Pin 1 and Pin 2 with a jumper to bypass audio amplifier when using a handset audio terminal - Connect Pin 2 and Pin 3 with a jumper to enable audio amplifier when using a handset audio terminal
CN1104	Negative audio line - Connect Pin 1 and Pin 2 with a jumper to bypass audio amplifier when using a handset audio terminal - Connect Pin 2 and Pin 3 with a jumper to enable audio amplifier when using a handset audio terminal
CN300	- Pin 1 is ADC0 input, 0-3V - Pin 2 connected to NTC on board - Pin 3 is ADC1 input, 0-3V - Note that SW300 must be switched "ADC & GPIO" to disable antenna detection when ADC is connected to an external input - Both ADC0 and ADC1 are connected by default
CN301	- Jumper connected = Fault Enable - Jumper disconnected = No Fault Simulator
CN305	Short with a jumper to enable power supply for GNSS active antenna with internal VCC reference voltage 3.1V, or connect a separate active antenna bias voltage can to Pin 2. This connector is shorted by default.
CN403	- Connect Pin 2 and Pin 3 with a jumper for applications using a 4V power supply unit (via CN402) - Connect Pin 1 and Pin 2 with a jumper when using a lab power supply (via CN401 and CN400)
CN404	- Connect Pin 1 and Pin 2 with a jumper for applications using a 4V power supply unit (via CN402) - Connect Pin 2 and Pin 3 with a jumper when using a lab power supply (via CN401 and CN400)
CN405	Short with a jumper to power ON the Development Kit. This connector is shorted by default.
CN406	- Connect Pin 1 and Pin 2 with a jumper to enable RTC backup battery for module - Connect Pin 2 and Pin 3 with a jumper to disable and discharge RTC backup battery - Disconnect the RTC backup battery with module by not connecting any jumpers
CN600	Short with a jumper to enable SIM2. This connector is shorted by default.
CN601	- Connect Pin 1 and Pin 2 with a jumper to bypass the POK_IN button (SW601). The Development Kit will automatically be powered on when VBAT is present. Pin 1 and Pin 2 are connected with a jumper by default. - Do not connect a jumper to enable Development Kit power on by pushing SW601 (2 seconds de-bouncing).
CN801	Short with a jumper to enable SIM1 insertion detection. This connector is shorted by default.
CN803	Short with a jumper to enable SIM2 insertion detection. This connector is shorted by default.

Connector/Switch	Connection
CN804	Short with a jumper to enable SIM switch control. This connector is open by default. If shorted with a jumper, the embedded SIM on the development kit (U805) will be connected to the SIM1 interface of the embedded module. Note that this feature is only available on the HL85xxx.
CN901	Short with a jumper to enable USB1 port (this feature is not available for the HL6528x). This connector is shorted by default.
SW1000	- Switch to "OUT" to disable GPIO1 to GPIO8 (default setting) - Switch to "IN" to enable GPIO1 to GPIO8
SW1001	- Switch to "HIGH" to enable GPIO1 to GPIO8 pull up - Switch to "LOW" to enable GPIO1 to GPIO8 pull down
SW1100	- Switch to "ANALOG" for analog audio out - Switch to "PCM" for PCM audio out through the PCM analog audio converter
SW1101	- Switch to "ON" to enable amplifier for audio out - Switch to "OFF" to disable amplifier for audio out
SW300	- Switch to "ANTENNAS DETECTION ENABLE" for antenna detection - Switch to "ADC & GPIO" for ADC application (default setting)
SW301	- Switch to "GSM FAULT TO VCC" for antenna fault simulator to VCC - Switch to "GSM FAULT TO GND" for antenna fault simulator to GND
SW302	- Switch to "GPS ANT DETECT" for GNSS antenna detection (only active for GNSS port on the Development Kit) - Switch to "GPS ACTIVE ANT SUPPLY ENABLE" to enable GNSS active antenna supply (default setting)
SW400	Discharge button for RTC battery. For internal Sierra Wireless use only.
SW500	- Switch to "1.8V" to manually detect the HL6528-1.8V module type (not used) - Switch to "2.8V" to manually detect the HL6528-2.8V module type (not used)
SW501	- Switch to "HL6528-G" to manually detect the HL6528x module type (not used) - Switch to "HL8548-G" to manually detect the HL75xx, HL85xxx module type (not used)
SW600	- Switch to "UART0" for UART applications (default setting) - Switch to "GPIO" for other GPIO applications (not available for the HL6528x)
SW603	<i>Note: This switch only has a bearing when using an HL85xxx module. The UART0/debug interface will always function as an SPI to UART interface regardless of this switch's setting when using an HL6528x; it has no effect when using an HL75xx.</i> - Switch to "SPI/UART0" to use the UART0 interface/debug port of the HL85xxx - Switch to "SPI" to use the SPI interface of the HL8518, HL8528 or HL8529
SW800	- Switch to "SIM2 & GPIO" for SIM2 applications (default setting) - Switch to "PWM" for PWM applications
SW900	- Switch to "I2C" for I2C applications (default setting) - Switch to "GPIO" for GPIO1 and GPIO5 applications

2.2.3. Snap-In Connector

The Snap-in connector houses the HL series embedded module and allows easy switching between any of the supported HL series embedded module.

Note: *The HL8549x module does not use this connector as it is soldered directly on the development kit.*




Figure 3. Snap-in Connector

Note: *To ensure that the HL embedded module works properly with the development kit, make sure that the HL series embedded module is positioned properly inside the Snap-in connector.*

Refer to the following figures for examples of the correct module orientation inside the Snap-in connector.




Figure 4. Module Position for HL6528x (without label)




Figure 5. Module Position for HL6528x (with label)




Figure 6. Module Position for HL75xx and HL85xxx

After plugging an HL series embedded module in the Snap-in connector, attach the Snap-in cover as shown in the figure below.




Figure 7. Snap-in Connector with Embedded Module and Cover

2.2.4. Test Ports

There are a total of 64 test ports available in the AirPrime HL Series Development Kit. The following table lists the test port serigraphy and the corresponding signal names of the applicable HL series module.

For more information about these signals, refer to the product technical specifications listed in section 6 Reference Documents.

Table 4. AirPrime HL Series Development Kit Test Ports

Test Port #	Test Port Serigraphy	Board to Board Connector Pin #	HL6528x Signal Name	HL75xx Signal Name	HL85xxx Signal Name
1	TXD1	CN200.81	UART1_TX	UART1_TX	UART1_TX
2	RXD1	CN200.85	UART1_RX	UART1_RX	UART1_RX
3	RTS1	CN200.73	UART1_RTS	UART1_RTS	UART1_RTS
4	CTS1	CN200.79	UART1_CTS	UART1_CTS	UART1_CTS
5	DTR1	CN200.77	UART1_DTR	UART1_DTR ¹ / TRACE_DATA3 ²	UART1_DTR
6	RI1	CN200.71	UART1_RI	UART1_RI ¹	UART1_RI
7	GND				
8	GND				
9	DSR1	CN200.83	UART1_DSR	UART1_DSR ¹ / TRACE_DATA0 ²	UART1_DSR
10	DCD1	CN200.75	UART1_DCD	UART1_DCD ¹ / TRACE_DATA1 ²	UART1_DCD
11	GPIO1	CN201.32	GPIO1 / I2C1_CLK	GPIO1 / I2C_CLK ^{3,4}	GPIO1/I2C_CLK
12	GPIO2	CN201.30	GPIO2	GPIO2 / TRACE_DATA2 ²	GPIO2
13	GPIO3	CN201.51	UIM1_DET / GPIO3	GPIO3 / UIM_DET	GPIO3 / UIM_DET
14	GPIO4	CN201.69	UIM2_DET / GPIO4	GPIO4	GPIO4
15	GPIO5	CN200.90	GPIO5 / I2C1_DATA	GPIO5 / I2C_SDA ^{3,4}	GPIO5/I2C_SDA
16	GPIO6	CN201.60	GPIO6	GPIO6	GPIO6
17	GPIO7	CN201.40	GPIO7	GPIO7	GPIO7
18	GPIO8	CN201.42	GPIO8	GPIO8 / TRACE_CLK ²	GPIO8
19	GPIO9	CN200.8	UIM2_VCC	NC1	NC1
20	GPIO10	CN201.66	SPI1_MISO	GPIO10 ² / SPI1_MISO ^{3,4}	GPIO10
21	GPIO11	CN201.38	SPI1_CLK	GPIO11 ² / SPI1_CLK ^{3,4}	GPIO11
22	GPIO12	CN200.10	UIM2_CLK / PMW	GPIO12 ² / UIM2_CLK ⁴	PWM2/GPIO12
23	GND				
24	PWM1	CN200.4	UIM2_RESET / BUZZER	UIM2_RESET ⁴	PWM1
25	GPIO13	CN201.70	SPI1_SRDY	GPIO13 ² / SPI1_SRDY ^{3,4}	DEBUG_TX / GPIO13

Test Port #	Test Port Serigraphy	Board to Board Connector Pin #	HL6528x Signal Name	HL75xx Signal Name	HL85xxx Signal Name
26	GPIO14	CN201.68	SPI1_MRDY	GPIO14 ² / SPI1_MRDY ^{3,4}	DEBUG_RX / GPIO14
27	GPIO15	CN201.64	SPI1_MOSI	GPIO15 ² / SPI1_MOSI ^{3,4}	GPIO15
28	GPIO16	CN200.6	UIM2_DATA	NC2 / UIM2_DATA ⁴	NC2
29	GND				
30	GND				
31	PCM IN	CN201.78	PCM_IN	PCM_IN ⁵	PCM_IN
32	PCM OUT	CN201.76	PCM_OUT	PCM_OUT ⁵	PCM_OUT
33	PCM CLK	CN201.74	PCM_CLK	PCM_CLK ⁵	PCM_CLK
34	PCM SYNC	CN201.80	PCM_SYNC	PCM_SYNC ⁵	PCM_SYNC
35	GND				
36	GND				
37	MIC+	CN201.93	MIC_P	NC	NC
38	SPKR+	CN201.97	SPKR_P	NC	NC
39	MIC-	CN201.95	MIC_N	NC	NC
40	SPKR-	CN201.99	SPKR_N	NC	NC
41	GND				
42	GND				
43	ADC0	CN201.53	ADC0	NC	ADC0
44	ADC1	CN201.55	ADC1	ADC1	ADC1
45	BAT RTC	CN201.35	BAT-RTC	BAT_RTC	BAT_RTC
46	VGPI0	CN201.20	VGPI0	VGPI0	VGPI0
47	PWR ON	CN201.33	PWR_ON	PWR_ON	PWR_ON
48	VIO FL				
49	GND				
50	NC				
51	RESET IN	CN201.37	RESET_IN	RESET_IN	RESET_IN
52	2G TX ON	CN201.29	2G_TX_ON	TX_ON ^{2,7} / GPIO21 ³	2G_TX_ON
53	TP1 / BOOT	CN201.25	TP1	TP1	TP1
54	TP2 / JTAG TEST	CN200.84	RESERVED	26M_CLKOUT	26M_CLKOUT
55	LNA EN	CN200.32	EXT_LNA_GPS_EN	NC	EXT_LNA_GPS_EN ⁶
56	PPS	CN200.34	PPS	NC	PPS ⁶
57	32KHZ / VGPI0 SEL	CN200.76	NC	32K_CLKOUT	32K_CLKOUT
58	USB VBUS	CN201.92	NC	NC	NC
59	GND				
60	GND				
61	SIM1 VCC	CN201.43	UIM1_VCC	UIM1_VCC	UIM1_VCC
62	SIM1 RST	CN201.47	UIM1_RESET	UIM1_RESET	UIM1_RESET
63	SIM1 DATA	CN201.45	UIM1_DATA	UIM1_DATA	UIM1_DATA

Test Port #	Test Port Serigraphy	Board to Board Connector Pin #	HL6528x Signal Name	HL75xx Signal Name	HL85xxx Signal Name
64	SIM1 CLK	CN201.49	UIM1_CLK	UIM1_CLK	UIM1_CLK

- 1 Not available on the HL7518 and HL7548.
- 2 Not available on the HL7528 and HL7549.
- 3 Only available on the HL7528 and HL7549.
- 4 Not available on the HL7518, HL7519, HL7548 and HL7588.
- 5 Only available on the HL7528, HL7549 and HL7588.
- 6 Not available on the HL8518, HL8528 and HL8529.
- 7 Not available on the HL7518.

2.3. Special Solder for Jumper Solder Pads

Jumper solder pads are used for interfaces and peripherals that can be disconnected electrically.

To connect signals between the embedded module and the dedicated connector on the HL Series Development Kit, solder these jumper pads.



Figure 8. Jumper Solder Pad

Interfaces and peripherals that may be electrically disconnected via jumper solder pads include:

- Module Detection Circuit (from TP502 to TP507)
- PWM1 (from TP800 to TP801)
- PWM2 (from TP802 to TP803)
- VBATT_RF bypass U400 chipset (TP405)

Note: All jumper solders are **not soldered** in the initial development kit configuration.

3. Interfaces

3.1. Power Supply

Two power supply sources are available on the HL Series Development Kit:

- DC jack (via CN402)
- LABO connector (via CN401/CN400)



Figure 9. Power Supply Connector (CN402, CN401 and CN400)

Either power supplies can be used to supply the development kit, or they can be used to supply power to VBAT_BB and VBAT_RF separately depending on CN403 and CN404's jumper configuration. Refer to the following diagram for possible configuration settings.




Figure 10. Power Source Selection (Schematic Diagram and Actual Development Kit Picture)

Other interfaces on the development kit are powered by VBAT, which is connected to VBAT_BB through CN405 (refer to Figure 21 Jumper for Supplying the Development Kit Interfaces Separately for the location of CN405).

3.2. Control Functions

3.2.1. Power ON/OFF

Once the HL Series Development Kit is connected to an external source, the HL module will start monitoring the ON/OFF pin for a power on event. A power on event can be triggered by either:

- Pressing pushbutton SW601 once for approximately 2 seconds, or by
- Shorting CN601.1 and CN601.2.

Note that shorting pins 1 and 2 of CN601 bypasses the POK_IN signal which means that the development kit will be powered on as soon as it is connected to an external source (without needing to press pushbutton SW601).

The module can be powered off by disconnecting the development kit from the power source or by issuing the appropriate AT command. For more information about AT commands, refer to document [1] AirPrime HL6 and HL8 Series AT Commands Interface Guide.




Figure 11. PWR ON Pushbutton and CN601 Jumper

Note: Do not put a jumper between pins 2 and 3 of CN601. Doing this will cause the module to always reset. Refer to the following section for information about properly resetting the module.

3.2.2. ~RESET

The ~RESET pushbutton starts a general reset when it is pushed. Reset can only be executed after the module has been switched ON.

Note: An operating system reset is preferred to a hardware reset.




Figure 12. ~RESET Pushbutton

3.3. USB0

The USB0 connection on the development kit is available from CN902.

Note: This interface is not supported on the HL6528RD and HL6528RD-2.8V.

The HL Series modules provide an I²C interface for NMEA package delivery, and an I²C to USB transceiver is embedded on the HL Series Development Kit. The transceiver can be detected by the PC while the HL Series module is connected to the development kit.

For detailed information about the transceiver embedded on the development kit, refer to <http://www.ftdichip.com/Products/ICs/FT201X.html>.



Figure 13. USB0 Interface

3.4. USB1

The USB1 connection on the development kit is available from CN901.

Note: This interface is only used for the HL6528RDx, HL75xx and HL85xxx modules.



Figure 14. USB1 Interface

3.5. Audio

Note: *HL75xx and HL85xxx modules do not support analog audio.*

A headset jack (CN1105) is available on the development kit which allows the HL series module to connect to an audio interface. Switch SW1100 allows audio selection from direct analog audio connection or PCM codec conversion output, and switch SW1101 is used for activating an audio amplifier. Jumpers CN1103 and CN1104 are used to bypass or to enable an audio amplifier.




Figure 15. Audio Interface




Figure 16. 4-pin RJ9 Connector for Audio Signals

Refer to the following table for Audio connector signal pin description.

Table 5. Audio Connector Pin Description

Pin Number	Signal Name	I/O	I/O Type	Description
1	MIC_N	I	Analog	Microphone negative input
2	SPK_N	O	Analog	Main speaker negative output
3	SPK_P	O	Analog	Main speaker positive output
4	MIC_P	I	Analog	Main microphone positive input

Both microphone and speaker signals are configured in differential mode.

3.6. SIM1 and SIM2

The HL Series Development Kit has two SIM connectors:

- SIM1 (CN800)
- SIM2 (CN802)

The development kit also supports a SON8 embedded SIM (U805) which can be connected to the SIM1 interface of the embedded module by shorting CN804 with a jumper.




Figure 17. SIM1 and SIM2 Interface

Note: Sierra Wireless recommends that SIM1 be used for single SIM applications.

Table 6. SIM1 Connector Pin Description

Pin Number	Signal Name	I/O	I/O Type	Description
1	UIM1_VCC	O	1V7 << 1V9 or 2V7 << 2V95	SIM Power Supply
2	UIM1_RESET	O	1V7 << 1V9 or 2V7 << 2V95	SIM Reset
3	UIM1_CLK	O	1V7 << 1V9 or 2V7 << 2V95	SIM Clock
4	CC4	Not used		
5	GND			Ground
6	VPP	Not used		
7	UIM1_DATA	I/O	1V7 << 1V9 or 2V7 << 2V95	SIM Data
8	CC8	Not used		
9	VIO	I	VIO*	VIO supply from module
10	UIM1_DETECT	I	VIO*	SIM Card Detect
11,12,13,14	GND			Ground casing

* VIO = 1V8 or 2V8 depending on the HL embedded module.

Table 7. SIM2 Connector Pin Description

Pin Number	Signal Name	I/O	I/O Type	Description
1	UIM2_VCC	O	2V7 << 3V	SIM Power Supply
2	UIM2_RESET	O	2V7 << 3V	SIM Reset
3	UIM2_CLK	O	2V7 << 3V	SIM Clock
4	CC4	Not used		
5	GND			Ground
6	VPP	Not used		
7	UIM2_DATA	I/O	2V7 << 3V	SIM Data
8	CC8	Not used		
9	VIO	I	VIO*	VIO supply from module
10	UIM2_DETECT	I	VIO*	SIM Card Detect
11,12,13,14	GND			Ground casing

* VIO = 1V8 or 2V8 depending on the HL embedded module.

The following table shows SIM configuration support per HL Series Embedded Module. The development kit must be configured according to the SIM configuration being used.

Table 8. SIM Configuration

HL Variant	Configuration	SIM1	SIM2	Embedded SIM
HL6528x	Single SIM	✓		
			✓	
	DSDS*	✓	✓	
	DSSS**	✓		✓
HL7518	Single SIM	✓		
HL7519, HL7528, HL7548, HL7549 and HL7588	Single SIM	✓		
	DSSS**	✓		✓
HL85xxx	Single SIM	✓		
	DSSS**	✓		✓

* Dual SIM Dual Standby

** Dual SIM Single Standby

For HL6528x with single SIM configuration,

- When using SIM1, short CN801 with a jumper to enable SIM1 insertion detection
- When using SIM2,
 - SW800 should be switched to position “SIM2 & GPIO”
 - Short CN600 with a jumper to enable the SIM2 connector
 - Short CN803 with a jumper to enable SIM2 insertion detection

For HL6528x with DSDS (SIM1 and SIM2) configuration,

- SW800 should be switched to position "SIM2 & GPIO"
- Short CN801 with a jumper to enable SIM1 insertion detection
- Short CN600 with a jumper to enable the SIM2 connector
- Short CN803 with a jumper to enable SIM2 insertion detection

For HL6528x with DSDS (SIM1 and Embedded SIM) configuration,

- Short CN801 with a jumper to enable SIM1 insertion detection
- Short CN804 with a jumper to enable U805 (Embedded SIM)

For HL75xx and HL85xxx with single SIM configuration,

- Short CN801 with a jumper to enable SIM1 insertion detection
- Open CN804 to disable U805 (Embedded SIM)

For HL75xx and HL85xxx with DSSS (SIM1 and Embedded SIM) configuration,

- Short CN801 with a jumper to enable SIM1 insertion detection
- Short CN804 with a jumper to enable U805 (Embedded SIM)

3.7. UART1

UART1 connection on the development kit is available from CN700, which is a SUB-D 9-pin female connector. This interface is used to communicate between an AirPrime HL series module and a PC or host processor.




Figure 18. UART1 Connector

Refer to the following table for the UART1 connector pin description.

Table 9. Pin Description of the UART1 Connector

Pin #	Signal Name	I/O	I/O Type	Description
1	CT109 DCD	O	RS232 (V24/V28)	Data carrier detect
2	CT104 RXD	O	RS232 (V24/V28)	Receive serial data
3	CT103 TXD	I	RS232 (V24/V28)	Transmit serial data
4	CT108-2 DTR	I	RS232 (V24/V28)	Data terminal ready

Pin #	Signal Name	I/O	I/O Type	Description
5	GND			Ground
6	CT107 DSR	O	RS232 (V24/V28)	Data set ready
7	CT105 RTS	I	RS232 (V24/V28)	Request to send
8	CT106 CTS	O	RS232 (V24/V28)	Clear to send
9	CT125 RI	O	RS232 (V24/V28)	Ring indicator

3.8. UART0/SPI1

Note: This interface is not supported on the HL6528RDx and HL75xx.

The UART0/SPI1 connector, CN602, is a SUB-D 9-pin female connector and is used for connecting the HL Series embedded module's debug port interface.

This interface is used for legacy HL6528x "SpyTracer" debugging. For more information about SpyTracer debugging, refer to section 5.1 Getting SpyTracer Debugging Data.

When using the HL85xxx, the operating mode of this connector can be set using SW603. When using a legacy HL6528x module, the UART0 connector functions as an SPI to UART interface regardless of SW603's setting.




Figure 19. UART0 Connector

Refer to the following table for the UART1 connector pin description.

Table 10. UART0 Connector Pin Description

Pin #	Signal Name	I/O	I/O Type	Description
1	Not used*	-	-	-
2	CT104 RXD	O	RS232 (V24/V28)	Receive serial data
3	CT103 TXD	I	RS232 (V24/V28)	Transmit serial data
4	Not used*	-	-	-
5	GND			Ground
6	Not used*	-	-	-
7	CT105 RTS	I	RS232 (V24/V28)	Request to send
8	CT106 CTS	O	RS232 (V24/V28)	Clear to send
9	Not used*	-	-	-

* Only 4 signals are used.

3.9. GPIO Control

Note: This interface is not supported on the HL6528RDx.

Two switch sets, SW1000 and SW1001, are available on the Development Kit for GPIO test purposes.



Figure 20. GPIOs Control Switches

SW1000 enables GPIO1 to GPIO8; while SW1001 enables these GPIOs to be connected to VIO either as 1k Ω pull ups or 100 Ω pull lows.

GPIO settings can be set or reset using AT commands. For more information about AT commands, refer to document [1] AirPrime HL6 and HL8 Series AT Commands Interface Guide.

3.10. Current Measurement

Note: This interface is not supported on the HL6528RDx.

To measure the current consumed by the HL series embedded module, disconnect CN405 and supply the Development Kit interfaces separately. Refer to the following figure for the jumper location.




Figure 21. Jumper for Supplying the Development Kit Interfaces Separately

VBAT_BB and VBAT_RF can be measured separately or as a total current drain depending on the configurations of CN403 and CN404.

3.11. JTAG




Figure 22. JTAG Connector

Warning: This interface is not available for customer use. Default configurations should not be tampered with.

3.12. Antenna Connections

Note: This interface is not supported on the HL6528RDx.

Three SMA connectors are available on the HL Series Development Kit for main RF, 4G diversity and GNSS antenna connections.




Figure 23. RF, 4G Diversity and GNSS Antenna Connectors

3.13. RTC Backup Battery

Note: This interface is not supported on the HL6528RDx.

The HL Series Development Kit provides an input signal, BAT_RTC, for connecting a coin battery. This pin is used as a backup power supply to preserve the date and time when VBATT is switched OFF (no VBATT).

Connect pins 1 and 2 of CN406 with a jumper to use this feature.




Figure 24. RTC Coin Battery Location

>> 4. Getting Started with the HL Series Development Kit


This section describes how the AirPrime HL Series Development Kit is set up as well as describes communications testing, making calls and debugging with an embedded module.

4.1. Setting Up the Development Kit

Perform the following steps before powering the Development Kit on.

1. Ensure that switches and connectors are configured accordingly. By default, the development kit board is configured from the factory before shipment. Refer to Table 3 Available Connections for some of the board's default settings.
2. Plug in an HL Series embedded module to the Snap-in connector and attach the Snap-in cover. Or, when using an HL8549x module, solder it directly on the development kit.
3. Insert a SIM or USIM card in the SIM1 slot, CN800, if communications are required.

Note: *SIM2 is optional in the HL6528x, and not applicable for the HL75xx and HL85xxx.*



4. Connect the HL module to the PC.

For HL6528x, connect the RS232 cable between the PC port and CN700 of the Development Kit for UART1 connection.


By default, baud rate = 115.2Kbps, data bits = 8, parity = N, and stop bits = 1.

Note: *Although the HL75xx and HL85xxx support UART connections, it is highly recommended that a USB connection be used instead as UART may not be enabled by default in the firmware.*




For HL75xx and HL85xxx, connect the USB cable between the PC port and CN901 of the Development Kit for USB1 connection.


Note: *The provided USB driver should be also installed in the host computer.*



5. Connect a GSM or LTE antenna to CN303 of the Development Kit depending on the HL embedded module used.



6. Connect a GNSS antenna to CN304 of the Development Kit (when using an HL embedded module that supports GNSS).



7. Connect a 4G diversity antenna to CN302 when using an HL75xx module.




8. Connect a handset to CN1105 for audio communications.

For HL6528x, select either digital (PCM) or analog audio via SW1100.

For HL7588 and HL85xxx, select digital (PCM) audio via SW1100.



9. To get NMEA output, connect a USB cable to USB0.




10. Connect a 4V power supply unit to CN402.

Note: Make sure that Pin 2 and Pin 3 of CN403, as well as Pin 1 and Pin 2 of CN402 are connected with a jumper when using a 4V power supply unit.

Alternatively, a lab power supply can be connected to CN401 and CN400. (If using a lab power supply, it is recommended to set it to 3.7V with 4A output to prevent failure at power on.)

Note: Make sure that Pin 1 and Pin 2 of CN403, as well as Pin 2 and Pin 3 of CN402 are connected with a jumper when using a lab power supply.



The AirPrime HL Series Development Kit should look like the following figure after it has been properly set up.




Figure 25. AirPrime HL Series Development Kit with an HL6528 Embedded Module Inside the Snap-in Connector

4.2. Switching the Development Kit On

The Development Kit will automatically be powered on if Pin 1 and Pin 2 of CN601 are connected with a jumper. Otherwise, push SW601 for approximately 2 seconds to power the Development Kit on.




Figure 26. CN601 and SW601

Two green LEDs, D403 and D501, are lit when the Development Kit has been properly powered on and is ready for use.




Figure 27. D403 and D501

4.3. RF Communications with the HL6528x

4.3.1. Configure the COM Port

Configure the COM port settings by selecting the port which is connected to the Development Kit and specifying the following port settings.

- Bits per second 115200
- Data bits 8
- Parity None
- Stop bits 1
- Flow control Hardware

Test communications using a PC terminal emulator (for example, HyperTerminal) by entering **AT+J**. The module should answer with **OK**.





Figure 28. AT Communication with the AirPrime HL6528x


4.3.2. Make a Voice Call

To make a voice call with the Development Kit, follow these steps.


1. Ensure that:
 - a power cable is connected to CN402
 - a UART RS232 cable is connected to CN700
 - a SIM card is inserted in SIM1 (CN800)
 - CN801 is connected with a jumper
 - a GSM antenna is connected to CN303
 - a handset is connected to CN1105
 - SW1100 is switched to either “ANALOG” or “PCM” depending on whether analog or digital audio is to be used
 - SW1101 is switched to either “ON” or “OFF” depending on whether an audio amplifier is used
 - Pins 1 and 2 of jumpers CN1103 and CN1104 are connected to bypass the audio amplifier
 - Pins 2 and 3 of jumpers CN1103 and CN1104 are connected to enable the audio amplifier



2. From a PC terminal emulator (for example, HyperTerminal), input **AT+CPIN?**. If the SIM card is ready, the module will respond with **+CPIN: READY**, otherwise it will return **ERROR**.



3. Enter **ATD<phone number>;** to make a call. For example, enter **ATD13800138000;**.



4.4. RF Communications with the HL75xx and HL85xxx

The provided USB driver should be installed in the host computer. The HL75xx and HL85xxx modules are automatically detected when the USB cable is connected to the PC via the Development Kit board.

Test communications using a PC terminal emulator (for example, HyperTerminal) by entering **AT+J**. The module should answer with **OK**.






Figure 29. AT Communication with the AirPrime HL75xx and HL85xxx

To make a voice call with the Development Kit, follow these steps.


1. Ensure that:
 - a power cable is connected to CN402
 - a USB cable is connected to CN901
 - a SIM card is inserted in SIM1 (CN800)
 - CN801 is connected with a jumper
 - an antenna is connected to CN303 (GSM antenna for the HL85xxx; LTE antenna for the HL75xx)
 - an RF diversity antenna is connected to CN302 for the HL75xx
 - a handset is connected to CN1105
 - SW1100 is switched to “PCM” (note that the HL7518, HL7519 and HL7548 do not support PCM)
 - SW1101 is switched to either “ON” or “OFF” depending on whether an audio amplifier is used
 - Pins 1 and 2 of jumpers CN1103 and CN1104 are connected to bypass the audio amplifier
 - Pins 2 and 3 of jumpers CN1103 and CN1104 are connected to enable the audio amplifier



- From a PC terminal emulator (for example, HyperTerminal), input **AT+CPIN?**. If the SIM card is ready, the module will respond with **+CPIN: READY**, otherwise it will return **ERROR**.



- Enter **ATD<phone number>;** to make a call. For example, enter **ATD13800138000;**.




Note: The HL75xx will automatically attach to the network.

4.5. GPS Communications with the HL6528-G

To get GNSS NMEA output, ensure that:


- a power cable is connected to CN402
- a GNSS antenna is connected to CN304
- a UART RS232 cable is connected to CN700
- a micro USB cable is connected to USB0 (CN902), and
- SW900 is switched to position "I2C"



4.6. GPS Communications with the HL854x-G

To get GNSS NMEA output, ensure that:

- a power cable is connected to CN402
- a GNSS antenna is connected to CN304, and
- a micro USB cable is connected to USB1 (CN901)




>> 5. Other Hardware Settings

5.1. Getting SpyTracer Debugging Data (for HL6528x only)


Note: Contact your Sierra Wireless representative for more details about the SpyTracer tool.

To get SpyTracer debug data, follow these steps:


1. Ensure that:
 - a UART RS232 cable is connected to UART0 (CN602)
 - SW603 is switched to position "SPI/UART0"
 - SW600 is switched to position "UART0"




2. Open the SpyTracer tool in the PC.
3. Ensure that the configuration is correct for DEF, STR files and UART_0 port settings. Click **Configuration > Link...**




- a. Set up DEF and STR file settings as follows.




- b. Set up UART port settings as follows.




4. Configure mobile settings by clicking **Configuration > Link....**



- a. Set up mobile settings as follows.



- Click “Start”, then power on the development kit board. The screen should start printing information as shown in the figure below.






6. Reference Documents

- [1] AirPrime HL6 and HL8 Series AT Commands Interface Guide
Reference Number: 4114680
- [2] AirPrime HL6528x Product Technical Specification
Reference Number: 4114016
- [3] AirPrime HL6528x (Automotive) Product Technical Specification
Reference Number: 4116503
- [4] AirPrime HL6528RDx Product Technical Specification
Reference Number: 4117701
- [5] AirPrime HL7518 Product Technical Specification
Reference Number: 4115834
- [6] AirPrime HL7519, HL7548 and HL7588 Product Technical Specification
Reference Number: 4116369
- [7] AirPrime HL7528 Product Technical Specification
Reference Number: 4116873
- [8] AirPrime HL7549 Product Technical Specification
Reference Number: 4117459
- [9] AirPrime HL8518, HL8528, HL8528 Product Technical Specification
Reference Number: 4117047
- [10] AirPrime HL8548 and HL8548-G Product Technical Specification
Reference Number: 4114663
- [11] AirPrime HL8549 and HL8549-G Product Technical Specification
Reference Number: 4115653

7. Dev-Kit Schematic Diagrams





























SIERRA
WIRELESS®