



Firmware Download Protocol

AirPrime HL75xx and HL854xx



SIERRA
WIRELESS®

4116488
2.0
December 09, 2014

Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the Sierra Wireless modem are used in a normal manner with a well-constructed network, the Sierra Wireless modem should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Sierra Wireless accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the Sierra Wireless modem, or for failure of the Sierra Wireless modem to transmit or receive such data.

Safety and Hazards

Do not operate the Sierra Wireless modem in areas where cellular modems are not advised without proper device certifications. These areas include environments where cellular radio can interfere such as explosive atmospheres, medical equipment, or any other equipment which may be susceptible to any form of radio interference. The Sierra Wireless modem can transmit signals that could interfere with this equipment. Do not operate the Sierra Wireless modem in any aircraft, whether the aircraft is on the ground or in flight. In aircraft, the Sierra Wireless modem **MUST BE POWERED OFF**. When operating, the Sierra Wireless modem can transmit signals that could interfere with various onboard systems.

Note: Some airlines may permit the use of cellular phones while the aircraft is on the ground and the door is open. Sierra Wireless modems may be used at this time.

The driver or operator of any vehicle should not operate the Sierra Wireless modem while in control of a vehicle. Doing so will detract from the driver or operator's control and operation of that vehicle. In some states and provinces, operating such communications devices while in control of a vehicle is an offence.

Limitations of Liability

This manual is provided "as is". Sierra Wireless makes no warranties of any kind, either expressed or implied, including any implied warranties of merchantability, fitness for a particular purpose, or noninfringement. The recipient of the manual shall endorse all risks arising from its use.

The information in this manual is subject to change without notice and does not represent a commitment on the part of Sierra Wireless. SIERRA WIRELESS AND ITS AFFILIATES SPECIFICALLY DISCLAIM LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE OR ANTICIPATED PROFITS OR REVENUE ARISING OUT OF THE USE OR INABILITY TO USE ANY SIERRA WIRELESS PRODUCT, EVEN IF SIERRA WIRELESS AND/OR ITS AFFILIATES HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

Notwithstanding the foregoing, in no event shall Sierra Wireless and/or its affiliates aggregate liability arising under or in connection with the Sierra Wireless product, regardless of the number of events, occurrences, or claims giving rise to liability, be in excess of the price paid by the purchaser for the Sierra Wireless product.

Customer understands that Sierra Wireless is not providing cellular or GPS (including A-GPS) services. These services are provided by a third party and should be purchased directly by the Customer.

SPECIFIC DISCLAIMERS OF LIABILITY: CUSTOMER RECOGNIZES AND ACKNOWLEDGES SIERRA WIRELESS IS NOT RESPONSIBLE FOR AND SHALL NOT BE HELD LIABLE FOR ANY DEFECT OR DEFICIENCY OF ANY KIND OF CELLULAR OR GPS (INCLUDING A-GPS) SERVICES.

Patents

This product may contain technology developed by or for Sierra Wireless Inc.

This product includes technology licensed from QUALCOMM®.

This product is manufactured or sold by Sierra Wireless Inc. or its affiliates under one or more patents licensed from InterDigital Group and MMP Portfolio Licensing.

Copyright

© 2014 Sierra Wireless. All rights reserved.

Trademarks

Sierra Wireless®, AirPrime®, AirLink®, AirVantage®, WISMO® and the Sierra Wireless and Open AT logos are registered trademarks of Sierra Wireless, Inc. or one of its subsidiaries.

Watcher® is a registered trademark of NETGEAR, Inc., used under license.

Windows® and Windows Vista® are registered trademarks of Microsoft Corporation.

Macintosh® and Mac OS X® are registered trademarks of Apple Inc., registered in the U.S. and other countries.

QUALCOMM® is a registered trademark of QUALCOMM Incorporated. Used under license.

Other trademarks are the property of their respective owners.

Contact Information

| | | |
|--------------------|---|---|
| Sales Desk: | Phone: | 1-604-232-1488 |
| | Hours: | 8:00 AM to 5:00 PM Pacific Time |
| | Contact: | http://www.sierrawireless.com/sales |
| Post: | Sierra Wireless 13811 Wireless Way Richmond, BC Canada V6V 3A4 | |
| Technical Support: | support@sierrawireless.com | |
| RMA Support: | repairs@sierrawireless.com | |
| Fax: | 1-604-231-1109 | |
| Web: | http://www.sierrawireless.com/ | |

Consult our website for up-to-date product descriptions, documentation, application notes, firmware upgrades, troubleshooting tips, and press releases: www.sierrawireless.com

Document History

| Version | Date | Updates |
|---------|-------------------|---|
| 1.0 | October 23, 2014 | Creation |
| 2.0 | December 09, 2014 | Added section 7 FLS File Decoding Mechanism |
| | | Updated: <ul style="list-style-type: none"> • 3 Synchronization Process • 6.2.1 Download Protocol Configuration • 6.2.3 Hardware Information • 6.3 Flash Information • 6.4 Security Information • 6.8.2 USB |



Contents

| | |
|---|-----------|
| 1. OVERVIEW | 8 |
| 1.1. Purpose | 8 |
| 1.2. Glossary | 8 |
| 2. FIRMWARE DOWNLOAD OVERVIEW | 9 |
| 3. SYNCHRONIZATION PROCESS..... | 10 |
| 4. PSI DOWNLOAD PROCESS | 11 |
| 5. EBL DOWNLOAD PROCESS..... | 12 |
| 6. FIRMWARE DOWNLOAD PROCESS | 13 |
| 6.1. Firmware Download Protocol Frame Structure | 13 |
| 6.1.1. UART Protocol | 13 |
| 6.1.2. USB Protocol..... | 13 |
| 6.1.3. Payload Data..... | 13 |
| 6.2. Firmware Download..... | 14 |
| 6.2.1. Download Protocol Configuration | 14 |
| 6.2.2. Baud Rate | 15 |
| 6.2.3. Hardware Information..... | 16 |
| 6.3. Flash Information..... | 17 |
| 6.4. Security Information..... | 18 |
| 6.5. Flash Erase | 19 |
| 6.6. Flash Erase Check | 20 |
| 6.7. Flash Write Address | 21 |
| 6.8. Flash Write | 22 |
| 6.8.1. UART..... | 22 |
| 6.8.2. USB | 23 |
| 6.9. Firmware Checksum..... | 24 |
| 6.10. Modem Reset | 25 |
| 7. FLS FILE DECODING MECHANISM | 26 |
| 7.1. Element Header..... | 26 |
| 7.1.1. Type | 26 |
| 7.1.2. Size | 26 |
| 7.1.3. UID | 26 |
| 7.2. Element Data | 27 |
| 7.2.1. Download Data (Type=0x0C)..... | 27 |
| 7.2.1.1. DownloadData Header | 27 |
| 7.2.1.2. Download Data | 27 |
| 7.2.2. Table of Contents (Type=0x10) | 27 |
| 7.2.2.1. TableOfContent Entry..... | 28 |

| | | |
|-----------|--|-----------|
| 7.3. | Examples..... | 28 |
| 7.3.1. | Normal Element Block (Hardware Information) | 28 |
| 7.3.2. | Download Data..... | 28 |
| 7.3.3. | Table of Contents..... | 29 |
| 8. | APPENDIX: HL75XX DOWNLOAD FLOW EXAMPLE..... | 30 |



List of Figures

| | | |
|------------|--------------------------------------|----|
| Figure 1. | Firmware Download Overview | 9 |
| Figure 2. | Synchronization Process | 10 |
| Figure 3. | PSI Download Process..... | 11 |
| Figure 4. | EBL Download Process..... | 12 |
| Figure 5. | Download Protocol Configuration..... | 14 |
| Figure 6. | Baud Rate..... | 15 |
| Figure 7. | Hardware Information..... | 16 |
| Figure 8. | Flash Information..... | 17 |
| Figure 9. | Security Information | 18 |
| Figure 10. | Flash Erase | 19 |
| Figure 11. | Flash Erase Check | 20 |
| Figure 12. | Flash Write Address | 21 |
| Figure 13. | Flash Write – UART | 22 |
| Figure 14. | Flash Write – USB | 23 |
| Figure 15. | Firmware Checksum | 24 |
| Figure 16. | Modem Reset | 25 |

1. Overview

1.1. Purpose

This document describes the protocol used to download firmware into the flash of an AirPrime HL75xx or HL854xx embedded module from an external processor (either a PC or a microprocessor).

1.2. Glossary

| Term | Definition |
|----------|---|
| Boot ROM | Built-in software executed after hardware reset or power up |
| EBL | External Boot Loader |
| Flash | High-speed writable/readable/erasable non-volatile memory component |
| PSI | Primary Signed Image |
| RAM | Random Access Memory |
| ROM | Read Only Memory |



2. Firmware Download Overview

Firmware download is initiated when the firmware download tool from the host is run. Once this is run, the host will initiate the synchronization phase by sending “**AT**” to the modem.

At power up, or after reset, the modem will wait for 100 ms to receive the sync character “**AT**” from the host. If it receives “**AT**” in time, the synchronization phase will continue. After which the host will send the PSI to the modem. Once the PSI has been downloaded and executed in RAM, the host will send the EBL to the modem. And once the EBL has been downloaded and executed in flash, the firmware image data will be sent to the flash via EBL’s protocol.




Figure 1. Firmware Download Overview



3. Synchronization Process




Figure 2. Synchronization Process

1. Host sends the sync character "AT" (0x41 0x54) to the modem every 20 ms.
2. Modem returns first acknowledgement frame (0xF0 or 0xF1) if two sync characters are received.
3. Modem sends chip information (27 bytes for HL75xx, 23 bytes for HL854xx), which includes chip ID, chip version, etc. Additional information regarding chip information parameters are listed below.

For the HL75xx,

<Size> (byte 0) = 0x1C
<Chip ID> (byte 1) = 0x54
<Boot core version> (byte 2) = 0x35

For the HL854xx,

<Size> (byte 0) = 0x16
<Chip ID> (byte 1) = 0x51
<Boot core version> (byte 2) = 0x94



4. PSI Download Process




Figure 3. PSI Download Process

1. Host sends 4 bytes (described below) to the modem indicating the length (in bytes) of PSI.
Transmit frame = `0x30` (1 byte) `length` (3 bytes) = total of 4 bytes
E.g. If the length is `0x18 0xA2 0x00`, it means length = 41496 bytes ($0x00A218 = 41496$ in decimal).
2. Host sends (raw) PSI data of N bytes (where N = length sent in the previous command).
3. Host sends XOR checksum of PSI data.
Transmit frame = `checksum` (1 byte) `0x00 0x00 checksum` (1 byte) = total of 4 bytes, duplicate checksum in the frame.
E.g. `0x60 0x00 0x00 0x60` for checksum = `0x60`
4. Modem returns 2 bytes as acknowledgment.
Transmit frame = `0x01 0x01` (if the first byte is `0x01`, it means that the download was successful; but if the first byte is `0xFF`, it means that the download was unsuccessful).

5. EBL Download Process




Figure 4. EBL Download Process

1. Modem sends PSI Ready signal.
Transmit frame = `0x00 0xAA`
2. Host sends EBL length (in bytes).
E.g. `0x34 0xCE 0x03 0x00` for 249396 (= `0x0003CE34`) bytes
3. Modem confirms EBL length by sending an acknowledgement.
Transmit frame = `0xCC 0xCC`
4. Host sends (raw) EBL data of N bytes (where N = EBL length).
5. Host sends XOR checksum of EBL data.
Transmit frame = **checksum** (1 byte) `0x00 0x00` **checksum** (1 byte) = total of 4 bytes, duplicate checksum in the frame.
6. Modem returns acknowledgement.
Transmit frame = **Chip ID** (1 byte) **result** (1 byte); where **Chip ID** = `0x54` for HL75xx, and **Chip ID** = `0x51` for HL854xx, and **result** = `0xA5` if the process was successful.



6. Firmware Download Process

6.1. Firmware Download Protocol Frame Structure

6.1.1. UART Protocol



SOT (2 bytes) = 0x02 0x00

TYPE (2 bytes) = 0xXX 0xYY (bytes are swapped; actually represents 0xYYXX)

LENGTH (2 bytes) = 0xXX 0xYY (bytes are swapped; actually represents 0xYYXX. Must be an even number, with maximum value = 0x800.)

PAYLOAD (N bytes where N = **LENGTH**) = Payload data

CRC (2 bytes) = 0xXX 0xYY (bytes are swapped; actually represents 0xYYXX. Sum-of-byte, SOT and EOT are **not** included in the checksum calculation.)

EOT (2 bytes) = 0x03 0x00

6.1.2. USB Protocol



CRC (2 bytes) = 0xXX 0xYY (bytes are swapped; actually represents 0xYYXX. This is the sum-of-byte of the **TYPE**, **LENGTH** and **PAYLOAD** data bytes.)

TYPE (2 bytes) = 0xXX 0xYY (bytes are swapped; actually represents 0xYYXX)

LENGTH (4 bytes) = 0xWW 0xXX 0xYY 0xZZ (bytes are swapped; actually represents 0xZZYYXXWW)

PAYLOAD (N bytes where N = **LENGTH**) = Payload data

6.1.3. Payload Data

The length of the payload data depends on the **LENGTH** defined in the header.

For example, if using UART protocol and **LENGTH** = 0x04 0x00, this means that the actual length is 0x04 and that the payload should be 4 bytes long.

6.2. Firmware Download

6.2.1. Download Protocol Configuration

Before downloading the firmware, the download protocol configuration needs to be set. The modem and the host exchange EBL versions and list of extended capabilities to use.




Figure 5. Download Protocol Configuration

1. When EBL starts running, the modem sends the EBL version string and the list of extended capabilities supported by the EBL to the host (76 bytes raw data).
2. Host sends back the EBL version string and the list of extended capabilities.

Header: **TYPE = 0x86, LENGTH = 0x48**

Payload: **EBL version and the list of extended capabilities** (same as the raw data in step 1 above).

Additional information regarding EBL version and extended capabilities are listed below.

For the HL75xx,

<EBL version> (byte 12 to byte 43) =

```

58 4D 4D 37 | XMM7
31 36 30 5F 31 34 33 34 2E 35 30 30 5F 4D 31 53 | 160_1434.500_M1S
31 00 00 00 00 00 00 00 00 00 00 00 00 00 00 | 1
    
```

<comm_format> (byte 46) = 0x00 for USIF, 0x01 for USB

For the HL854xx,

<EBL version> (byte 12 to byte 43) =

```

58 4D 4D 36 | XMM6
32 36 30 5F 31 33 32 37 2E 31 30 30 5F 4D 31 53 | 260_1327.100_M1S
31 00 00 00 00 00 00 00 00 00 00 00 00 00 00 | 1
    
```

<comm_format> (byte 46) = 0x00 for USIF, 0x01 for USB

3. Modem sends acknowledgement frame.
 Header: **TYPE = 0x86, LENGTH = 0x02**
 Payload: **0x01 0x00**

6.2.2. Baud Rate

The command is sent by the host to change the baud rate of the modem.




Figure 6. Baud Rate

1. Host sends BAUDRATE command.
 Header: **TYPE = 0x82, LENGTH = 0x04**
 Payload: **baud rate** (4 bytes)
 E.g. **0x00 0x10 0x0E 0x00** for 921600 (= 0x000E1000)
2. Modem sends acknowledgement frame with same baud rate.
 Header: **TYPE = 0x82, LENGTH = 0x04**
 Payload: **baud rate** (same as the baud rate in step 1 above)
3. Host should wait for 20 ms for other commands in order to ensure that baud rate has changed.

6.2.3. Hardware Information

The command is sent by the host to transfer hardware information to the modem.




Figure 7. Hardware Information

1. Host sends HW Info command.

Header: **TYPE = 0x801, LENGTH = 0xAC**

Payload: **Hardware information** (platform, boot speed, etc.)

For the HL75xx, **Hardware information** details are as follows:

<Platform ID> (byte 0 to byte 3) = **0x14 0x00 0x00 0x00**

<Boot speed> (byte 8 to byte 11) = **0x00 0xC2 0x01 0x00**
(this value represents **0x1C200**, which is 115200 in decimal)

For the HL854xx, **Hardware information** details are as follows:

<Platform ID> (byte 0 to byte 3) = **0x0E 0x00 0x00 0x00**

<Boot speed> (byte 8 to byte 11) = **0x00 0xC2 0x01 0x00**
(this value represents **0x1C200**, which is 115200 in decimal)

2. Modem sends acknowledgement frame.

Header: **TYPE = 0x801, LENGTH = 0x02**

Payload: **0x00 0x00**

6.3. Flash Information

The command is sent by the host to request Flash information from the modem.




Figure 8. Flash Information

1. Host sends Flash Info command.
Header: **TYPE** = 0x84, **LENGTH** = 0x02
Payload: 0x00 0x00
2. Modem returns flash information.
Header: **TYPE** = 0x84, **LENGTH** = 0x100
Payload: **Flash information** (manufacturer, etc.)
For the HL75xx, <manufacturer> (byte 4 to byte 7) = 0x2C 0x00 0xB1 0x00
For the HL854xx, <manufacturer> (byte 4 to byte 7) = 0xC8 0x00 0xA1 0x00
3. Host sends Flash Info acknowledgement.
Header: **TYPE** = 0x85, **LENGTH** = 0x100
Payload: **Flash information** (same as the flash information in step 2 above)
4. Modem sends acknowledgement frame.
Header: **TYPE** = 0x85, **LENGTH** = 0x02
Payload: 0xFF 0xFF

6.4. Security Information

The command is sent by the host to verify the firmware to download. The payload contains the load map and the signature of the firmware image to download.




Figure 9. Security Information

1. Host sends Security Info command.

Header: **TYPE = 0x204, LENGTH = 0x800**

Payload: **Load map and signature** (2048 bytes)

Additional information regarding load map and signature are listed below.

<Security data, signature and flags> (byte 0 to byte 1919) = **0xXX, 0xYY, ...**

<LoadMap> (byte 1920 to byte 2047) is 128 bytes long and supports up to 8 load map sections (16 bytes each). The structure of each load map section (4x4 bytes) is:

```

typedef struct {
    U32 StartAddr;
    U32 TotalLength;
    U32 UsedLength;
    U32 ImageFlags;
}RegionStructType;
  
```

The start address and end address used in sections 6.5 and 6.7 refer to the information specified here; start address = **StartAddr** in the load map and end address = **StartAddr + UsedLength - 2**.

2. Modem sends acknowledgement frame.

Header: **TYPE = 0x204, LENGTH = 0x02**

Payload: **0xXX 0x00** (where **0xXX = 0x00** means normal download, and **0xXX = 0x01** means the firmware image to be downloaded can be considered as identical to the installed firmware image; download is not needed).

6.5. Flash Erase

The command is sent by the host to specify the start address and the end address of the flash area to erase. After this command is acknowledged, erasing will be conducted in the background.




Figure 10. Flash Erase

1. Host sends Flash Erase command.

Header: **TYPE = 0x805, LENGTH = 0x08**

Payload: **start address** (4 bytes) and **end address** (4 bytes)

E.g. **0x00 0x00 0x0A 0x00 0xFE 0xFF 0x0B 0x00** (where **start address = 0x000A0000**, and **end address = 0x000BFFFE**)

2. Modem sends acknowledgement frame.

Header: **TYPE = 0x805, LENGTH = 0x02**

Payload: **0x00 0x00**

6.6. Flash Erase Check

The command is sent by the host to check if the erase procedure has finished.




Figure 11. Flash Erase Check

1. Host sends Flash Erase Check command.
 Header: **TYPE = 0x806, LENGTH = 0x02**
 Payload: **0x00 0x00**
2. Modem sends acknowledgement frame.
 Header: **TYPE = 0x806, LENGTH = 0x06**
 Payload: **state** (1 byte), **start address** 4 bytes and **0x00** (where **state = 0x01** if erasing is finished, else erasing is not yet finished; and **start address** should be the same start address sent in step 1 of section 6.5 Flash Erase)

6.7. Flash Write Address

The command is sent by the host to set the address pointer for writing to the flash.




Figure 12. Flash Write Address

1. Host sends Flash Write Address command.

Header: **TYPE** = 0x802, **LENGTH** = 0x04

Payload: **start address**

E.g. 0x00 0x00 0x0A 0x00 (where **start address** = 0x000A0000)

2. Modem sends acknowledgement frame.

Header: **TYPE** = 0x802, **LENGTH** = 0x02

Payload: 0x00 0x00

6.8. Flash Write

Although USB and UART adopt different methods to send data streams, commands are sent by the host to write a chunk of data to the flash memory for both protocols.

Before the command is sent, make sure that the flash erase process of the target area has finished.

6.8.1. UART

The host truncates the firmware image into blocks and sends the blocks to the modem one by one. Each block has a maximum of 2048 bytes. The firmware image is fully downloaded when all blocks have been sent to the modem.




Figure 13. Flash Write – UART

1. Host sends Flash Write Block command.

Header: **TYPE = 0x804, LENGTH = 0x800** (note that the length can be less than 0x800 if needed, i.e. the payload is less than 2048 bytes in the last block)

Payload: **Block data of firmware image**

2. Modem sends acknowledgement frame for every block.

Header: **TYPE = 0x804, LENGTH = 0x02**

Payload: **CRC for the received block**

3. Repeat steps 1 and 2 above until all data blocks are sent.

6.8.2. USB

In this mode, larger chunks of data can be sent using the USB layer’s handshake mechanism. The first package will have a payload of length 4 bytes, indicating the length of every chunk of data to be sent. The raw data will be sent to the modem immediately after this. The upper length limit for each chunk of data is 0x20000 (131073 bytes). Repeat this process if massive data is required to be sent chunk by chunk.




Figure 14. Flash Write – USB

1. Host sends Flash Write Raw command.
 Header: **TYPE = 0x80F, LENGTH = 0x04**
 Payload: **data length**
 E.g. 0x00 0x00 0x02 0x00 = 0x20000 (131072 bytes)
2. Host sends firmware image (raw data of N bytes where N = data length).
3. Modem sends acknowledgement frame.
 Header: **TYPE = 0x80F, LENGTH = 0x04**
 Payload: **Dummy (4 bytes)**

6.9. Firmware Checksum

The command is sent to request verification of the firmware image downloaded and check if it has been downloaded successfully.




Figure 15. Firmware Checksum

- Host sends Firmware Checksum command.
 - Header: **TYPE** = 0x205, **LENGTH** = 0x02
 - Payload: 0x00 0x00
- Modem sends acknowledgement frame.
 - Header: **TYPE** = 0x205, **LENGTH** = 0x04
 - USB Payload: 0x01 0x00 0xXX 0xYY (where the firmware checksum = 0xYYXX)
 - UART Payload: 0x01 0x00 0x00 0x00

6.10. Modem Reset

The command is sent by host to force the target to reset. This will cause the protocol to shut down and the target will start-up in normal mode.




Figure 16. Modem Reset

Host sends Modem Reset command.

Header: **TYPE** = 0x208, **LENGTH** = 0x04

Payload: 0x01 0x10 0x11 0x00



7. FLS File Decoding Mechanism

Several FLS files could be packed into one FLS file. The current HL854xx firmware release consists of six FLS files. The host needs to download these six files into the HL854xx Embedded Module one by one, according to their load map. The HL75xx firmware on the other hand, consists of a single FLS file from where six FLS files can be extracted from. The same flashing process used for the HL854xx should then also be used for the HL75xx.

The FLS file has a block by block structure where each element block contains a specific type of information and consists of an **element header** and its **element data**.

7.1. Element Header

Each element header takes 12 bytes in the form of 3 unsigned integer variables representing its type, size and UID as follows:

```
typedef struct {
    U32    Type;
    U32    Size;
    U32    UID;
}ElementHeaderStructType;
```

7.1.1. Type

Type indicates the type of information stored in a block. Each type of information (e.g. hardware information, security information) has its unique Type value. Some necessary values are specified below:

- Type = 0x0C refers to flashing data (the actual data to be downloaded into ROM)
- Type = 0x0D refers to hardware information (see section 6.2.3)
- Type = 0x0F refers to security information (see section 6.4)
- Type = 0x10 refers to table of contents (used for the HL75xx to extract the embedded FLS files)
- Type = 0x12 refers to PSI data patch (see section 4)
- Type = 0x13 refers to EBL data patch (see section 5)
- Type = 0x02 refers to the last element block of FLS file

7.1.2. Size

Size represents the total length (in bytes) of the block, including the element header (12 bytes) and data (N bytes).

7.1.3. UID

The UID correspond to the table of contents (see section 7.2.2) used with the HL75xx. Each table of contents entry has one UID.

7.2. Element Data

7.2.1. Download Data (Type=0x0C)

Contained in the element data of Download Data (Type=0x0C) is a sub-block with DownloadData Header and Download Data. Download Data is the exact data to be downloaded. The block structure is as follows:

[Element Header (Type=0x0C)][DownloadData Header][Download Data]

7.2.1.1. DownloadData Header

```
typedef struct
{
    U32 LoadMapIndex;
    U32 CompressionAlgorithm;
    U32 CompressedLength;
    U32 CRC;
    U32 DataLength;
    U8 *Data;
    U32 DataOffset;
}DownloadDataStructType;
```

Where:

<DataLength> (byte 16 to byte 19) indicates the total length (in bytes) of the flashing data to be transmitted. This is identical with the <UsedLength> in load map.

<DataOffset> (byte 24 to byte 27) indicates the offset value with respect to the FLS file. (In the case of the HL75xx, this is the offset value of the packed FLS file, i.e. the full FLS file with its six embedded FLS packed inside.)

7.2.1.2. Download Data

The range of Download Data starts from <DataOffset>, and is <DataLength> bytes long.

7.2.2. Table of Contents (Type=0x10)

In the HL75xx, six FLS files are packed into one FLS file. In order to download the FLS files one by one, the host needs to extract the files according to the Table of Contents. Information regarding Table of Contents parameters are as follows:

<NoOfEntries> (byte 0 to byte 3) indicates how many entries are stored in the table of contents

<DataOffset> (byte 8 to byte 11) indicates the offset value with respect to the FLS file

7.2.2.1. TableOfContent Entry

Starting with <DataOffset>, several TableOfContent Entry sub-blocks are stored, with the total number of entries specified by <NoOfEntries>. Each TableOfContent Entry sub-block is 144 bytes, and contains the variables listed below.

<UID> (byte 0 to byte 3) matches with the <UID> in section 7.1.3. In the case of the HL75xx, there are six TableOfContent Entry sub-blocks, with <UID> ranging from 0 to 5, representing the unique ID for each packed FLS file.

<MemoryClass> (byte 4 to byte 7) and can have the following values:


- 0x01 = PSI
- 0x02 = SLB
- 0x04 = CODE
- 0x05 = CUST

<FileName> (byte 16 to byte 143) stores an ASCII string of the file name of each packed FLS file.


7.3. Examples

7.3.1. Normal Element Block (Hardware Information)

The following is an example of a block for hardware information trimmed from an FLS file. Blocks on PSI, EBL and security information have the same structure.



7.3.2. Download Data



7.3.3. Table of Contents

Type = 0x10, Size = 0x3078, UID = 0 NoOfEntries = 6 DataOffset = 0x20D10

| | | | | |
|---------|-------------------------------------|-------------|-------------|-------------|
| | 10 00 00 00 78 03 00 00 00 00 00 00 | 06 00 00 00 | 00 00 00 00 | 10 0D 02 00 |
| UID = 0 | 00 00 00 00 01 00 00 00 00 00 00 00 | 00 00 00 00 | 70 73 69 2E | 66 6C 73 00 |
| | 00 00 00 00 00 00 00 00 00 00 00 00 | 00 00 00 00 | 00 00 00 00 | 00 00 00 00 |
| | 00 00 00 00 00 00 00 00 00 00 00 00 | 00 00 00 00 | 00 00 00 00 | 00 00 00 00 |
| | 00 00 00 00 00 00 00 00 00 00 00 00 | 00 00 00 00 | 00 00 00 00 | 00 00 00 00 |
| | 00 00 00 00 00 00 00 00 00 00 00 00 | 00 00 00 00 | 00 00 00 00 | 00 00 00 00 |
| | 00 00 00 00 00 00 00 00 00 00 00 00 | 00 00 00 00 | 00 00 00 00 | 00 00 00 00 |
| UID = 1 | 01 00 00 00 02 00 00 00 00 00 00 00 | 00 00 00 00 | 73 6C 62 5F | 73 69 67 6E |
| | 65 64 2E 66 6C 73 00 00 00 00 00 00 | 00 00 00 00 | 00 00 00 00 | 00 00 00 00 |
| | 00 00 00 00 00 00 00 00 00 00 00 00 | 00 00 00 00 | 00 00 00 00 | 00 00 00 00 |
| | 00 00 00 00 00 00 00 00 00 00 00 00 | 00 00 00 00 | 00 00 00 00 | 00 00 00 00 |

MemoryClass = SLB
MemoryClass = PSI



8. Appendix: HL75xx Download Flow Example

The following shows an actual data flow of an HL75xx firmware download over USB.

Host sends the sync character "AT"

41 54 41 54

Host receives acknowledgement

F1

Host receives chip information

1C 54 35 05 00 15 00 00 00 E0 10 0C 09 70 20 94 C1 48 E6 EC 2E
92 30 00 20 00 FF

Host sends PSI length

30 04 80 01

Host sends PSI data

72 35 00 EA 6C 69 48 55 02 A0 FE FF F4 01 9A 05
00 80 01 00 10 03 00 00 00 03 00 00 04 03 00 00
FF FF FF FF FF FF FF FF 00 7F 01 00 FF FF FF FF
00 00 08 00 FF FF F7 FF 00 03 08 00 43 4A 4B 54
.....suppressed.....
EC E6 C2 74 22 C4 10 A4 E4 FE F1 92 B9 DF 29 33
54 D4 75 91

Host sends PSI checksum

BF 00 00 BF

Host receives acknowledgement

01 01

Host receives PSI Ready signal

00 AA

Host sends EBL length

34 CE 03 00

Host receives acknowledgement

CC CC

Host sends EBL data

28 B4 25 67 80 84 9D 97 13 A2 35 38 9F CC 0A 8B
.....suppressed.....
36 08 DA 0C 08 09 A6 B8 72 0F 0A 4D 04 08 09 9E
F8 09 51 08 (249396 bytes)

Host sends EBL checksum

54 00 00 54

Host receives acknowledgement

54 A5

Host receives EBL Info command

BB 00 00 00 9A 05 00 00 F4 01 00 00 58 4D 4D 37
 31 36 30 5F 31 34 33 34 2E 35 30 30 5F 4D 31 53
 31 00 00 00 00 00 00 00 00 00 00 00 03 10 01 01
 01 00 01 00 00 01 01 01 00 00 00 00 00 00 00 00
 28 01 04 00 04 00 00 00 00 00 00 00 00

Host sends EBL Info command

56 08 86 00 48 00 00 00 BB 00 00 00 9A 05 00 00 F4 01 00 00 58
 4D 4D 37
 31 36 30 5F 31 34 33 34 2E 35 30 30 5F 4D 31 53
 31 00 00 00 00 00 00 00 00 00 00 00 03 10 01 01
 01 00 01 00 00 01 01 01 00 00 00 00 00 00 00 00
 28 01 04 00 04 00 00 00 00 00 00 00 00

Host receives acknowledgement

89 00 86 00 02 00 00 00 01 00

Host sends BAUDRATE command

A4 00 82 00 04 00 00 00 00 10 0E 00

Host receives acknowledgement

A4 00 82 00 04 00 00 00 00 10 0E 00

Host request HW Info command

BF 1B 01 08 AC 00 00 00 14 00 00 00 00 00 00 02
 00 C2 01 00 00 00 00 00 00 00 00 00 01 00 00 00
 FF 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
 00 00 00 00 FF 00 00 00 00 00 00 00 00 00 00 00
 00 00 00 00 00 00 00 00 FF 00 00 00 00 00 00 00
 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
suppressed.....
 00 00 00 00 00 00 00 00

Host receives acknowledgement

03 08 01 08 02 00 00 00 00 00

Host sends Flash Info command

86 00 84 00 02 00 00 00 00 00

Host receives Flash Info command

61 02 84 00 00 01 00 00 00 00 00 00 2C 00 B1 00
 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
suppressed.....
 00 00 00 00 00 00 00 00

Host sends Flash Info acknowledgement

```
62 02 85 00 00 01 00 00 00 00 00 00 2C 00 B1 00
00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
.....suppressed.....
00 00 00 00 00 00 00 00
```

Host receives acknowledgement

```
85 02 85 00 02 00 00 00 FF FF
```

Host sends Security Info command

```
E8 E6 04 02 00 08 00 00 BD 73 12 9F 90 19 99 44
3F BE 17 F1 BE 26 A0 F6 8A A0 D7 1B 9E 7C EF DA
.....suppressed.....
00 00 00 00 00 00 00 00
```

Host receives acknowledgement

```
07 02 04 02 02 00 00 00 01 00
```

Host sends Flash Erase command

```
1F 0A 05 08 08 00 00 00 00 00 0A 00 FE FF 0B 00
```

Host receives acknowledgement

```
07 08 05 08 02 00 00 00 00 00
```

Host sends Flash Erase Check command

```
08 08 06 08 02 00 00 00 00 00
```

Host receives acknowledgement

```
17 08 06 08 06 00 00 00 01 00 00 0A 00 00
```

Host sends Flash Write Address command

```
10 08 02 08 04 00 00 00 00 00 0A 00
```

Host receives acknowledgement

```
04 08 02 08 02 00 00 00 00 00
```

Host sends Flash Write Raw command

```
15 08 0F 08 04 00 00 00 00 00 02 00
```

Host sends firmware image

```
83 C1 9A 9D 76 5C 32 FE 7C CD
.....suppressed.....
83 C1 9A 9D 76 5C 32 FE 7C CD
```

Host receives acknowledgement

```
13 08 0F 08 04 00 00 00 00 00 00 00
```

The process of the host sending the Flash Write Raw command, sending the firmware image and then receiving acknowledgement is repeated until all chunks of data are sent.

Host sends Firmware Checksum command

```
07 02 05 02 02 00 00 00 00 00 00 00
```

Host receives acknowledgement

```
EC 02 05 02 04 00 00 00 01 00 85 5D
```

Host sends Modem Reset command

2E 02 08 02 04 00 00 00 01 10 11 00

Modem resets and the download process is finished.



SIERRA
WIRELESS®