

Hive EV Charging

EO Mini Pro 3 Installation Guide



Contents

Before you start	3
Charger installation	4
Software setup	8
Smart Charging	9
Randomised Delay	10
PEN fault detection	13
GSM – Hive SIM	13
Customer registration	14
Wiring connections	16
Status light	16
Hive support centre	17


Before you start

1. Register with EO as an installer and complete the necessary induction modules.

Failure to register with the EO academy may invalidate the customer's warranty.

2. Ensure you have access to a mobile device that can connect to Wi-Fi, and appropriately sized cable glands, based on cable sizing.
3. Find the Installer Details label within the rear housing (see below) and take a clear photo where you can read the text clearly. **You will need to refer to this later.**

NOTE: Technical support is available at <https://eouk-eocharging.talentlms.com/>



Charger installation

1. Remove all packaging.


In the box:

A) Fascia – this is the last component to fit


B) Centre section containing the charger socket and main electrical components

C) Rear housing containing the electronics, including the Wi-Fi and GSM modems, make sure you have a clear photo of the Installer Details label on the inside wall of the main housing (see image **C**)


A




B




C



2. Place the base of the EO Mini Pro 3 in the installation location and make sure the surface is flat and level.
3. Level the EO Mini Pro 3 base and mark the position of the four holes.
4. Take the EO Mini Pro 3 base away and drill the four holes in the mounting surface.




5. Attach the EO Mini Pro 3 base to the wall using the four screws provided. Make sure the charger is secure and flush against the wall. Use packing washers if necessary for a flush fit.
6. Strip and prepare the power cable and feed into the pre-made hole and stuffing gland, using an appropriately sized gland (25mm gland provided).



7. Connect the live, neutral, and earth wires to the charger connector block.


NOTE: There is no need to modify (tighten or loosen) either of the following connections in the charger as all of these fixings are tightened to the correct setting in the factory:

- Mains Power Terminal
- Castle nuts on the PCB





When connecting CT clamps for load management, there is a four-pin connector block in the lower right of the unit (see right). Ensure this is firmly seated before moving on.

IMPORTANT: If a separate CT wiring label is supplied with the charger, follow the instructions on this label. It is specific to the charger you are installing and supersedes this guide.



Wire designations for load management

Connector Number	CT Assignment	CT Wiring Colour	Function
1	CT1B	Red	ALM
2	CT1A	White	ALM



The CT clamps supplied have a red and white wire attached to them.

The CT for load management should be connected to CT1. Connect the white wire to position 2 and the red wire to position 1.


Make sure to orientate the CT clamps correctly when connecting them to the supply cable.

The clamps have an arrow which should be orientated with the current flow, which is the flow from the supply.

8. Take a photo of the Installer Details label if you haven't already. You will need this information to configure the charger once the unit is assembled.
9. Before closing the charger case, check that the PCB tethering lead is plugged in and connects both front and rear PCB boards together, as shown on the next page.



Make sure the lead is connected to the right-hand male connector of the rear case, as below:




10. With all cables securely connected, close the Mini Pro 3 cases together, making sure no internal cabling is trapped, and secure the housings together with the four hex bolts and washers.
11. Do not attach the fascia to the EO Mini Pro 3 until all testing is done. Complete all testing before closing the unit.



Software setup

1. Power up the charger.
2. You will see a hotspot with the name eo-xxxxxxxxxxxxxx - it may take a couple of minutes to appear. The hotspot expires after 10 minutes if no connection is made. You must power the charger down and back up again to reactivate the hotspot.
3. Use a laptop or mobile device to search for the Wi-Fi hotspot and join it, using the credentials on the Installer Details label – you should be able to see these in the photo you took earlier of the label.



NOTE: For Windows OS, you may be limited to entering eight characters into the password field. To enable more characters, click **Connect using a security key** instead.

4. Once connected to the hotspot, open your device's web browser.
5. In the address bar, type 10.10.10.1 - your browser may warn you with a security message. Accept it and proceed.
6. You should now see the charge point User Interface [UI] login page.



7. Enter the UI credentials from the Installer Details label.

8. Confirm charger settings.

eo EO CHARGING

Installer Settings

Charger Settings

Timezone
(UTC+00:00) Dublin, Edinburgh, Lisbon, London Save Timezone

Charger Current Limit (8 - 63A)
32

Installer Info

Installer Name (text) Installer Company (text) Installer Email (email)
My Name My Company myemail@myemail.com

EVSE #1/1

Tilt/Bump Detection

☒ Enabled Bump Acceleration (1 - 15g) Tilt Angle (1 - 80°
1 1 save tilt + calibrate

- Check and set the time in your location
- Enter your installer details
- Enter the charger current limit. This is set at 32A, but you may want to reduce this if site capacity is not adequate
- Check and amend the phase selection and connection where applicable
- Make sure Tilt/Bump Detection is enabled
- Make sure the Bump Acceleration is set to 2g and Tilt Angle to 10°
- Tap Save Tilt + Calibrate to confirm if you have changed any of these values
- A CT clamp is provided for load management. Select External Metering, set it to CT clamp and save your settings (see first image on the next page)
- If an external CT clamp has been fitted, enable the option, enter the CT rating and set the Type to Site
- Make sure your CT clamp is connected at the outgoing live cable, then click Save + Calibrate

Phase Settings

Installer Phase Selection: Single-Phase Phase Connection (v1): R (L1)

External Metering

External CT Clamps: ☒ Enabled

CT Clamps

Clamp #	On/Off	Rating [A]	Type
Clamp #1	<input checked="" type="checkbox"/>	100	Source Site Load external
Clamp #2	<input type="checkbox"/>	8	Source Site Load external

[save all configuration + calibrate](#)

[reset to default](#)

CT Types

Source: An external source of energy.

Site: Boundary point into a property which will contain the charger usage within it.

Load: An external load to the charger that does not contain the charger usage.

Load Management

Where a CT clamp is fitted you can set parameters for load management on the Load Balancing page.

Load Balancing

Settings

Enabled: ☒ Load Balancing Enabled

Load Balancing Mode: Dynamic

Load Balancing Minimum Change [A]:

Load Balancing Minimum TopUp Charge [A]:

Load Balancing Margin [A]:

Site Limit [A]:

Load Balancing Minimum Delay [s]:


[Save](#)

Load balancing is switched off by default so slide the toggle to allow inputs.

1. Set the site limit value. This is the incoming supply value to the property. e.g. 60 or 100 Amps.
2. Input a load balancing margin. This will be a safety value in amps. For example, you may wish to set a safety margin of 50A on a 60A incoming supply. We recommend referring to your site load tests for more accurate inputs in these fields.
3. Select Dynamic from the Load Balancing Mode menu and save your settings.
4. Set Load Balancing Minimum Change to 1A.
5. Set the Safety Margin to the appropriate values, for example, 100A and 10A.
6. Save your settings.

Smart Charging

In accordance with UK regulations, all chargers are supplied with a Smart Charging profile enabled. Customers can log in to the charging station using their EV user account to view their transaction history and modify their default charging schedules and Randomised Delay settings.



The screenshot shows the 'Smart Charging' settings page in the EO CHARGING interface. On the left is a dark sidebar menu with options: Info, Transactions, CSMS, Smart Charging (highlighted), EVSE, Network, SCC, LED, Admin, Installer, Load, and Logout. The main content area is titled 'Smart Charging' and contains two sections. The 'Default Charging Profile' section has a 'Default Profile' toggle set to 'Enabled' (indicated by a green checkmark). Below this, it states 'No charging during these periods' and lists two time periods: Period 1 from 08:00 to 11:00, and Period 2 from 16:00 to 22:00. The 'Randomised Delay' section has a 'Max Delay [0-1800s]' input field set to 600. A blue 'Save' button is located at the bottom of the settings area.

If the charger will be used with the Hive app:

Disable the toggle beneath Default Profile and set the Max Delay (beneath Randomised Delay) to 0. These will be overridden by the Hive app.

If the charger will be used as a non-smart charger, without the Hive app:

Set the Default Profile to suit the customer's requirements. Otherwise, they will only be able to charge outside of the periods set by the factory.

Set Max Delay to 600s and check all settings with the customer. Otherwise, the charger may not work as they expect.

NOTE: Any Smart Charging settings you configure for non-smart operation may impact testing or demonstration of the device to the user. After you have confirmed these settings in line with the end user's requirements, you may need to temporarily disable the Smart Charging profile (using the toggle under Default Profile) to carry out any test or demonstration. To re-enable it after your testing / demonstration is complete please follow the initial hotspot connection process and navigate back to the Default Profile section.

Randomised Delay

There is a risk of overloading the grid if lots of people start or stop charging their EV at the same time. To avoid this, all EV chargers now have a Randomised Delay feature. This means that there will be a random delay of up to 10 minutes when customers start or stop charging, which will help the grid stay balanced.

This setting is a legal requirement so it can't be switched off, but it doesn't apply to customers who have their own energy generation (such as wind or solar) and are using their own excess energy. EV chargers that provide Demand Side Response are also exempt.

The default setting is 600 seconds. This means that when the customer plugs their EV into the charger, it will start charging anywhere between immediately and 10 minutes later.

If it is set to zero, the charger will always try to start charging as soon as an EV is plugged in.

IMPORTANT: NEVER give a customer your installer access credentials as it could cause damage and be a health and safety risk. Customers can amend their settings with their own login details, which are provided on their own access label. The functions they can access are limited for safety reasons. They can find more details in their user guide.

PEN fault detection

Hive's EO Mini Pro 3 models HIVE-EV-01 and HIVE-EV-02 have built-in Protective Multiple Earth (PEN) fault detection and no configuration is needed.

GSM – Hive SIM

For units that are GSM-enabled with a Hive SIM:

1. Select the Network page from the left-hand menu.
2. At the bottom of the page, you will find a Modem section showing SIM status details. Do not change these settings.
3. Modem Status messages:
 - **SIM Status:** This shows the charger can see the SIM and communicate with it.
 - **IP:** Displays the IP address assigned by the network provider.
 - **PING Test:** Displays a successful communication ping to the back office.
 - **RSSI:** Signal strength.

Modem

ICCID	IMSI	IMEI	
89883040000025337051	206018131523705	865456053290407	
COPS	RSSI [dBm]		
Automatic, O2 - UK, User-specified GSM access technolo	-66		
SIM Status	IP	PING IP	PING Test
SIM OK	129.168.2.30	8.8.8.8	⇒ 2.5ms
restart modem (interface + service)		refresh modem info	
APN	Username	Password	show <input type="checkbox"/>
wlapn.com	JUUCELIM	*****	
save			

4. Connection via GSM will not occur unless the Wi-Fi hotspot connection has timed out or closed so disconnect from the hotspot and reboot the charger.

Physical EO Mini Pro 3 installation is now complete. The customer can now log in to the Hive App to complete setup of the charger. If the customer has not received a charger PIN from Hive then please follow the customer registration steps which follow.

NOTE: If you are unable to connect the charger via GSM, please contact Hive Support on +44 (0)333 202 1054

Customer registration

The customer needs to be registered with Hive to receive the PIN that is required to add their EO Mini Pro 3 charger to the Hive App. You can complete this by:

- Going to hivehome.com/ev-charging-retail or scanning the QR code on the Installer Details label
- Entering their details on the registration form
- Adding their Charger PIN, which they'll receive by email from Hive

NOTE: If you are installing this device in a new build property or somewhere else where you do not have the customer's details, the registration process allows you to input information so Hive can onboard the customer later.

After completing the installation and configuration of the charger, it may update to the latest firmware. This may take a few minutes.

Important installation information

Topic	Note
Characteristics of power supply input	Permanently connected to 230V AC supply
Characteristics of power supply output	Supplies 230V AC to the vehicle
Normal environmental conditions	Can be installed indoors or outdoors
Access requirements	Can be installed with no access restrictions
Mounting method	Stationary equipment intended for surface or post mounting
Protection against electric shock	Class I equipment
Charging mode	Mode 3 charging equipment
Ventilation during the supply of energy	Does not support ventilation during charging
Ingress protection	IP54
Mechanical strength	IK08
Operating temperature	-25°C to +50°C
Height of installation	The charging equipment should be mounted with the bottom face of the enclosure at least 0.9m above ground level. For tethered units, the holster height should be between 0.5m & 1.5m above ground level
Usage of adaptors/cord extension sets	Adaptors and conversion adaptors sets are not permitted to be used with the equipment. Cord extension sets are not permitted to be used
Maximum altitude	2000m
Pollution degree	Pollution Degree 2
Torque setting for main input cables	1.2 Nm
Skill level	Operation by ordinary – Installation by skilled authorised electrician

IMPORTANT: The installer must select the RCD and earthing configuration by following the current local regulations and best practices.

Where the EO Mini Pro 3 includes DC leakage protection a Type A RCD can be fitted at the supply, otherwise, a Type B RCD or equivalent should be used. EO recommends a 40A supply for a 32A charging station. Overcurrent protection (e.g. MCB) should be installed upstream of the charging station.

Wiring connections

Physical connections

Wiring system	Power connections on EO Mini Pro 3		
	PE	N	L1
TN (230V)	PE	N	L1
IT (220V)	PE	L1	L2

PE= Protective Earth

N = Neutral

L1= Line/Phase 1

L2= Line/Phase 2

Status light

The EO Mini Pro 3 has a status LED on the front face to show its status.

When powering up

LED colour	State	Notes
Not illuminated	Power off	No power is available
LED solid white	Initialising	Initialising
LED pulses blue	Ready	The unit has started up successfully and is ready to charge*

*Once the LED pulses blue, it may take up to a further 10 minutes for the charger to connect to the Hive platform, which enables control and smart functionality within the Hive App.

During normal operation

LED colour	State	Notes
LED pulses blue	Ready	Ready to charge
LED pulses green	Cable is inserted	EO Mini Pro 3 is communicating with the vehicle and trying to start a charging session
LED solid green	Charging	A charging session has started successfully
LED pulses blue	Cable is removed	Ready to charge
LED solid yellow	Paused	The EO Mini Pro 3 has paused
LED pulses red	Fault condition	A fault has occurred
LED pulses red and amber	Device tamper notification	This indicates that the internal tamper boundary of the device has been triggered

Hive support centre

Get help at hivehome.com/guides/ev-charging or call **+44 (0)333 202 1054**

This document contains information that is subject to change without notice.

The latest version of this guide can be downloaded at:

hivehome.com/guides/ev-charging

Disclaimer: No part of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, including, but not limited to, copying, recording, retrieving data, or computer networks without the written permission of Centrica Hive.