

2 Burner Electric Cooktop



← **Featured buttons***

Step 1:

- Dampen a cloth with water and use it to wipe the surface of the Cooktops before **every** use. **Do not** use abrasive cleaners (Ajax, Comet, Brillo...)

Step 2:

- Once the surface is clean, press the **ON/OFF** button for **one second**
- Press one of the featured buttons* to select which burner you want to use (top or bottom)

Step 3:

- Once the cooking zone has been selected, you should see # 5 shown on the digital display. That is the default heat value for the cooking zone.
- The value seen in the digital display correlates to the intensity of the heat. Settings range from [0] to [9]. You can increase or decrease the heat intensity by pressing the + or – button
- **DO NOT SET HEAT INTENSITY TO [9] OR [8].** Heat settings at # 7 and below are sufficient and help prevent setting off the fire, alarm

Step 4:

- Place your cook wear on the cooking zone.
- Carefully and responsibly monitor the heated surface to make sure nothing burns or catches on fire.

Step 5:

- Press the “On/Off” button when completed cooking.
- Remember that the surface remains hot after the burner is turned off.

Microwave & Convection Oven Instructions



Microwave:

Step 1:

- Please do not use any metal or plastic cooking containers. Glass is recommended.
- Enter the amount of time needed to cook food. (Enter minutes before seconds).
- Place food in the microwave then shut the door.

Step 2:

- Touch the **Power Level** pad then touch [1] through [10] to select the percentage of power used to cook food. ([1] = 10% power, [3] = 30% power, etc.)
- The default power level is set to [10].

Step 3:

- Press the Start button

Step 4:

- Carefully and responsibly monitor food to make sure nothing burns

Convection Oven:

Step 1:

- Preheat and Cook with Convection
- Touch the **Preheat** pad then touch a number pad to select desired to preheat temperature. (6 = 350 °F)

Step 2:

- Touch the **Convec** pad then touch a number pad to select desired cooking temperature.
- (Yes, there are some cases where the preheat temperature will need to differ from cooking temperature. If this case does not apply to you, enter the same temperature value as the selected preheating setting)

Step 3:

- Touch the number pads to enter the desired cooking time.
 - (**[2] [5] [0] [0] = 25 minutes**)

Step 4: (Do Not Start Until Steps 1-3 are completed)

- Touch **Start/Touch On** pad to begin the preheating process.

Step 5:

- Once preheating is complete, place food on the turn table. Close the convection oven door and monitor the food as it cooks for the predetermined amount of time.

Step 6:

- When cooking is completed, grab oven mittens or the equivalent and open the convection oven doors. Use the oven mittens to remove the food and place it on a surface that will not melt.
- **DO NOT USE BARE HANDS TO REMOVE FOOD CONTENTS FROM OVEN**