

## AVS 75 extension module

00BNO9055-A

FR DE EN ES IT NL

# 1. WARNINGS AND RECOMMENDATIONS

## 1.1. Storage

Extension modules:

- should be stored in a place where the temperature is between -20° C and +65° C and the relative humidity is between 5% and 95%.
- Should be protected from moisture.

## 1.2. Symbols used in this document



**ATTENTION:**

Failure to follow these instructions may cause damage to the facility or other items.



**DANGER :**

Failure to follow these instructions may result in electric shock.

## 1.3. Safety instructions

Always turn off the boiler and close the gas supply before doing any work on the boiler.

## 1.4. Regulatory installation conditions

The installation and maintenance of the unit must be performed by a qualified professional in accordance with the regulations and standard good practices in force, including national and local standards pertaining to low voltage electrical installations.

## 1.5. Environmental compatibility



This device contains electrical and electronic components that should not be thrown in the garbage.  
Local laws in force must be obeyed.

## 2. SUPPLY

Accessory AVS 75 is made up of:

- 1 extension module (with terminal heads)
- 2 fixing screws (M4 x 16) for mounting CONDENSINOX boilers equipped with a NAVISTEM B3000.
- 1 BSB bus communication web
- 1 power bypass cable
- 1 QAD36 surface contact sensor

## 3. INSTALLING THE EXTENSION MODULE



**DANGER:**

**Prior to any work, ensure that the electrical supply is cut off.**

### 3.1. On VARMAX


The extension module is installed on a DIN rail in the boiler.

- Open the door trim on the front of the boiler (see boiler installation and operating instructions)
- Open the left hand side panel of the boiler (see boiler installation and operating manual)
- The DIN rail is located at the top right (behind the NAVISTEM B3000 boiler controller).
- Place the extension module on the rail.

### 3.2. On CONDENSINOX (equipped with a NAVISTEM B3000)

The extension modules are mounted under the NAVISTEM B3000 boiler controller.

- Open the front casing doors of the boiler (see the instructions for installation and use of the boiler);
- Fit the extension module and secure using two M4 x 16 screws (provided).



## 4. ELECTRICAL CONNECTION

### 4.1. Cables

Cable sections below are purely illustrative and do not relieve the installer from checking that they meet requirements and satisfy the national and local standards in force.

If a cable is damaged, it must be replaced by the manufacturer, its after-sales service or a similarly qualified person to avoid any possible danger.

This device is designed to operate at a nominal voltage of 230V, +10% / -15%, 50 Hz

Cable	Copper conductors	Cable raceway
Power supply	provided	High current
BSB communication bus	provided	Low current
Valve	4 G 1,5 mm <sup>2</sup> (2A maxi)	High current
Pump	3 G 1.5 (2A max)	High current
Sensors	2 x 0,5 mm <sup>2</sup>	Low current
"0 ... 10V" input / "On/Off"		


To reduce the risk of pulling on cables, please use the cable clamps located on the boiler.

### 4.2. Electrical connections to terminals

#### 4.2.1. Power supply terminals

**1<sup>st</sup> case: Just one module**


power cable from the boiler



**2<sup>nd</sup> case: Several modules**


power bypass cables supplied with modules

power cable from the boiler




### 4.2.2. Communication bus terminals


1<sup>st</sup> case: Just one module



2<sup>nd</sup> case: Several modules



### 4.2.3. Boiler component terminals



## 5. PARAMETER SETTING

Parameter setting is explained in the documentation supplied with the boiler.

The switches located on the extension module are used to define the address of the module:

