

bella^{PRO}

2-Slice Toaster

Instruction Manual



Scan to register
bellakitchenware.com





TABLE OF CONTENTS

IMPORTANT SAFETY INSTRUCTIONS	2
ADDITIONAL IMPORTANT SAFEGUARDS	3
NOTES ON THE PLUG	4
NOTES ON THE CORD	4
PLASTICIZER WARNING	4
ELECTRIC POWER	4
GETTING TO KNOW YOUR 2-SLICE TOASTER	5
BEFORE USING FOR THE FIRST TIME	5
HOW TO USE THE TOASTER	5
BROWNING CONTROL	6
BAGEL FUNCTION	6
GLUTEN FREE FUNCTION	6
HIGH LIFT FUNCTION	6
CANCEL FUNCTION	6
CLEANING AND MAINTENANCE	6
LIMITED TWO-YEAR WARRANTY	7



IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. **READ ALL INSTRUCTIONS.**
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock do not immerse cord, plugs, or appliance in water or other liquid.
4. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
5. Close supervision is necessary when any appliance is used by or near children.
6. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
7. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest store for examination, repair or adjustment.
8. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
9. Do not use outdoors.
10. Do not let cord hang over edge of table or counter, or touch hot surfaces.
11. Do not place on or near a hot gas or electric burner, or in a heated oven.
12. To disconnect, Press the CANCEL button, then remove plug from wall outlet.
13. Do not use appliance for other than intended use.
14. Oversize foods, metal foil packages, or utensils must not be inserted in a Toaster as they may involve a risk of fire or electric shock.
15. A fire may occur if Toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
16. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
17. Countertop use only
WARNING: ELECTRICAL SHOCK HAZARD. Never attempt to dislodge food inside the Toaster while the Toaster is plugged in. Doing so could cause an electrical shock hazard or a risk of fire.

ADDITIONAL IMPORTANT SAFEGUARDS

CAUTION, HOT SURFACES: This appliance generates heat and escaping steam during use. Proper precautions must be taken to prevent the risk of burns, fires or other injury to persons or damage to property.

1. A person who has not read and understood all operating, toasting, and safety Instructions is not qualified to operate this appliance. All users of this appliance must read and understand this Instruction Manual before operating or cleaning this appliance.
2. If this appliance falls or accidentally becomes immersed in water, unplug it from the wall outlet immediately. Do not reach into the water!
3. When using this appliance, provide adequate air space above and on all sides for air circulation. Do not operate this appliance while it is touching or near curtains, wall coverings, clothing, dishtowels, or other flammable materials.
4. To reduce the risk of fire, do not leave this appliance unattended during use.
5. If this appliance begins to malfunction during use, immediately Press the CANCEL button and unplug the cord. Do not use or attempt to repair a malfunctioning appliance!
6. The cord to this appliance should only be plugged directly into a 120 V AC electrical wall outlet.
7. Do not use this appliance in an unstable position.
8. Use the Toaster on a hard, flat surface. Do not place it near a flame or heat or on a soft surface (such as carpet). Avoid placing it where it may tip over during use. Dropping the Toaster could cause it to malfunction.
9. Do not operate unattended
10. When heating toaster pastries, always use the lightest toast color setting.
WARNING: ELECTRICAL SHOCK HAZARD. Never attempt to dislodge food inside the Toaster while the Toaster is plugged in. Doing so could cause an electrical shock hazard or a risk of fire.
CAUTION: This appliance is hot during operation and retains heat for some time after turning off. Always use oven mitts when handling hot materials and allow metal parts to cool before cleaning. Do not place anything on top of the Toaster while it is operating or while it is hot.

CAUTION:

DO NOT toast pastries with runny fillings or frosting.

DO NOT toast torn slices of bread.

DO NOT place buttered bread or wrapped food into the Toaster.

DO NOT toast small-size breads, mini-baguettes, breadsticks, etc.

FOR HOUSEHOLD USE ONLY SAVE THESE INSTRUCTIONS

NOTES ON THE PLUG

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug will fit in a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.

NOTES ON THE CORD

The provided short power-supply cord (or detachable power-supply cord) should be used to reduce the risk resulting from becoming entangled in or tripping over a longer cord. Always plug directly into a wall outlet/receptacle.

- A. A short power-supply cord (or detached power-supply cord) is provided to reduce the risk resulting from becoming entangled in or tripping over a long cord.
- B. Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.
- C. If a long detachable power-supply cord or extension cord is used:
 - 1. The marked electrical rating of the cord set, or extension cord should be at least as great as the electrical rating of the appliance.
 - 2. The cord should be arranged so that it will not drape over the be at least as great as the electrical rating of the appliance.
 - 3. If the appliance is of the grounded type, the cord set or extension cord should be a grounding-type 3-wire cord.

PLASTICIZER WARNING

CAUTION: To prevent Plasticizers from migrating to the finish of the countertop or tabletop or other furniture, place NON-PLASTIC coasters or place mats

between the appliance and the finish of the countertop or tabletop. Failure to do so may cause the finish to darken; permanent blemishes may occur, or stains can appear.

ELECTRIC POWER

If the electrical circuit is overloaded with other appliances, your appliance may not operate properly. It should be operated on a separate electrical circuit from other appliances.

GETTING TO KNOW YOUR 2-SLICE TOASTER

Product may vary slightly from illustration.

1. Loading lever
2. Bagel button
3. Gluten Free button
4. Cancel button
5. Browning control
6. High lift function
7. Removable crumb tray



BEFORE USING FOR THE FIRST TIME

There may be manufacturing residue or oil remaining in the toaster or heating element, which might emit an odor at the time of the first use. This is normal and will not occur after several uses. It is suggested to operate the 2-Slice Toaster without bread for first use according to the below steps. Then let the toaster cool down before you start toasting the first slice.

HOW TO USE THE TOASTER

1. Ensure the 2-Slice Toaster is connected to the main power supply.
2. Place one to two slices of bread into the toasting slots and press the loading lever down until it latches. The 2-Slice Toaster will heat up automatically and start toasting.
NOTE: the 2-Slice Toaster must be connected to the main power supply in order for the bread carriage to engage and for the toasting cycle to begin.
3. Adjust the browning control to brown the toast to your desired taste.
4. To stop toasting press the CANCEL button at any time.
5. The loading lever will rise automatically when toasting is finished. This 2-Slice Toaster is equipped with a high lift lever to help with the removal of smaller items.
6. If the toast is not dark enough, you can toast the bread again. Adjust the browning control to your desired setting and replace the toast. Ensure the toast does not burn while re-toasting.



BROWNING CONTROL

The browning control enables adjustment of toasting time and has the following settings:

- 1-2 for light toasting
- 3-4 for medium toasting
- 5-6 for dark toasting

BAGEL FUNCTION

The bagel setting works great for English muffins, too!

1. Place one half in each toasting slot with the cut sides facing the center.
2. Set the browning control to desired setting.
3. Press the loading lever down.
4. Press the BAGEL button. The bagel indicator will light up. Ensure bagel doesn't burn.
5. The loading lever will rise automatically when the toasting cycle is complete.

GLUTEN FREE FUNCTION

Use your 2-Slice Toaster to toast your Gluten-free bread, bagels and waffles. Gluten-free breads are often denser in quality and requires a longer toasting time. The gluten free function adjusts and adds the ideal amount of time to your toasting cycle in order to ensure precise and even toasting. Note: The gluten free function does not remove the gluten from your bread.

1. Place one bread, bagel or waffle in each toasting slot.
2. Set the browning control to desired setting.
3. Press the loading lever down.
4. Press the GLUTEN FREE button to toast. The Gluten-free button will light up. Ensure toast/ bagel/ waffle doesn't burn.
5. The loading lever will rise automatically when the toasting cycle is complete.

HIGH LIFT FUNCTION

Allows the loading lever to be raised further for easier access to smaller breads. This ensures smaller pieces of bread and bagels can be removed easily.

CANCEL FUNCTION

The CANCEL button can be pressed at any time during toasting to interrupt the toasting cycle.

CAUTION:

1. Remove all protective wrapping before using the 2-Slice Toaster.
2. If the 2-Slice Toaster starts to smoke, press CANCEL to stop toasting immediately.
3. Do not toast food with runny ingredients.
4. Never attempt to remove bread jammed in the slots without first unplugging the 2-Slice Toaster from the electrical outlet. Be sure not to damage the internal mechanism or heating elements when removing bread.
5. The bread slot is to be used for toasting regular bread slices only. Do not use the 2-Slice Toaster to toast irregularly shaped bread as it may become lodged in the toaster.

CLEANING AND MAINTENANCE

1. Disconnect the 2-Slice Toaster from outlet before cleaning.
2. Wipe the outside with a soft dry cloth after 2-Slice Toaster cools down. Never use metal polish.
3. Pull out crumb tray on bottom of the 2-Slice Toaster and empty it. If toaster is used frequently, accumulated bread crumbs should be removed at least once a week. Make sure the crumb tray is inserted correctly to the toaster and completely closed before using the toaster again.
4. The power cord may be wound under the bottom of the 2-Slice Toaster when not in use or for storage.
5. This appliance requires little maintenance. Do not try to repair it yourself. Any servicing requiring disassembly must be performed by a qualified appliance repair technician.





LIMITED TWO-YEAR WARRANTY

SENSIO Inc. hereby warrants that for a period of **TWO YEARS** from the date of purchase, this product will be free from mechanical defects in material and workmanship, and for 90 days in respect to non-mechanical parts. At its sole discretion, SENSIO Inc. will either repair or replace the product found to be defective, or issue a refund on the product during the warranty period.

The warranty is only valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt, as proof of purchase is required to obtain warranty validation. Retail stores selling this product do not have the right to alter, modify, or in any way revise the terms and conditions of the warranty.

EXCLUSIONS:

The warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use of the product, use of improper voltage or current, improper routine maintenance, use contrary to the operating instructions, disassembly, repair, or alteration by anyone other than qualified SENSIO Inc. personnel. Also, the warranty does not cover Acts of God such as fire, floods, hurricanes, or tornadoes.

SENSIO Inc. shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Apart from the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in time to the duration of the warranty. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, and therefore, the above exclusions or limitations may not apply to you. The warranty covers specific legal rights which may vary by state, province and/or jurisdiction.

HOW TO OBTAIN WARRANTY SERVICE:

You must contact Customer Service at our toll-free number: 1-866-832-4843.

A Customer Service Representative will attempt to resolve warranty issues over the phone. If the Customer Service Representative is unable to resolve the problem, you will be provided with a case number and asked to return the product to SENSIO Inc. Attach a tag to the product that includes: your name, address, daytime contact telephone number, case number, and description of the problem. Also, include a copy of the original sales receipt. Carefully package the tagged product with the sales receipt, and send it (with shipping and insurance prepaid) to SENSIO Inc.'s address. SENSIO Inc. shall bear no responsibility or liability for the returned product while in transit to SENSIO Inc.'s Customer Service Center.







For customer service questions or comments
1-866-832-4843 / help@bellahousewares.com
Made in China



Sensio Inc.
dba Made by Gather™
New York, NY 10016/USA

90224_90231 R. 1