

button-fix™ router multijig instructions





The Multijig is designed to help rebate the Button-fix Type 1, Type 1 Bonded, and Type 1 Flush Fixes. It should be used with a metric 12mm cutter and an 18mm guide bush.

Plate selection

The Multijig is supplied with a choice of two steel plates that attach magnetically. One creates an oval rebate to suit the Type 1 and Type 1 Bonded Fixes, the other the Type 1 Flush. The square plates can be orientated vertically or horizontally in the acrylic frame.

Rebate on a panel face

When rebating the Fix into the panel face, align the Multijig in the desired position. To assist, the frame is engraved with centreline guides for the oval rebate. Secure the frame to the workpiece either with clamps or with the two countersunk screws supplied.



Rebate on a panel edge

The Type 1 Flush Fix can be rebated into the edge of a panel of at least 28mm thick. To use the Multijig for this application, first loosely screw a planed timber batten to the underside of the Multijig with the two pan head wood screws supplied, fixing through the slotted holes in the frame.

Next, securely clamp the batten to the workpiece and adjust the frame until the centreline guides align. Tip: you can also use the aperture in the frame as a guide. The centre of the oval rebate will be 32mm offset from the edge of this aperture.

Once aligned, lock the Multijig to the batten with the two countersunk screws supplied.

Always ensure that the Multijig assembly is stable and secure before routing the panel.

