

SMART HOME MONITORING



# LG Wireless LED Bulb

Manufacturer's Installation Guide

# LED Light Bulb Features

- › Simple installation
- › Works with OpenHome™ and ZigBee HA 1.2 compatible Home Controllers

## ZigBee Certified Feature

- › This ZigBee® Certified product works with other ZigBee Home Automation™ Version 1.2.0(or prior versions) products.
- › This device works with ZigBee Gateway.
- › Global 2.4 GHz wireless use.
- › ZigBee® Certified is a registered trademark of the ZigBee Alliance.

## OpenHome™ Certified

- › This product is certified to work with OpenHome™ home control platforms.
- › See [OpenHome.io](http://OpenHome.io) for more information along with other materials to help assist you in using this product.

# LED Light Bulb Set-Up

## Installation and Use

- › Disconnect power before installing a LED Bulb.
- › Install LED Bulb into the light fixture. LED Bulb can be installed to lighting fixture with E26 Base Socket.
- › If you want to connect your LED Bulb with a home controller, please refer to the controller's user guide for instructions on how to pair this product.

### WARNING

Violation of warning may lead to injury or death.

- › Make sure to turn off the power before installing or servicing the product.
- › Do not operate the product with wet hands.
- › Do not install the product near a fire hazard.
- › Do not plug too many devices into the same outlet.
- › An electrician shall be required in accordance with electricity standards or requirements in the jurisdiction of installation.

### CAUTION

Violation of precautions may lead to injury or product damage.

- › Do not disassemble or modify the product.
- › Use the product at the rated voltage.
- › Do not install in a place at risk of flooding.
- › Do not use the product for purposes other than for which it was designed.
- › If using within an enclosed fixture, ensure there is enough ventilation for temperature regulation.
- › Do not look directly at the lamp while lighting.
- › Do not use with dimmer switches.

## Rejoining

To rejoin the Home Controller, turn light off and on five times. Bulb will blink twice to indicate success.

## EZ-Mode Commissioning

To start EZ-Mode Commissioning, turn light off and on seven times. Bulb will blink for 3 minutes during commissioning.

## Factory Reset

To factory default the LED Bulb, turn light off and on ten times. LED Bulb will blink five times to indicate success. LED Bulb will unpair with the Home Controller. Device will then go back into pairing mode.