## Urban Outfitters

Minimum Make Manual Section 7:

**Knitwear** 

## Urban Outfitters

Construction Method	<u>Photo</u>
Fashioned Panels Stitch tension must be controlled.	
Linked seams On all garments unless overlocking is agreed in advance. Seam allowance: Maximum of 3 wales on fine gauge and 2 wales on heavy gauge.	
Overlocked Neck Seam Strapping must be used to conceal (where this construction is agreed in place of linking).	BDG SP WARR OF SP
Shoulder Tape Must be DTM knitted tape or use framilon.  DO NOT use woven tape.  Fitted Styles: Shoulder seams to be linked, or fashioned, where possible.	
Tension  Nylon to be added to first 1cm of set up course at hems, cuffs and ribs (unless already contains elastane).  100% cotton yarns to be fully plated.	

## Urban Outfitters

Construction Method	<u>Photo</u>
Stripes and Designs To match at side seams and armholes (including raglans). Linking thread must be changed to match stripe colour.	
Float lengths  To be no greater than 2cm per float.	
End and Knots  Must be carried to the side seam.  There must be no knots on the front of the garment.	
Hanger Loops To be in DTM satin ribbon (3mm wide ) Single ribbon for wide necks and cardigans ONLY	
Fur URBN do not use real fur or angora rabbit hair.	