

MasterSet[®] DELVO Admixture Stabilizer

Application: Same day stabilization of concrete with MasterSet DELVO admixture. It is important to follow each step correctly.

1

Identify the mix proportions from the batch ticket, which will give (1) the total amount of cementitious material per volume of concrete, and (2) time elapsed since batching. Determine the quantity of returned plastic concrete. Add the required amount of water to adjust slump of concrete to 5 to 7 in (125-175 mm). Mix for 1 minute.

2

Back concrete to rear of drum and determine temperature of returned plastic concrete (leave thermometer in concrete for at least 30 seconds or until temperature stabilizes).

3

Determine correct MasterSet DELVO admixture dosage and dispense into concrete. Mix for 5 minutes.

4

Batch freshly manufactured concrete on top of stabilized concrete within 30 minutes from addition of MasterSet DELVO. The minimum amount of fresh concrete to be batched on top is based on a ratio of 1:1. Mix for at least 5 minutes.

Master Builders Solutions Admixtures US, LLC

23700 Chagrin Boulevard
Beachwood, OH 44122 USA
(800) 628-9990

master-builders-solutions.com/en-us
admixtures@masterbuilders.com

Master Builders Solutions Canada, Inc

1800 Clark Boulevard
Brampton, Ontario L6T 4M7 CANADA
(289) 360-1300