

Tratar el concreto devuelto con MasterSuna® RCT 323 es tan fácil como contar hasta 3



Paso 1: Determine el volumen de concreto y agregue una bolsa de **MasterSuna RCT 323** por yarda³ o 0.75 m³



Paso 2: Mezcle (aprox. 2 min) y descargue en pequeñas pilas (aprox. 12 pulgadas o 300 mm de alto)
(Deje de mezclar cuando escuche que el material se solidifica)



Paso 3: El mismo día: aplane las pilas tratadas. Al día siguiente: gire las pilas para desintegrar el material tratado.

Master Builders Solutions Admixtures US, LLC
23700 Chagrin Boulevard
Beachwood, OH 44122 USA
(800) 628-9990

Master Builders Solutions Canada, Inc
1800 Clark Boulevard
Brampton, Ontario L6T 4M7 CANADA
(289) 360-1300

master-builders-solutions.com/en-us
admixture@masterbuilders.com

® marca comercial registrada de un Master Builders
Solutions en muchos países del mundo
Lit# AD 3000303 rev 10/23



**Su equipo de
Master Builders Solutions
está aquí para ayudarlo.**



Treating returned concrete with MasterSuna[®] RCT 323 is as easy as 1-2-3



Step 1: Determine concrete volume and add one bag of **MasterSuna RCT 323** per yd^3 or 0.75 m^3



Step 2: Mix (~ 2 min) and Discharge in small piles (~ 12 in or 300 mm high)
(Stop mixing when you hear material solidify)



Step 3: Same day: flatten the treated piles. Next day: turn the piles to break up treated material.

Master Builders Solutions Admixtures US, LLC
23700 Chagrin Boulevard
Beachwood, OH 44122 USA
(800) 628-9990

Master Builders Solutions Canada, Inc
1800 Clark Boulevard
Brampton, Ontario L6T 4M7 CANADA
(289) 360-1300

master-builders-solutions.com/en-us
admixture@masterbuilders.com

® registered trademark of Master Builders Solutions in many countries of the world
Lit# AD 3000303 rev 10/23



**Your Master Builders
Solutions team is here to help!**

