

TECHNICAL GUIDANCE - REPAIR MIX FOR KEYSTONE TW3

- 1.** CLEAN THE VOID TO BE FILLED FREE FROM LOOSE DUST.
- 2.** BRUSH THE AREA WITH A SOLUTION OF WATER AND A PVA ADHESIVE (UNIBOND) 1 PART UNIBOND 10 PARTS WATER.
- 3.** THOROUGHLY MIX THE MATERIALS SUPPLIED DRY AND THEN ADD WATER AND UNIBOND (1 PART UNI BOND 10 PARTS WATER) TO GET THE MIX TO A FIRM BUT NOT WET CONSISTENCY.(SQUEEZE IN THE HANDS AND IT STAYS IN A BALL).
- 4.** HAND RAM THE CONCRETE INTO THE VOID.
- 5.** TROWEL THE CONCRETE INTO THE CORRECT SHAPE AND FINISH WITH A STIFF BRUSH TO GIVE IT TEXTURE.