Dulux[®]



BATHROOM TILES EASY HOW-TO PROJECT GUIDE



BATHROOM TILES

Dulux[®] Renovation Range Tiles & Benchtops is a revolutionary, water based interior coating perfect for transforming your bathroom tiles.



EXPERT TIP

For the best quality finish, do not skip steps 1 and 2 and wash extra dirty or mouldy tiles twice.

Preparation

Dulux Renovation Range Tiles & Benchtops, requires a clean surface to adhere. All grease and dirt contamination MUST be removed, or the paint will not adhere and will peel or flake off.

Previously Painted Surfaces:

On ALL surfaces cleaning is the most important step.

- Scrub down all areas with Selleys® Sugar Soap and rinse with clean water to remove any dirt, oil or grease. Use a plastic scouring pad on heavily contaminated surfaces.
- Repeat this process using clean water, at least twice.

IMPORTANT: Do not use abrasive cleaning detergents.

- Completely remove any loose and flaking paint. Fill any cracks or holes with a suitable hard epoxy based filler such as Selleys[®] Knead-IT[®] Aqua.
- Sand glossy and semi gloss finishes to a dull flat finish using p400 paper before coating.
- Use a clean damp cloth to remove any dust.

Tiles and Glass – Wall and Splashback:

- For grout lines ensure to remove all grease and oil.
- Thoroughly clean surface using Selleys[®] Rapid Mould Killer[™]. Remove all silicone sealant from joints using Selleys[®] Silicone Remover.

- Wash down well with water.
- Sand with p400 paper all areas where silicone has been removed.
- Wash with Selleys[®] Sugar Soap and use a scrubbing brush or a toothbrush to properly clean grout lines.
- Rinse with clean water and dry with a clean cloth.
- Allow grout lines to dry for a minimum 2 hours before painting. Mask using a good quality painters tape.

Mixing:

Add all of the Additive found underneath the blue lid to the paint.

Stir well for approximately 2-5 minutes with a broad flat paddle, using an up and down scooping action until the additive is completely mixed into the paint.

Once mixed the product is suitable to use for up to 10 days.



Sand surface



Add the additive and stir well

Application

Topcoat

After the additive has been added and stirred, apply at least two coats of *Dulux* Renovation Range Tiles & Benchtops ensuring that the previous coat is left for a minimum of 8 hours before recoating.

- **1.** Cut in as necessary using a 38–50mm high quality angled sash cutter brush.
- 2. Coat surface using a 4mm nap 100mm wide microfibre roller.
- Lay off. Once each section is coated, gently go over the surface in the same direction with an unloaded roller using minimal pressure. This will give a smooth consistent finish.

Clear Coat

On bathroom tiles apply *Dulux* Renovation Range Clear Coat as the final coating. This will add a layer of protection to the *Dulux* Renovation Range topcoat.



Scrub tiles before applying topcoat



Roll on topcoat

THE PERFECT RENOVATION SYSTEM

This revolutionary range works as a three step system. For the best possible result, ensure you always follow all three steps.⁺



NEED HELP & ADVICE?

CALL: Aust 13 25 25 NZ 0800 800 424 ONLINE & LIVE CHAT:



For 'How To' videos, helpful tips and more, scan here!

FRONT COVER: Tiles: Dulux Renovation Range Tiles & Benchtops in Dulux Lexicon®

Disclaimers: Colours shown are as close as possible to actual paint colours. Please note, due to limitations of the printing process, photographic and printed images may not represent the true colour. Always confirm your choice with a *Dulux* Sample Pot.

*For full use instructions please see the *Dulux* website and review the Data Sheet, Application and FAO information. *The *Dulux* Renovation Range Floor product does not require a clear coat as it will reduce the non-slip performance.

Registered trade mark information: Dulux, Worth doing, worth Dulux, Lexicon, Selleys and Knead-IT are registered trademarks and Rapid Mould Killer is a trade mark of DuluxGroup (Australia) Pty Ltd.