

Dulux®

Worth doing, worth Dulux.

THE END TO TIMBER EXPOSURE



HOW-TO-GUIDE

1



SURFACE PREPARATION

Ensure the surface is clean and dry, free from dust, dirt, mould and grease.

2



BEFORE SPRAYING

Shake the can thoroughly for at **least 3 minutes** before spraying and then regularly during use. Avoid spraying when air or surface temperature is below 10°C or above 30°C. Low temperatures and high humidity will slow the drying time.

3



SPRAY APPLICATION

Hold can upright 10 to 25cm from the surface and spray 2–3 smooth even strokes to achieve optimum coverage of the timber end.

4



AFTER SPRAYING

Prevent blocking in the can nozzle by turning the can upside down and spraying until clear gas emerges. Wipe the front nozzle clean with a cloth. Clean up any overspray while still wet with mineral turpentine.