

X4 COMMANDER

RVX4-BIRD-SPIKE

INSTALLATION SHEET

The Redvision Commander Bird Spike provides an anti-perch surface for the camera when mounted in an upright position.

Contents

- 1 x RVX4 Bird Spike
- 1 x M3 Allen Key
- 1 x M4 x 16 socket cap head fixing
- 1 x M4 Nytlite washer

Instructions:

1. Insert the U-bend of the bird spike into the vacant slot on the bezel
2. Fold Bird Spike around the top of the camera and fix the right-angle bend of the bird spike into the central M4 fixing, secure using an M3 Allen key
3. Bend the Bird Spikes to desired position – alternate one vertical and one 40 degrees bend per pair of spikes.

