

X3 STORM

RVX3-VISOR Installation Guide

Preparation

Camera must be properly supported before Visor fitting. Visor should be attached at low level prior to installation.

Attaching the Visor

Align the 3 fixing holes on the visor with the threaded holes on the Ball Top. Assemble the visor to the Camera using the fixings/spacers provided.

Top fixing: Assembly stack comprises, from the outside M4 x 8 Socket Button Cap Head Screw, Nytlite, Visor; fastened with M2.5 Allen key. Fix this first as per Figure B

Side two fixings: Assembly stack comprises, from the outside M4 x 10 Socket Cap Screw, Nytlite, Visor, Nylon Spacer; fastened with M3 Allen key – as per Figure A.

The hole on top of the visor is reserved for the bird spike, which is to be fitted using the M3 x 8 Pozi Pan head screw and 2 off Wavy Washers.

Contents

- 316 Stainless Steel Visor
- 2 off M4 x 10 Socket Cap Screws
- 3 off M4 Nytlites
- 3 off M4 Spacers
- 1 off M2.5 Allen Key
- 1 off M4 x 8 Socket Button Cap Screw
- 1 off Bird Spike
- 1 off M3 x 8 Pozi Pan Head
- 2 off M3 Wavy Washers
- 1 off M3 Allen Key

