

YOJI FLOOR LAMP

URBAN OUTFITTERS

Assembly Instructions

Use a 60W (MAX) G type incandescent bulb or 13W CFL type bulb.
(Do not use bulb that exceeds recommended wattage)

Do not throw away packing materials and carton until after assembly.
Assemble all parts on a clean smooth surface



PARTS INCLUDED



(A) Wood Base 1x



(B) Lamp Body 1x



(C) Wrench 1x



(D) Glass Shade 2x

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully and easily inserted. Do not alter the plug.

CLEANING:

Use only soft cloth to dust and clean fixture, never use chemicals or abrasive cleaners as it may damage finish.

NOTE: Turn the power off (unplug from the wall outlet) before replacing the bulb. Make sure the bulb has sufficient time to cool down. Do not subject to the lamp to any shock while lit as shattering of lamp may result.

YOJI FLOOR LAMP

URBAN OUTFITTERS

Assembly Instructions

1. Use the wrench (D) screw the wood base (A) onto the lamp base (B).
2. Place bulb (not included) into socket.
3. Put the glass shade (I) on the lamp body (B).
4. Plug into outlet, turn on switch, and enjoy your new lamp.

