

TULIP SINGLE HOOK

URBAN OUTFITTERS

Assembly Instructions

TOOLS REQUIRED BUT NOT INCLUDED:


Drill, Phillips head screwdriver driver, Hammer, Pencil, Level

WARNINGS:


Do not throw away packing materials and carton until after assembly.
Ensure all parts are present prior to assembly.
Contact customer service immediately if parts are missing.
Assemble all parts on a clean smooth surface.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.
Do not place over heat or air conditioning vents.
Adjust levelers so that the furniture sits flat on uneven floors.
Blot spills with a clean white cloth, do not rub.
Do not use harsh chemicals.
Before cleaning any part test a small spot in a hidden area.
You may need to re-tighten all bolts after initial use.



PARTS INCLUDED:



(A) Hook x 1

[2.60" x 1.00" x 3.54"]
or
[67 x 27 x 90 mm]



(B) Plastic Anchor x 2

[D0.35" x 1.38"] x2
or
[D9 x 35 mm] x2



(C) Screw x 2

[D0.30" x 1.38"] x2
or
[D8 x 35 mm] x2

TULIP SINGLE HOOK


URBAN OUTFITTERS

Assembly Instructions

STEP 1

Wood or Stud installation:

Insert the screws (C) through the hook (A) into the wall and fasten them with a Phillips head screwdriver or drill.



Drywall installation:

Mark the location of the screw holes in the hook (A) on the wall. Insert anchors (B) into the wall at the marked locations using a drill and a hammer. Insert screws (C) through the hook (A) into the anchors, then tighten with a Phillips head screwdriver.

