

BANANA SCONCE

URBAN OUTFITTERS

Assembly Instructions

TOOLS REQUIRED BUT NOT INCLUDED:

Drill, Phillips head screwdriver, Hammer, Pencil, Level

WARNINGS:

Do not throw away packing materials and carton until after assembly. Ensure all parts are present prior to assembly.

Contact customer service immediately if parts are missing.

Assemble all parts on a clean smooth surface.

Use a MAX 4W LED Type T4/G9 bulb.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.

Do not place over heat or air conditioning vents.

Adjust levelers so that the furniture sits flat on uneven floors.

Blot spills with a clean white cloth, do not rub.

Do not use harsh chemicals.

Before cleaning any part test a small spot in a hidden area.

You may need to re-tighten all bolts after initial use.



PARTS INCLUDED:



(A) Anchors X 2



(B) Screws
[M4x25mm] X 2



(C) Screws
[5/32-32T*7mm] X 4



(D) Mounting plate



(E) Lamp Shade

BANANA SCONCE

Assembly Instructions

URBAN OUTFITTERS

STEP 1

As you unpack and prepare for assembly, place the contents on a carpeted or padded flat surface area.

STEP 2

Remove the Screws (C) from the Mounting Plate (D). Insert the specified light bulb into the socket. **DO NOT EXCEED THE SPECIFIED WATTAGE.**

STEP 3

Attach the lamp shade (E) to the mounting plate (D) with the screws (C) using a Phillips head screwdriver.

STEP 4

Place the assembled sconce on the wall in a desired location. Ensure the Sconce is level and mark the location for the screw holes on the wall.

Wood or Stud installation:

Use a Phillips head screwdriver to fasten the screws (B) directly into the wall at the marked locations. Leave 1/2" between the top of the screws (B) and the wall.

Drywall installation:

Insert anchors (A) into the wall at the marked locations using a drill and a hammer. Insert screws (B) into the anchors, then tighten with a Phillips head screwdriver. Leave 1/2" between the top of the screws (B) and the wall. Decrease the gap between top of the screws (B) and the wall as necessary to ensure the sconce is flush with the wall.

The included hardware is intended for attachment to drywall or wooden wall surfaces, contact your local hardware store to find the correct anchor for alternative wall-types such as stone or brick.

STEP 5

Plug into outlet, turn on switch, and enjoy your new lamp.

Use a MAX 4W LED Type T4/G9 bulb. Do not use bulb that exceeds recommended wattage.

