

ADURA®Rigid by Mannington Under Cabinet Guidelines

INSTALLING CABINETS

- Install cabinets and then ADURA®Rigid around the cabinets, leaving the 1/4" (6.35 mm) to 1/2" (12.7 mm) expansion zone.
- If installing cabinets after the ADURA®Rigid has been installed, most or all the cabinet weight should be supported by the wall mountings.

To secure the cabinets to the substrate with screws or nails, drill holes through the ADURA®Rigid 1/2" (12.7 mm) diameter larger than the screw or nail to allow for expansion. Do not draw down screw or fasten too tight.

INSTALLING KITCHEN ISLANDS

- The island must be freestanding and weigh less than 250 pounds gross weight if it is to be installed on top of the installed ADURA®Rigid flooring.
- If the island weighs more than 250 pounds, the ADURA®Rigid must be installed around the island, allowing the normal 1/4" (6.25 mm) to 1/2" (12.7 mm) expansion area around the base of the island.
- If the ADURA®Rigid has already been installed, and the island must be installed over the ADURA®Rigid, and the island weighs more than the 250-pound maximum, secure the island to the substrate with screws or nails, drill holes through the ADURA®Rigid 1/2" (12.7 mm) diameter larger than the screw or nail to allow for expansion. Do not draw down screw or fasten too tightly.

FLOOR PREPARATION

- When installing under cabinets it is essential that floor be flat and smooth and free from deflection
- ADURA®Rigid Flooring must not be allowed to be pinched or secured in anyway
- Expansion requirement of a min ¼" must be followed around all permanent structure

U.S. Patent 6,291,078; U.S. Patent 6,218,001; U.S. Patent 7,384,697 and other patents pending.

**Be sure to register your new floor at
Mannington.com/Register for a chance to win
\$100 and for proper warranty coverage.**