

ThermaCork

100% Natural Cork Insulation

Thermacork MD Façade Shiplap System Basic Install Guidelines

1. Unwrap from factory packaging 24 hours prior to installing. Store in a dry location.



2. Start from a corner. Lap orientation is not relevant. Minimum 4 screws per board.

3. Use appropriate screws for backing surface. Screw size depends on material thickness, so total load will vary. Check with fixing company load capacity and recommendations.

For metal: Self drilling galvanized screws.
For wood or panels: Wood screws.



4. For bigger boards extra screws may be used for extra safety.

Note: Screws may be used outside the shiplap joint as MD Façade Cork will cover the screws.



5. Press boards firmly together



6. Thermacork color change is normal during installation and will fade out throughout time. (Sometimes lighter and sometimes darker.)

Questions? Contact Us!

ecosupply

ecosupplycenter.com
1-800-883-7005