

Fuse table

Time Direct

Depending on which length and variant of luminaire you would like to use, see below table in order to find which fuse table you should use.

Fuse tables will be found on page 2.

Luminaire length	Type	Fuse table to use
1140	(All variants)	1
1420	(All variants)	1
1700	HE 830, 840, 930, 940	1
1700	HO 830, 840	1
1700	HO 930, 940	2
2260	HE 830, 840, 930, 940	1
2260	HO 830, 840, 930, 940	2
2820	HE 830, 840	1
2820	HE 930, 940	2
2820	HO 830, 840, 930, 940	2

HE = High Efficiency
HO = High Output

Fuse table 1

Time Direct

Maximum loading of automatic of circuit breakers

	Automatic circuit breaker type:	C10	C13	C16	C20	C25	B10	B13	B16	B20	B25	Inrush current
Driver:	Xitanium 36W 0.3-1A 54V TD 230V											I_{max} time
	Number of drivers/fuse: There are 1 driver / DALI address in each luminaire	37	49	61	75	94	23	29	36	45	56	26 A 140 μ^*

* Input voltage 230V, Time measured at 50% Ipeak

Fuse table 2

Time Direct

Maximum loading of automatic of circuit breakers

	Automatic circuit breaker type:	C10	C13	C16	C20	C25	B10	B13	B16	B20	B25	Inrush current
Driver:	Xitanium 75W 0.7-2A 54V TD 230V											I_{max} time
	Number of drivers/fuse: There are 1 driver / DALI address in each luminaire	25	32	41	50	62	15	19	24	30	37	24,9 A 215 μ^*

* Input voltage 230V, Time measured at 50% Ipeak