

INSTRUCTIONS FOR INSTALLATION OF DUMMY LEVER/KNOB

TOOLS NEEDED FOR NEW INSTALLATION

- Pencil
- Phillips Screwdriver
- Tape Measure

The following requirements should be observed to keep the finish of your lever/knob lasting longer:

1. Do not install the lever/knob before doors are painted.
2. To avoid oxidation, refrain from using cleansers or acid chemicals to polish your lever/knob.
3. Refrain from using heavy or sharp-edged objects to scrub lever/knob.

CUT ALONG DOTTED LINE TO REMOVE TEMPLATE

REPLACEMENT INSTALLATION

1. Remove dummy lever/knob from packaging.
2. Place lever/knob on door over old location. Insert screws and tighten.

NEW INSTALLATION

1. Use template. Draw center line for dummy lever/knob across edge of door approximately 36" (914 mm) above floor.
2. Align edge of template with edge of door after measuring for backset required see template. Match center line with center line drawn on door edge.
3. Mark by piercing 2 holes on door for locating screws.
4. Attach dummy to door by lining up holes in the lever/knob with those pierced in the door. Insert screws and tighten.

INSTRUCTIONS POUR LA POSE DE FAUSSES GARNITURE

OUTILS NÉCESSAIRES POUR UNE NOUVELLE INSTALLATION

- Crayon
- Tournevis Phillips
- Mètre

Observer les consignes suivantes afin de préserver l'aspect de vos leviers/poignées:

1. Ne pas monter les leviers/poignées avant que les portes ne soient peintes.
2. Afin d'éviter l'oxydation, éviter l'emploi de produits de nettoyage ou de produits chimiques acides pour astiquer les leviers/poignées.
3. Éviter l'emploi d'objets lourds ou à arêtes vives pour astiquer les leviers/poignées.

COUPER LE LONG DU POINTILLÉ POUR RETIRER LE GABARIT

MONTAGE D'UNE POIGNÉE DE REMPLACEMENT

1. Sortir la fausse garniture de son emballage.
2. Placer la levier/poigné sur la porte par dessus l'ancien emplacement. Insérer les vis et les serrer.

NOUVEAU MONTAGE

1. Utiliser le gabarit. Marquer l'axe de la fausse levier/poignée sur le bord de la porte à environ 36" (914 mm) au dessus du plancher.
2. Aligner le bord du gabarit avec celui de la porte, après avoir mesuré la distance de retrait voulu voir gabarit. Faire coïncider l'axe du gabarit avec celui tracé sur le bord de la porte.
3. Marquer la porte en y perçant 2 trous pour l'emplacement des vis.
4. Fixer la fausse levier/poignée sur la porte en alignant les trous de la poignée avec ceux percés dans la porte. Insérer les vis et les serrer.

