
The stressing records are part of the structural design and serve as a basis for the stressing operation. Besides the prestressing data, they contain sequence of stressing and directions for procedures directly connected with stressing operation, such as lowering of the formwork and releasing of bearings.

## Calculation of bar tendon elongation at stressing

The total elongation  $\Delta I_{tot}$  [mm] which the bar has to achieve during stressing should be calculated as:


$$\Delta I_{\text{tot}} = \Delta I_{\text{p}} + \Delta I_{\text{c}} + \Delta I_{\text{sl}}$$


 $\Delta I_p$  = elongation of the bar tendon [mm]



or in many cases it is accurate enough

$$\Delta I_p = \frac{P_{0,l} + P_{0,0}}{2 \cdot A_p \cdot E_p} \cdot I_p$$





$$P_{x,0} = P_0 \cdot e^{-\mu \cdot \widehat{\gamma} X}$$

 $P_{x,0}^{\gamma,0}$  = prestressing force immediately after stressing at any point distance x along the member [kN]  $P_{0,0}$  = stressing force at the stressing end [kN]

 $P_{0,l}$  = prestressing force at the dead end

 $\widehat{\gamma}_x = \sum_{n = 1}^{\infty} a_n g \log n$  deflection between the stressing end and at any point distance x [rad]  $\widehat{\gamma} = \frac{\pi}{180} \left[ \sqrt{a_H^2 + a_V^2} + \beta \cdot \right]$ 

= coefficient of friction (see p.36)

= wobble angle (see p.36)

= prestressing force at the stressing end after unintentional slip [kN]

 $\Delta I_c$  = elastic deformation of the concrete (shortening must be treated as a positive value) [mm]

$$\Delta I_{C} = \frac{\sigma_{cm}}{E_{C}} \cdot I_{C}$$

= average stress in the concrete cross section at the centre of gravity of all tendons due to prestressing force [MN/m²]

= length of the concrete member [m]

 $\Delta I_{sl}$  = sum of slip in the thread of the anchorages and coupler according anchorage type applied [mm]

 $\Delta I_{SI}$  [mm] = For allowable stresses of 0.55  $f_{pk}$  the technical details are given in the Certificate of Approval for DYWIDAG Post-tensioning Systems, for higher stresses the values increase in proportion.