

D & D CLASSIC AUTO
 2300 MOTE DR
 COVINGTON OH 45318
 937-473-2229

WO#: 21896

1937 STUDEBAKER
 513-702-7877

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|--|----------------------|-------------|---------------------|-------------------|-------------|
| | SHOP MATERIAL | \$590.70 | | HAZ WASTE REMOVAL | \$10.00 |
| PARTS TOTAL | | \$590.70 | SUBLET TOTAL | | \$10.00 |
| 268.50 | \$55.00 | \$14,767.50 | LABOR TOTAL | | \$14,767.50 |
| LABOR TOTAL | | | LABOR TOTAL | | \$14,767.50 |
| 268.50 | HR AT \$55.00 PER HR | \$14,767.50 | PARTS TOTAL | | \$590.70 |
| | | | SUBLET TOTAL | | \$10.00 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 11-10-12 | SUBTOTAL | | \$15,368.20 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$16,367.13 | TAX | | \$998.93 |
| | | | BALANCE DUE: | | \$16,367.13 |

WE ACCEPT M/CARD, VISA & DISCOVER

*Paid
 11/28/12
 ch # 2103*

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: _____

WO: 21896

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 1

| DATE | DESCRIPTION | BY | TIME WORKED | |
|----------|---|----------|-------------|-----|
| | | | HRS | MIN |
| 10-5-12 | Get door handles working. Remove glass from doors and remove headliner. | Steve | 10 | 00 |
| 10-27-12 | Disassemble grille shell, bag, tag and photograph. | Rodney | 4 | 00 |
| 10-27-12 | Disassemble hood and right front fender. | Steve | 4 | 00 |
| 10-29-12 | Remove trim from hood sides and put on customer's shelves. Disassembling truck. Remove rear fenders, bed, tailgate, bumper and gas tank. | Rodney | 11 | 00 |
| 10-29-12 | Disassemble left front fender from doaner car. Remove front fenders, hood, hood sides, front bumper and running boards. | Steve | 11 | 00 |
| 10-30-12 | Disassembly of truck. Remove wiring harness, hoses and dash cluster. | Steve | 9 | 00 |
| 10-30-12 | Disassembling bed. Remove sides and front bed mount. | Rodney | 10 | 00 |
| 10-31-12 | Remove right rear bed mount. Make new left rear bed mount. Remove doors. Order steel for sides and tubing. | Rodney | 10 | 00 |
| 10-31-12 | Clean and sand bed floor and braces, hang, prepare and spray. | Scott | 4 | 00 |
| 10-31-12 | Remove heater box, dash braces, all dash panels/levers and both doors. | Steve | 10 | 00 |
| 10-31-12 | Take sheet metal to be blasted. | Garv | 1 | 50 |
| 10-31-12 | Sand bed floor and braces for epoxy. Start sandblasting bed side. | Brian F. | 6 | 00 |
| 10-31-12 | Sandblast bed side. | Dale | 2 | 00 |
| 11-1-12 | Fit floor and mounts to frame. Prepare parts for welding. Weld front and back supports to bed floor. Weld bed mounts to floor. Make supports for inner bed sides, prime and fit to frame. | Rodney | 11 | 00 |
| 11-1-12 | Remove rear window frame, hood hinges from firewall, floor boards and trim from bottom floor on right side. Load and put parts in storage. | Steve | 10 | 00 |
| 11-1-12 | Sandblast bedside and sand. Hang two bedsides, prepare and epoxy. | Brian F. | 4 | 00 |
| 11-2-12 | Prepare floor for cross members. Weld cross members. Make mounting brackets for tailgate. Cut out top of left bedside. Start metal finishing top roll. | Rodney | 9 | 00 |
| 11-2-12 | Sandblast misc. parts. | Dale | 2 | 00 |
| 11-2-12 | Shape new panels for fronts of front fenders. Unload loaner car and check for usable parts. | Steve | 10 | 00 |
| 11-3-12 | Sand bed filler panels, cowl vent and braces - hang, clean, prepare and epoxy prime. | Scott | 1 | 50 |
| 11-3-12 | Metal finishing left bedside. | Rodney | 5 | 00 |

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: _____

WO: 21896

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 2

| DATE | DESCRIPTION | BY | TIME WORKED | |
|---------|--|----------|-------------|-----|
| | | | HRS | MIN |
| 11-3-12 | Remove running boards from car. Peel rubber, begin sandblasting and cleaning up. | Steve | 5 | 00 |
| 11-5-12 | Heat and scrape undercoating on running boards and floorboards then sandblast. | Steve | 11 | 00 |
| 11-5-12 | Metal finishing on left bedside. Cut blanks for bedside tops. Fabricate new left inner bedside. | Rodney | 11 | 00 |
| 11-6-12 | Fabricate right inner bedside. Go to Piqua and pick up brake bedside tops and tubing for front. Make new front for bed (original too small). | Rodney | 10 | 00 |
| 11-6-12 | Finish sandblasting floor boards and transmission cover. Tap holes in transmission cover. Begin disassembly of loaner car parts. | Steve | 10 | 00 |
| 11-6-12 | Pick up fenders and front end at Aesthetic Finishers. | Gary | 1 | 00 |
| 11-6-12 | Sand all four fenders, grill shell then prepare and epoxy all. | Brian F. | 4 | 00 |
| 11-7-12 | Cut tubing and weld to front bed piece. Cut stake pockets and brackets off old bed. Clean and spot weld brackets on left inner bedside. Remove loaner car body from chassis. | Rodney | 10 | 00 |
| 11-7-12 | Remove front doors, front floorboards, carpet, front seat, bottom of back seat, trunk upholstery, body bolts, and body from frame (loaner car). | Steve | 10 | 00 |
| 11-7-12 | Sand two running boards and four small pieces for epoxy then hang. Remove body from loaner chassis and take to storage. | Brian F. | 3 | 00 |
| 11-7-12 | Prepare buck for body. Assist with removing body from chassis. | Dale | 2 | 00 |
| 11-8-12 | Sandblast bed front panel, rear panel and brackets. Hang bed panels, front/sides/rear - clean, prepare and spray with epoxy primer. | Scott | 2 | 00 |
| 11-8-12 | Begin removing sludge from frame and cleaning to remove all chassis parts so frame is ready for heat cleaning. | Steve | 10 | 00 |
| 11-8-12 | Finish putting inner bed sides together. Weld cracks and holes in left bed side. Grind welds and continue metal finishing and start on right bed side. | Rodney | 10 | 00 |
| 11-8-12 | Sand inner two bed sides, grind spot welds, hang and prepare for epoxy. | Brian F. | 1 | 00 |
| 11-9-12 | Loosely assemble bed for customer to see. Clean, continue straightening and metal finishing right bedside. | Rodney | 8 | 00 |

**D & D CLASSIC AUTO
2300 MOTE DR
COVINGTON OH 45318
937-473-2229**

WO#: 21948

**1937 STUDEBAKER P/U
613-702-7877**

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|--------|----------------------|----------|-----|--|----------|
| | SHOP MATERIAL | \$534.60 | | HAZ WASTE REMOVAL | \$10.00 |
| 12 | NOR23589-40 SPAPER | \$28.92 | | AESTHETIC FINISHERS | |
| 20' | NOR49562-180 SPAPER | \$19.00 | | **STRIP 4 FENDERS & 1 GRILL SHELL** | \$325.00 |
| 6' | NOR49558-320 SPAPER | \$5.70 | | | |
| 26 | COR62959/180 SPAPER | \$19.24 | | | |
| 1/8 PT | 965-60 ACTIVATOR | \$6.45 | | | |
| 1 QT | 801-703 EPOXY PRIMER | \$75.70 | | | |
| 1/2 L | USC26125 METAL PUTTY | \$22.72 | | | |

PARTS TOTAL

\$712.33

SUBLET TOTAL

\$335.00

243.00

\$55.00

\$13,365.00

LABOR TOTAL

LABOR TOTAL

\$13,365.00

243.00

HR AT \$55.00 PER HR

\$13,365.00

PARTS TOTAL

\$712.33

SUBLET TOTAL

\$335.00

** THIS BILLING BRINGS YOU UP TO DATE AS OF:

11-24-12

SUBTOTAL

\$14,412.33

TAX

\$936.80

** BALANCE DUE UPON RECEIPT IS:

\$15,349.13

BALANCE DUE:

\$15,349.13

WE ACCEPT M/CARD, VISA & DISCOVER

*Paid
11/29/12
ch # 2103*

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: _____

WO: 21948

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 1

| DATE | DESCRIPTION | BY | TIME WORKED | |
|----------|---|--------|-------------|-----|
| | | | HRS | MIN |
| 11-12-12 | Strip paint from hood sides inside/out. | Scott | 4 | 00 |
| 11-12-12 | Remove suspension from doaner chassis and prepare for stripping. | | | |
| | Metal finish top rail of right bed side. Start repairing edges. | Rodney | 11 | 00 |
| 11-12-12 | Remove all parts from chassis for stripping. Prepare for truck cab removal from chassis. | Steve | 11 | 00 |
| 11-12-12 | Prepare, catalog and photograph parts for plating. | DJ | 2 | 00 |
| 11-12-12 | Disassemble louver surround that fits between hood and hood sides. | Dale | 2 | 50 |
| 11-13-12 | Finish stripping hood sides and hood. Sandblast edges of hood sides and hood. Sand tailgate and floor boards. | Scott | 6 | 00 |
| 11-13-12 | Remove cab from chassis and load. Make and weld new edges on right bed side. Kleco inner and outer bed sides together and fit to bed. | Rodney | 11 | 00 |
| 11-13-12 | Remove cab from old frame. Load cab and frame to go to Aesthetic Finishers. Finish tagging and boxing up parts. Cut spare tire well from old fender. Grind welds on floor panels. | Steve | 11 | 00 |
| 11-13-12 | Blast parts for paint. Prepare, catalog and photograph parts for plating. | DJ | 8 | 00 |
| 11-13-12 | Load frame and cab, take to Aesthetic Finishers and unload. | Gary | 1 | 00 |
| 11-13-12 | Take radiator and fuel tank to Shroyer Radiator. | Tom | 1 | 00 |
| 11-13-12 | Work on hood louvers. | Dale | 3 | 00 |
| 11-14-12 | Sandblast hood louvers. Tape off stainless trim. Hang hood, tail gate, louvers and hood brace - clean, prepare and spray with epoxy primer. | Scott | 9 | 50 |
| 11-14-12 | Fit top patch to left bed side, tack in place, weld and start grinding welds. | Rodney | 10 | 00 |
| 11-14-12 | Sandblast spare tire well, hammer, dolly dents and metal finish. | Steve | 8 | 00 |
| 11-14-12 | Take frame to Aesthetic Finishers. | Gary | 1 | 00 |
| 11-15-12 | Finish grinding welds. Hammer and trim left inside bed side and Kleco to outside. Fit to bed and trim right beside top. | Rodney | 10 | 00 |
| 11-15-12 | Sand and polish stainless trim on hood louvers. | Scott | 8 | 00 |
| 11-16-12 | Hang floor boards, clean, prepare and spray with reface. sand epoxy primer on hood louvers. | Scott | 7 | 50 |
| 11-16-12 | Fit top patch to right bed side, tack in place, weld and grin welds. | Rodney | 9 | 00 |
| 11-16-12 | Hammer and dolly spare tire well, weld cracks and grind welds. | Steve | 7 | 00 |
| 11-17-12 | Metal finish top patch. | Rodney | 5 | 00 |
| 11-18-12 | Metal finish top patch, trim and fit right inside bedside. Fit | | | |

D & D CLASSIC AUTO
2300 MOTE DR
COVINGTON OH 45318
937-473-2229

WO#: 21972

1937 STUDEBAKER P/U
513-702-7877

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|------|-------------------------|----------|-----|--|------------|
| | SHOP MATERIAL | \$650.10 | | HAZ WASTE REMOVAL | \$10.00 |
| 1 | 8698K75 1/4" RUBBER | \$39.64 | | AESTHETIC FINISHERS | |
| 36 | NOR23588-80 SPAPER | \$70.20 | | **STRIP/POWDERCOAT CAB, FRAME & MISC. PARTS** | \$1,365.00 |
| 16 | NOR49566-80 SPAPER | \$15.20 | | SHROYER RADIATOR | |
| 12 | NOR49562-180 SPAPER | \$11.40 | | **REPAIR RADIATOR** | \$45.50 |
| 1 PT | 541-5 RUBBER SEAL | \$8.57 | | **LINE GAS TANK** | \$91.00 |
| 1 PT | 360-4 METAL CLEANER | \$12.87 | | TURNER MACHINE CO | |
| 1/4 | FILLER POLY METALLIC | \$15.60 | | **FIT KING PINS & BUSHING TO FRONT END PIECES** | \$273.00 |
| 1 L | 965-60 ACTIVATOR | \$103.16 | | | |
| 5L | 801-703 EPOXY PRIMER | \$376.00 | | | |
| | USC25310 SP LITE FILLER | | | | |
| 1/2 | USC26125 METAL PUTTY | \$22.72 | | | |
| 1 | 21A3111 KING PIN SET | \$58.50 | | | |
| | MISC HARDWARE | \$23.85 | | | |

PARTS TOTAL

\$1,407.81

SUBLET TOTAL

\$1,784.50

295.50

\$55.00

\$16,252.50

LABOR TOTAL

LABOR TOTAL

\$16,252.50

295.50

HR AT \$55.00 PER HR

\$16,252.50

PARTS TOTAL

\$1,407.81

SUBLET TOTAL

\$1,784.50

** THIS BILLING BRINGS YOU UP TO DATE AS OF:

12-9-12

SUBTOTAL

\$19,444.81

TAX

\$1,263.91

** BALANCE DUE UPON RECEIPT IS:

\$20,708.72

BALANCE DUE:

\$20,708.72

WE ACCEPT M/CARD, VISA & DISCOVER

Paid 12/12/12
Ch# 2122

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: _____

WO: 21972

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 1

| DATE | DESCRIPTION | BY | TIME WORKED | |
|----------|--|--------|-------------|-----|
| | | | HRS | MIN |
| 11-26-12 | Drill holes in new tail gate brackets. Mill slots for chain hook. | Rodney | 5 | 00 |
| 11-26-12 | Sand epoxy primer on left hood side, fill and sand. | Scott | 7 | 50 |
| 11-26-12 | Repair headlight buckets, weld holes, grind and sandblast. Repair transmission cover and weld corners. Sandblast left door. | Steve | 9 | 00 |
| 11-26-12 | Blast parts for paint. Disassemble parts from doaner car for plating, take photographs and catalog. | DJ | 8 | 00 |
| 11-27-12 | Disassemble front suspension. Kleco bed together to fit to doaner chassis. | Rodney | 11 | 00 |
| 11-27-12 | Finish filling and sanding on left hood side. Sand epoxy primer on right hood side. Fill, sand, hang and spray hood sides with reface. Sand passenger door and headlamp brackets, hang, clean and spray with epoxy primer. | Scott | 10 | 00 |
| 11-27-12 | Begin repairs on right door, weld bottom hinge mount, hammer and dolly. Use dent puller to remove dents from door handle area. Pick up chassis at Aesthetic Finishers. | Steve | 9 | 00 |
| 11-27-12 | Pick up frame at powder coaters. | Garv | 1 | 00 |
| 11-27-12 | Disassemble parts from doaner car. Prepare and epoxy prime bumper hardware, sand and polish. | DJ | 7 | 50 |
| 11-28-12 | Disassemble front suspension components (control arms, tie rods, stabilizers and right brake hub). | Rodney | 11 | 00 |
| 11-28-12 | Block sand right hood sides, hang, clean, prepare and spray with urethane primer. Sandblast hood brace, grille brace, fender braces, radiator valance and bottom - hang, clean, prepare and spray with epoxy primer. | Scott | 10 | 50 |
| 11-28-12 | Blast interior parts, prime and sand. Disassemble parts off doaner car. Prepare, photograph and catalog parts for plating. | DJ | 10 | 00 |
| 11-29-12 | Disassemble left front brake and spindle then clean. | Rodney | 3 | 00 |
| 11-29-12 | Assist with disassembling motor housing in preparation for paint. | Bobby | | 50 |
| 11-29-12 | Prepare, catalog and photograph parts for plating. Disassemble heater. Repair heater housing. Prepare and paint heater parts. Clean hardware. Sand and fill bumper brackets. | DJ | 10 | 00 |
| 11-29-12 | Sand epoxy on inside of hood. Block sand outside of hood, fill and sand low spots. | Scott | 7 | 00 |
| 11-29-12 | Repair wiper transmission. | Mike | 4 | 00 |
| 11-30-12 | Blast and paint heater parts. Finish disassembling doaner car. | DJ | 5 | 50 |
| 11-30-12 | Pick up cab at Aesthetic Finishers. | Garv | 1 | 00 |

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: _____

WO: 21972

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 2

| DATE | DESCRIPTION | BY | TIME WORKED | |
|----------|--|--------|-------------|-----|
| | | | HRS | MIN |
| 11-30-12 | Fill, sand, clean, prepare and spray hood with reface. Start sanding cab. | Scott | 8 | 00 |
| 12-1-12 | Sand cab, clean, prepare and spray with epoxy primer. | Scott | 4 | 00 |
| 12-3-12 | Sandblast front end chassis parts. Sand parts, hanq, clean and epoxy. Powerwash rear end, springs and front spring. | Scott | 8 | 50 |
| 12-3-12 | Weld cracks around bottom hinge of left door. | Steve | 2 | 00 |
| 12-3-12 | Prepare, photograph and catalog parts for plating. Prepare and paint heater parts. Polish parts. | DJ | 9 | 00 |
| 12-3-12 | Pick up fuel tank and radiator at Shroyers. | Tom | 1 | 00 |
| 12-4-12 | Install new lead wires onto blower motor. | Bobby | 1 | 50 |
| 12-4-12 | Clean grease from tie rod ends for paint. Clean and sandblast front brake drums. Strip gas tank, fill dents and dings. Hanq, clean, prepare brake drums and gas tank then spray with epoxy primer. | Scott | 9 | 00 |
| 12-4-12 | Finish repairs on left door. Remove hinges from both doaner car doors. | Steve | 11 | 00 |
| 12-4-12 | Prepare, photograph and catalog parts for plating. Prepare and paint interior parts. Clean up hardware for heater. | DJ | 8 | 00 |
| 12-5-12 | Remove ring pins and blast front axle. Tear down rear axle and prepare for blasting. | Gary | 8 | 00 |
| 12-5-12 | Assemble fan motor. | Bobby | | 50 |
| 12-5-12 | Strip radiator. Hanq, clean, prepare and spray radiator and backing plates with epoxy primer. | Scott | 3 | 50 |
| 12-5-12 | Remove broken bolts from hinges for both doors. Drill and tap new holes. Install hinges in left door. Begin repairs on right door. | Steve | 9 | 00 |
| 12-5-12 | Assembly hardware on heater box. Prepare, photograph and catalog parts for plating. | DJ | 8 | 00 |
| 12-6-12 | Clean rear end up for prime and brake parts. | Garv | 8 | 00 |
| 12-6-12 | Sand epoxy primer on front end chassis parts, fill and sand pits and tool marks - hanq, clean, prepare and spray all with urethane primer. | Scott | 8 | 50 |
| 12-6-12 | Prepare, photograph and catalog parts for plating. Disassemble trim off of doaner car. Prepare and paint hardware for heater. | DJ | 8 | 00 |
| 12-6-12 | Weld nuts on tail gate mounts and fit to bed frame. Bolt tailgate. Mount rear fenders to bed. | Rodnev | 10 | 00 |
| 12-6-12 | Make two covers to cap axle tubes to sandblast rear end. Blast | | | |

**D & D CLASSIC AUTO
2300 MOTE DR
COVINGTON OH 45318
937-473-2229**

WO#: 21999

**1937 STUDEBAKER P/U
513-702-7877**

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|--------|--------------------------|----------|-----|--------------------------------|---------|
| | SHOP MATERIAL | \$634.70 | | HAZ WASTE REMOVAL | \$10.00 |
| 6' | NOR49566-80 SPAPER | \$6.00 | | DAYTON CLUTCH & JT | |
| 12' | NOR49562-180 SPAPER | \$11.40 | | **REATTACH BRK SHOE | |
| 10' | NOR49561-220 SPAPER | \$9.50 | | LININGS** | \$15.60 |
| 20' | NOR49558-320 SPAPER | \$19.00 | | SMITTYS LOCKSMTIH | |
| 1L | 965-60 ACTIVATOR | \$101.16 | | **REPAIR & KEY WITH | |
| 50 GAL | SC804 RM UNO BLACK PAINT | \$290.40 | | NEW KEYS** | \$40.25 |
| 50 GAL | 801-703 EPOXY PRIMER | \$151.40 | | | |
| 1 QT | DH46 HARDNER | \$122.94 | | | |
| 1/2 | USC26125 METAL PUTTY | \$22.72 | | | |
| | KEYS | \$13.00 | | | |

PARTS TOTAL

\$1,382.22

SUBLET TOTAL

\$65.85

288.50

\$55.00

\$15,867.50

LABOR TOTAL

LABOR TOTAL

\$15,867.50

288.50

HR AT \$55.00 PER HR

\$15,867.50

PARTS TOTAL

\$1,382.22

SUBLET TOTAL

\$65.85

** THIS BILLING BRINGS YOU UP TO DATE AS OF:

12-21-12

SUBTOTAL

\$17,315.57

TAX

\$1,125.51

** BALANCE DUE UPON RECEIPT IS:

\$18,441.08

BALANCE DUE:

\$18,441.08

WE ACCEPT M/CARD, VISA & DISCOVER

PAID 12/28/12
CL# 2136
\$ 28,800.04

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: _____

WO: 21999 _____

VEHICLE: 1937 STUDEBAKER P/U _____

C. NUM: 727 _____

SERIAL: _____

PAGE: 1 _____

| DATE | DESCRIPTION | BY | TIME WORKED | |
|----------|--|--------|-------------|-----|
| | | | HRS | MIN |
| 12-10-12 | Mark out door hinge mount from doaner car, cut out and sandblast. | | | |
| | Remove inner bracing. | Steve | 9 | 00 |
| 12-10-12 | Prepare, photograph and catalog parts for plating. Sand and polish | | | |
| | glove box lock cylinders. | DJ | 2 | 00 |
| 12-10-12 | Sand epoxy primer on rear end and fill pits. Clean, prepare and | | | |
| | spray with urethane primer. | Scott | 7 | 00 |
| 12-10-12 | Assemble front spindles. Remove front wheel cylinders to be rebuilt. | Gary | 3 | 00 |
| 12-10-12 | Hammer welds on left rear fender. Drill new mount holes and mount to | | | |
| | bed. Mark holes in right rear fender, make patch, tack, weld patch | | | |
| | and grind welds. | Rodney | 11 | 00 |
| 12-11-12 | Hammer welds on right rear fender, weld cracks, grind welds, metal | | | |
| | finish, drill new holes and fit to bedside. Disassemble bed. | | | |
| | Remove gaiters from rear leaf springs. | Rodney | 11 | 00 |
| 12-11-12 | Sand urethane primer on chassis and steering parts for paint. Sand | | | |
| | epoxy primer on gas tank, hang, clean, prepare and spray with | | | |
| | urethane primer. Start sandblasting rear leaf springs. | Scott | 10 | 00 |
| 12-11-12 | Finish removing inner brace from hinge mount and make repairs - | | | |
| | mark out on truck body. Remove bad area, clean and paint rusty | | | |
| | area. Fit new hinge panel. Remove rear leaf spring gaiters. | Steve | 11 | 00 |
| 12-12-12 | Prepare and weld back piece to bed floor. Prepare and weld | | | |
| | right inner bedside to bed. | Rodney | 11 | 00 |
| 12-12-12 | Fit panel. Fabricate new bolt plate, mark out drill and counter- | | | |
| | sink new holes. Metal finish and fit up on repair panel. | Steve | 9 | 00 |
| 12-12-12 | Sand gas tank for paint. Finish sandblasting leaf springs. Sanding | | | |
| | chassis parts for paint. | Scott | 8 | 00 |
| 12-12-12 | Machining new suspension bushings. | Brad | 2 | 00 |
| 12-13-12 | Fit, prepare and weld left inner bedside to bed. Fit outer | | | |
| | bedsides, tail gate and rear roller. Adjust and mark bedsides | | | |
| | for weld preparation. | Rod | 10 | 00 |
| 12-13-12 | Sand chassis parts. Sand rear end for paint. | Scott | 9 | 50 |
| 12-13-12 | Clean primer from weld area, trim and fit panel. Begin tacking | | | |
| | weld in place. | Steve | 8 | 00 |
| 12-14-12 | Fit pieces between front of bed and cab. Drill holes. Start | | | |
| | sanding off primer and paint from areas to be welded and clean. | Rod | 5 | 00 |
| 12-14-12 | Sand chassis parts for paint. | Scott | 4 | 00 |
| 12-14-12 | Weld bottom left door jamb on cab to hinge plate. Grind welds and | | | |

D & D CLASSIC AUTO

DAILY LABOR LOG

NAME: _____

WO: 21999

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 2

| DATE | DESCRIPTION | BY | TIME WORKED | |
|----------|---|--------|-------------|-----|
| | | | HRS | MIN |
| | metal finish. | Steve | 6 | 00 |
| 12-15-12 | Finish preparing left outer bedside and weld side to bed. | Rodnev | 5 | 50 |
| 12-15-12 | Hang springs, clean, prepare and spray with epoxy primer. Hang, | | | |
| | clean, prepare and epoxy chassis/steering parts with black paint. | Scott | 5 | 00 |
| 12-15-12 | Finish welding panel in door jamb, grind and metal finish. | Steve | 5 | 00 |
| 12-17-12 | Finish sanding brake drums and rear end. Hang, clean, prepare and | | | |
| | spray brake drums, rear end and remaining parts with black paint. | Scott | 9 | 00 |
| 12-17-12 | Finish preparing right bedside and weld. Prepare roll pan and weld. | | | |
| | Grind welds on bed. | Rodnev | 11 | 00 |
| 12-17-12 | Clean metal on left door jamb hinge mount. Cut out old metal. | | | |
| | Fabricate new mount plate, drill and countersink holes. Fit up | | | |
| | and weld in place. | Steve | 11 | 00 |
| 12-17-12 | Remove springs from truck frame and install springs on front | | | |
| | car frame. | Gary | 3 | 00 |
| 12-18-12 | Clean up welds under bed. Weld stud on gas tank strap. Start | | | |
| | hammering and pulling dents out of cab. | Rodnev | 11 | 00 |
| 12-18-12 | Finish hinge mount on left side. Begin repairs on cab body behind | | | |
| | left door on belt line. | Steve | 11 | 00 |
| 12-18-12 | Assemble front end and prepare to install rear end. | Gary | 7 | 00 |
| 12-18-12 | Sandblast rear leaf springs and hardware - hang, clean, prepare and | | | |
| | spray with black paint. Start block sanding reface on hood. Sanding | | | |
| | engine panel and filling pits. | Scott | 8 | 50 |
| 12-19-12 | Metal finishing cab. Mount gas tank. Set bed on chassis. Mount | | | |
| | rear fenders. Fabricate new right rear fender brace. | Rodnev | 11 | 00 |
| 12-19-12 | Block sand hood. Fill and sand low spots. Sand shocks - hang, | | | |
| | prepare and spray with black paint. Set bed on chassis. | Scott | 6 | 50 |
| 12-19-12 | Install rear spring and rear end. Clean shocks for paint. | Gary | 5 | 00 |
| 12-20-12 | Weld and grind rear of left door jamb. Fabricate repair panel | | | |
| | and fit up. | Steve | 10 | 00 |
| 12-20-12 | Prepare and paint chassis hardware. | DJ | | 50 |
| 12-20-12 | Finish block sanding hood. Sand upper radiator panel. Sand head | | | |
| | lamp buckets, fill, sand pits and low spots. Hang, clean, prepare | | | |
| | and spray buckets, radiator panel and hood with urethane primer. | Scott | 9 | 00 |
| 12-20-12 | Make left rear fender brace and install. Metal finishing cab. | Rod | 6 | 00 |
| 12-21-12 | Weld repair panel in place, grind and metal finish welds. | Steve | 10 | 00 |
| 12-21-12 | Sand instrument panel and glove box door - fill dents and pits. | | | |

**D & D CLASSIC AUTO
2300 MOTE DR
COVINGTON OH 45318
937-473-2229**

WO#: 22014

**1937 STUDEBAKER P/U
513-702-7877**

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|--------|-------------------------|----------|-----|---|----------|
| | SHOP MATERIAL | \$224.40 | | HAZ WASTE REMOVAL | \$10.00 |
| 4 | NOR23588-40 SPAPER | \$9.64 | | WHITE POST RESTORATIONS | |
| 36' | NOR49566-80 SPAPER | \$34.20 | | **SLEEVE & REBUILD WHEEL CYLINDERS** | \$962.00 |
| 2 | NOR38671-2*36 SP LOCKS | \$6.12 | | | |
| 6 | NOR23609-40/40 SPAPER | \$9.54 | | | |
| 3/4 | FILLER POLY METALLIC | \$46.80 | | | |
| 3/4 QT | USC15310 SP LITE FILLER | \$9.75 | | | |
| 1/2 | USC26125 METAL PUTTY | \$22.72 | | | |

Paid 2/11/13

PARTS TOTAL \$363.17

SUBLET TOTAL \$972.00

102.00 \$55.00 \$5,610.00

LABOR TOTAL

LABOR TOTAL \$5,610.00

102.00 HR AT \$55.00 PER HR \$5,610.00

PARTS TOTAL \$363.17

SUBLET TOTAL \$972.00

** THIS BILLING BRINGS YOU UP TO DATE AS OF: 1-4-13

SUBTOTAL \$6,945.17

TAX \$451.44

**** BALANCE DUE UPON RECEIPT IS: \$7,396.61**

BALANCE DUE: **\$7,396.61**

WE ACCEPT M/CARD, VISA & DISCOVER

**D & D CLASSIC AUTO
2300 MOTE DR
COVINGTON OH 45318
937-473-2229**

WO#: 22031

**1937 STUDEBAKER P/U
513-702-7877**

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|------|-------------------------|----------|-----|--------------------|---------|
| | SHOP MATERIAL | \$634.70 | | HAZ. WASTE REMOVAL | \$10.00 |
| 3' | NOR23588-40 SPAPER | \$7.23 | | | |
| 16' | NOR49566-80 SPAPER | \$15.20 | | | |
| 3 | NOR49558-320 SPAPER | \$2.85 | | | |
| 3 | NOR23609-40/40 SPAPER | \$4.77 | | | |
| 14 | COR31552/1000 SPAEPR | \$10.36 | | | |
| 13 | COR31550/1500 SPAEPR | \$9.62 | | | |
| 15 | COR62932/6" -600 SPAPER | \$11.10 | | | |
| 16 | COR62954-320 SPAPER | \$11.84 | | | |
| 1/2 | FILLER POLY METALLIC | \$31.20 | | | |
| 1 | UP073 REFACE | \$42.38 | | | |
| 1 QT | USC15310 SP LITE FILLER | \$6.50 | | | |
| 1/4 | USC26125 METAL PUTTY | \$11.36 | | | |

*PAID
2/11/13*

PARTS TOTAL \$799.11

SUBLET TOTAL \$10.00

288.50 \$55.00 \$15,867.50

LABOR TOTAL

LABOR TOTAL \$15,867.50

288.50 HR AT \$55.00 PER HR \$15,867.50

PARTS TOTAL \$799.11

SUBLET TOTAL \$10.00

** THIS BILLING BRINGS YOU UP TO DATE AS OF: 1-19-13

SUBTOTAL \$16,676.61

TAX \$1,083.98

** BALANCE DUE UPON RECEIPT IS: \$17,760.59

BALANCE DUE: \$17,760.59

WE ACCEPT M/CARD, VISA & DISCOVER

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: _____

WO: 22031 _____

VEHICLE: 1937 STUDEBAKER P/U _____

C. NUM: 727 _____

SERIAL: _____

PAGE: 1 _____

| DATE | DESCRIPTION | BY | TIME WORKED | |
|----------|---|--------|-------------|-----|
| | | | HRS | MIN |
| 1-7-13 | Continue polishing and straightening grill. | Jim | 3 | 00 |
| 1-7-13 | Prepare and paint crossmember and rear brake hardware. Install crossmember and rear brakes. Start cleaning emergency brake cables and brackets. | Rodney | 11 | 00 |
| 1-7-13 | Weld and grind on door mount. Cut old door skin from bottom hinge and weld in new skin. | Steve | 9 | 00 |
| 1-7-13 | Fill and sand bed and steering column. | Scott | 8 | 50 |
| 1-8-13 | Straightening and polishing stainless grill trim. | Jim | 6 | 00 |
| 1-8-13 | Finish assembling hubs and emergency brakes on rear drums. Set chassis on wheels. Start assembling steering and steering arms. | Rodney | 11 | 00 |
| 1-8-13 | Hang, prime and paint steering column. Fill and sand on bed sides and front end of bed. | Scott | 10 | 00 |
| 1-8-13 | Repairing left door. | Steve | 9 | 00 |
| 1-8-13 | Fill and sand bumper hardware. | DJ | 3 | 00 |
| 1-9-13 | Metal finishing and polishing stainless grill trim. | Jim | 7 | 00 |
| 1-9-13 | Finish assembling steering arms. Blast, clean and paint emergency brake cables. Install front fenders, grille shell and hood sides. Mount running board. | Rodney | 11 | 00 |
| 1-9-13 | Repairing left door, weld, grind, hammer and dolly. | Steve | 4 | 00 |
| 1-9-13 | Sand and prime bumper brackets. | DJ | 2 | 50 |
| 1-9-13 | Fill and sand tailgate jamb. Weld left side inner wheel well panel to outside wheel well. Grind welds, fill and sand. | Scott | 10 | 50 |
| 1-10-13 | Metal finishing, straightening and polishing grill trim. | Jim | 8 | 00 |
| 1-10-13 | Sandblast front emergency brake cable/handle, mount, clutch pushrod and pedals. Clean and paint cable, mount and pushrod. Clear clutch rod. Blast, clean and paint master cylinder mount. | Rodney | 11 | 00 |
| 1-10-13 | Finish filling and sanding left side wheel house edge. Weld right side wheel house inner to outer, grind welds, fill and sand. | Scott | 10 | 50 |
| 1-10-13 | Weld clutch linkage and grind. | Steve | 5 | 00 |
| 1-11-13 | Block straightening and polishing grill trim. | Jim | 8 | 00 |
| 1-11-13 | Install core support. Sandblast dash bars and throttle linkage. Install front emergency brake cable and metal finish. | Rodney | 6 | 00 |
| 1-11-13 | Finish filling and sanding right side wheel well. Fill pits. | Scott | 8 | 00 |
| 11-12-13 | Sand edges of bed, tape up and spray with reface. | Scott | 5 | 50 |
| 11-12-13 | Replace spring on throttle linkage. Adjust left door. Remove fuel line fittings and clamps. Start grinding cracks in steering wheel. | Rod | 5 | 50 |

D & D CLASSIC AUTO
 2300 MOTE DR
 COVINGTON OH 45318
 937-473-2229

WO#: 22047

1937 STUDEBAKER P/U
 513-702-7877

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|---|--------------------------------|-------------------|---------------------|------------------------|-------------------|
| | SHOP MATERIAL | \$246.40 | | HAZ WASTE REMOVAL | \$10.00 |
| | CNC425 BRAKE LINE | \$54.11 | | APPLE HYDRAULICS | |
| 4 | NOR23589-40 SPAPER | \$9.64 | | **REBUILD MASTER CYL** | \$312.50 |
| 40' | NOR49566-80 SPAPER | \$38.00 | | | |
| 16' | NOR49562-180 SPAPER | \$15.20 | | | |
| 4' | NOR49558-320 SPAPER | \$3.80 | | | |
| 4' | NOR23609-40/40 SPAPER | \$6.36 | | | |
| 2 | NOR03075 SOFT TOUCH 400-320/20 | \$6.04 | | | |
| 1/4 | FILLER POLY METALLIC | \$15.60 | | | |
| 1/8 PT | 965-60 ACTIVATOR | \$6.45 | | | |
| 1 QT | SC804 RM UNO BLACK PAINT | \$145.80 | | | |
| 1 PT | 801-703 EPOXY PRIMER | \$37.85 | | | |
| 1/2 PT | 929-53 HARDNER PRIMER | \$31.56 | | | |
| 3 QTS | 285-13 URETHANE PRIMER | \$278.88 | | | |
| 3/4 | USC15310 SP LITE FLLER | \$19.50 | | | |
| 1/2 | USC21625 METAL PUTTY | \$22.72 | | | |
| PARTS TOTAL | | \$937.91 | SUBLET TOTAL | | \$322.50 |
| 154.00 | \$40.00 | \$6,160.00 | LABOR TOTAL | | \$6,160.00 |
| LABOR TOTAL | | | PARTS TOTAL | | \$937.91 |
| 154.00 | HR AT \$40.00 PER HR | \$6,160.00 | SUBLET TOTAL | | \$322.50 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 2-3-13 | SUBTOTAL | | \$7,420.41 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$7,902.74 | TAX | | \$482.33 |
| | | | BALANCE DUE: | | \$7,902.74 |

*Paid 3/18/13
 CF 2225
 \$22,576.71*

WE ACCEPT M/CARD, VISA & DISCOVER

D & D CLASSIC AUTO

DAILY LABOR LOG

NAME: _____

WO: 22047 _____

VEHICLE: 1937 STUDEBAKER P/U _____

C. NUM: 727 _____

SERIAL: _____

PAGE: 1 _____

| DATE | DESCRIPTION | BY | TIME WORKED | |
|---------|---|--------|-------------|-----|
| | | | HRS | MIN |
| 1-21-13 | Repairing steering wheel. | Rodney | 11 | 00 |
| 1-21-13 | Block sand left side of bed. | Scott | 5 | 00 |
| 1-21-13 | Begin repairs on right door and hinge post. | Steve | 11 | 00 |
| 1-22-13 | Repairing and fitting up right door. | Steve | 11 | 00 |
| 1-22-13 | Block sand left side and rear of bed. | Scott | 2 | 00 |
| 1-22-13 | Repairing steering wheel. | Rodney | 11 | 00 |
| 1-23-13 | Finish steering wheel. Install hood. Paint fuel line clips and sending unit. | Rodney | 11 | 00 |
| 1-23-13 | Block sand front of bed, top bed rails, inside edges and tailgate jamb. | Scott | 10 | 00 |
| 1-24-13 | Assemble master cylinder. Make loom for cowl. Paint loom cover and pedal spring. Install hood latch. Blast front end support rods. | Rodney | 8 | 00 |
| 1-24-13 | Finish block sanding outside of hood. Start filling and sanding on inside of bed. Sand brake and clutch pedals then paint black. | Scott | 11 | 00 |
| 1-24-13 | Fitting up and repairing right door. | Steve | 7 | 00 |
| 1-24-13 | Prepare and prime steering wheel. | Tim | 2 | 00 |
| 1-25-13 | Install master cylinder, pedal assembly and floor pans. Assist with doors. | Rodney | 6 | 00 |
| 1-25-13 | Fill and sand on inside of hood. | Scott | 7 | 50 |
| 1-25-13 | Sand primed steering wheel and spray 2 nd coat of primer. | Andrew | 2 | 00 |
| 1-26-13 | Make new rubber seals for headlight mounts. | Rodney | 2 | 00 |
| 1-26-13 | Fill and sand on inside of bed. Grind radiator support rods and prime. Sand emergency brake handle, fender brace, brake line brackets and clutch linkage. Hang, clean, prepare and paint black handle, brace, brackets and linkage. | Scott | 6 | 00 |
| 1-28-13 | Sand primed steering wheel and prepare for paint. | Andrew | 2 | 00 |
| 1-28-13 | Fill and sand on inside bedside. | Scott | 2 | 00 |
| 1-31-13 | Fill and sand inside of bedside. | Scott | 2 | 00 |
| 2-1-13 | Assemble grill and hood trim. | Jim | 5 | 00 |
| 2-1-13 | Clean body and chassis. | Pete | 3 | 00 |
| 2-1-13 | Block sand left rear fender. | Scott | 8 | 00 |
| 2-2-13 | Block sand right rear fender. Sand inside both rear fenders. Finish filling and sanding on inside bedside. Hang fenders. Clean, prepare and spray bed and fenders with urethane primer. | Scott | 8 | 00 |
| 2-3-13 | Install rear fenders. | Scott | | 50 |
| TOTAL | | | 154 | 00 |

D & D CLASSIC AUTO
2300 MOTE DR
COVINGTON OH 45318
937-473-2229

WO#: 22067

1937 STUDEBAKER P/U
513-702-7877

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|---|----------------------|-------------------|------------------------|--------------------|-------------------|
| | SHOP MATERIAL | \$227.20 | | HAZ. WASTE REMOVAL | \$10.00 |
| 12' | NOR49566-80 SPAPER | \$11.40 | | | |
| 10' | NOR49564-120 SPAPER | \$9.50 | | | |
| 16' | NOR49562-180 SPAPER | \$9.50 | | | |
| 5' | NOR49558-320 SPAPER | \$4.75 | | | |
| 10' | NOR49557-400 SPAPER | \$9.50 | | | |
| 10 | COR31552/1000 SPAPER | \$7.40 | | | |
| 15 | COR31550/1500 SPAPER | \$11.10 | | | |
| 5 | COR62959-180 SPAPER | \$3.70 | | | |
| 10 | COR62953/400 SPAPER | \$7.40 | | | |
| 10 | COR62952/600 SPAPER | \$7.40 | | | |
| PARTS TOTAL | | \$308.85 | SUBLET TOTAL | | \$10.00 |
| 142.00 | \$40.00 | \$5,680.00 | LABOR TOTAL | | \$5,680.00 |
| LABOR TOTAL | | | PARTS TOTAL | | \$308.85 |
| 142.00 | HR AT \$40.00 PER HR | \$5,680.00 | SUBLET TOTAL | | \$10.00 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 2-17-13 | SUBTOTAL | | \$5,998.85 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$6,388.78 | TAX | | \$389.93 |
| | | | BALANCE DUE: | | \$6,388.78 |
| | | | CREDIT CK 2175: | | -\$842.80 |
| | | | AMOUNT DUE: | | \$5,545.98 |

WE ACCEPT M/CARD, VISA & DISCOVER

D & D CLASSIC AUTO
 2300 MOTE DR
 COVINGTON OH 45318
 937-473-2229

SAM PETERS
 10001 ALLIANCE RD
 CINCINNATI OH 45242

WO#: 22093

1937 STUDEBAKER P/U
 513-702-7877

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|--|---------------------------------|----------------------|--------------|--------------------|------------|
| 1 | SHOP MATERIAL 8963K47 COPPER | \$158.40 \$118.06 | | HAZ. WASTE REMOVAL | \$10.00 |
| PARTS TOTAL | | \$276.46 | SUBLET TOTAL | | \$10.00 |
| 99.00 | \$40.00 | \$3,960.00 | LABOR TOTAL | | \$3,960.00 |
| LABOR TOTAL | | | PARTS TOTAL | | \$276.46 |
| 99.00 | HR AT \$40.00 PER HR | \$3,960.00 | SUBLET TOTAL | | \$10.00 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 3-1-13 | SUBTOTAL | | \$4,246.46 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$4,522.48 | TAX | | \$276.02 |
| | | | BALANCE DUE: | | \$4,522.48 |

WE ACCEPT M/CARD, VISA & DISCOVER

D & D CLASSIC AUTO
 2300 MOTE DR
 COVINGTON OH 45318
 937-473-2229

SAM PETERS
 10001 ALLIANCE RD
 CINCINNATI OH 45242

WO#: 22110

1937 STUDEBAKER P/U
 513-702-7877

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|--|---------------------------|------------|--------------|--------------------|------------|
| | SHOP MATERIAL | \$193.60 | | HAZ. WASTE REMOVAL | \$10.00 |
| 2 QTS | 800810 GREEN ENGINE PAINT | \$154.70 | | | |
| 8 | NOR23588-80 SPAPER | \$15.60 | | | |
| 2 | NOR23589-40 SPAPER | \$4.82 | | | |
| 10 | NOR49566-80 SPAPER | \$9.50 | | | |
| 5 | NOR49564-120 SPAPER | \$6.65 | | | |
| 5 | NOR49562-180 SPAPER | \$4.75 | | | |
| 1 L | FILLER POLY METALLIC | \$62.40 | | | |
| PARTS TOTAL | | \$452.02 | SUBLET TOTAL | | \$10.00 |
| 121.00 | \$40.00 | \$4,840.00 | LABOR TOTAL | | \$4,840.00 |
| LABOR TOTAL | | | PARTS TOTAL | | \$452.02 |
| 121.00 | HR AT \$40.00 PER HR | \$4,840.00 | SUBLET TOTAL | | \$10.00 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 3-16-13 | SUBTOTAL | | \$5,302.02 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$5,646.65 | TAX | | \$344.63 |
| | | | BALANCE DUE: | | \$5,646.65 |

PD 3/21/13
 #22110
 \$5,646.65

WE ACCEPT M/CARD, VISA & DISCOVER

OC
 BTP

D & D CLASSIC AUTO
2300 MOTE DR
COVINGTON OH 45318
937-473-2229

SAM PETERS
10001 ALLIANCE RD
CINCINNATI OH 45242

WO#: 22130

1937 STUDEBAKER P/U
513-702-7877

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|---|-----------------------------|-------------------|---------------------|---------------------|-------------------|
| | SHOP MATERIAL | \$302.40 | | HAZ. WASTE REMOVAL | \$10.00 |
| 2' | NOR23589-40 SPAPER | \$4.94 | | AESTHETIC FINISHERS | |
| 4' | NOR49566-80 SPAPER | \$13.92 | | **ARMOUR COAT EXH. | |
| 2' | NOR23609-40/40 SPAPER | \$3.26 | | MANIFOLDS** | \$214.50 |
| 1 ROLL | NOR36319-2" TAPE | \$12.62 | | | |
| 1 ROLL | NOR05838-3/4" TAPE | \$12.62 | | | |
| 1/4 | FILLER POLY METALLIC | \$15.60 | | | |
| 1/4 | SC804 RM UNO BLACK PAINT | \$36.45 | | | |
| 2 QT | REFACE UPOL | \$94.64 | | | |
| 1/4 | GL1006-26 POLY BODY FILLER | \$18.16 | | | |
| 2.5 QTS | 285-13 URETHANE PRIMER | \$173.90 | | | |
| 2 | 207/207SL BEARINGS | \$69.72 | | | |
| 1 | 00604788 NITRILE SEAL | \$10.40 | | | |
| 1 | 216190 3/16" STEEL | \$9.74 | | | |
| 1 | 69723 1/8" STEEL | \$6.89 | | | |
| PARTS TOTAL | | \$785.26 | SUBLET TOTAL | | \$224.50 |
| 189.00 | \$40.00 | \$7,560.00 | LABOR TOTAL | | \$7,560.00 |
| LABOR TOTAL | | | PARTS TOTAL | | \$785.26 |
| 189.00 | HR AT \$40.00 PER HR | \$7,560.00 | SUBLET TOTAL | | \$224.50 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 3-30-13 | SUBTOTAL | | \$8,569.76 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$9,126.79 | TAX | | \$557.03 |
| | | | BALANCE DUE: | | \$9,126.79 |

*Paid 4/16/13
 Ch # 2262
 \$13,595.23*

WE ACCEPT M/CARD, VISA & DISCOVER

Paid in Full

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22130

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 1

| DATE | DESCRIPTION | BY | TIME WORKED | |
|---------|--|-------|-------------|-----|
| | | | HRS | MIN |
| 3-18-13 | Work on transmission and exhaust manifold. Clean transmission parts for reassembly. | Gary | 8 | 50 |
| 3-18-13 | Sand, fill and block on right front fender. | Joe | 10 | 00 |
| 3-18-13 | Installing floor boards. Mount door hinges to doors, hang right door and fit up. Start on left side door. | Steve | 12 | 00 |
| 3-18-13 | Finish block sanding tail gate. Hang, clean, prepare and spray tail gate, front bed extensions and lower grill splash guard with reface. | Scott | 3 | 00 |
| 3-19-13 | Repair shift fork in transmission. Weld up groove and grind smooth. | Scott | 1 | 00 |
| 3-19-13 | Work on cooling fan. | Brian | 2 | 50 |
| 3-19-13 | Fit up left door. Remove door and add shims for fit up. Weld and grind any small tears or cracks. Install running boards. Clean window regulators. | Steve | 11 | 00 |
| 3-19-13 | Clean and blast parts for transmission. Get bearings and seals then make gasket for transmission. | Gary | 6 | 50 |
| 3-20-13 | Reassemble transmission. | Gary | 6 | 50 |
| 3-20-13 | Start removing cab from chassis. Fabricate brackets to mount cab to buck. | Scott | 2 | 00 |
| 3-20-13 | Sandblast, clean, sand and paint window regulators. | Steve | 8 | 00 |
| 3-20-13 | Sand and fill on left front fender. | Joe | 10 | 00 |
| 3-21-13 | Remove wheels. Take to get tires removed. Take wheels to be powder coated. Go through shifter and clean up for paint. | Gary | 3 | 50 |
| 3-21-13 | Sand, fill and block on left fender. | Joe | 10 | 00 |
| 3-21-13 | Disassemble and remove rubber. Paint front windshield center post. Assemble window regulators. | Steve | 4 | 00 |
| 3-21-13 | Detail on chassis. Touch up chips and tag parts. | DJ | 1 | 50 |
| 3-21-13 | Remove cab from chassis. Mount cab on buck. | Scott | 2 | 00 |
| 3-22-13 | Sand and fill on front fender. | Joe | 9 | 00 |
| 3-25-13 | Go to Piqua and pick up seal for transmission and install. | Gary | 1 | 50 |
| 3-25-13 | Fill, sand and block on left/right fenders and front panel. | Joe | 9 | 50 |
| 3-25-13 | Sand window trim for doors. | Steve | 2 | 00 |
| 3-26-13 | Clean up speedometer cable and bracket for reassembling. | Gary | 1 | 00 |
| 3-26-13 | Block sand reface primer on tail gate and small parts. Clean, prepare and mask left/right fenders and front grill for primer. | Joe | 10 | 50 |

D & D CLASSIC AUTO
2300 MOTE DR
COVINGTON OH 45318
937-473-2229

SAM PETERS
10001 ALLIANCE RD
CINCINNATI OH 45242

WO#: 22145

1937 STUDEBAKER P/U
513-702-7877

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|--------|----------------------------|----------|-----|---------------------------|----------|
| | SHOP MATERIAL | \$421.60 | | HAZ. WASTE REMOVAL | \$10.00 |
| 10' | NOR23588-80 SPAPER | \$20.00 | | DAYTON CLUTCH | |
| 9' | NOR23589-40 SPAPER | \$22.23 | | **REBUILD CLUTCH AND | |
| 55' | NOR49566-80 SPAPER | \$191.40 | | PRESSURE PLATE** | \$146.64 |
| 1' | NOR49564-120 SPAPER | \$1.94 | | MILLETS GARAGE | |
| 55' | NOR49562-180 SPAPER | \$106.70 | | **GRIND FLYWHEEL** | \$45.50 |
| 22' | NOR49561-220 SPAPER | \$42.68 | | AUTOMOTIVE ARMATURE | |
| 3' | NOR49558-320 SPAPER | \$5.82 | | **REBUILD GEN/STARTER** | \$113.10 |
| 2 | NOR23609-40/40 SPAPER | \$3.26 | | MULLENS FIRESTONE | |
| 1.75 L | FILLER POLY METALLIC | \$109.20 | | **DISMOUNT TIRES** | \$97.50 |
| 4.5 QT | 285-13 URETHANE PRIMER | \$312.86 | | AESTHETIC FINISHERS | |
| 1 QT | REFACE UPOL | \$47.32 | | **STRIP/P.COAT 5 WHEELS** | \$422.50 |
| 2 QTS | UP0684 DOLPHIN LITE FILLER | \$34.20 | | | |
| 1 | 13076 THERMOSTAT | \$6.02 | | | |
| 2 | 29200 STUD KITS | \$12.98 | | | |
| 25' | ELE014 7MM PLUG WIRE | \$48.63 | | | |
| 6 | 727005 7MM WIRE ENDS | \$4.84 | | | |
| 7 | 727008 7MM WIRE ENDS | \$3.82 | | | |
| 1 | 91A15142 CONTROL VALVE | \$39.78 | | | |
| | EXHAUST PIPE | \$45.50 | | | |
| 1 | CNC525 BRAKE LINE | \$91.10 | | | |
| 1 | 4416T67 STEEL HEX BAR | \$11.76 | | | |

PARTS TOTAL \$1,583.64

SUBLET TOTAL \$835.24

263.50 \$40.00 \$10,540.00

LABOR TOTAL

LABOR TOTAL \$10,540.00

263.50 HR AT \$40.00 PER HR \$10,540.00

PARTS TOTAL \$1,583.64

SUBLET TOTAL \$835.24

** THIS BILLING BRINGS YOU UP TO DATE AS OF:

4-13-13

SUBTOTAL \$12,958.88

TAX \$842.33

** BALANCE DUE UPON RECEIPT IS: \$13,801.21

BALANCE DUE: \$13,801.21

WE ACCEPT M/CARD, VISA & DISCOVER

Paid 4/24/13

Un# 2278

\$13,806.21

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22145

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 1

| DATE | DESCRIPTION | BY | TIME WORKED | |
|--------|--|--------|-------------|-----|
| | | | HRS | MIN |
| 4-1-13 | Beadblast air cleaner. Body work on shift knob. | Andrew | 1 | 00 |
| 4-1-13 | Sand, fill and prime horn hardware. | DJ | 2 | 00 |
| 4-1-13 | Sand and fill inside of left fender. Sand fender. | Joe | 10 | 00 |
| 4-1-13 | Pick up starter and generator at Auto Armature. Install intake. | Gary | 2 | 00 |
| 4-2-13 | Install motor and transmission. Clean up parts for motor. | Gary | 6 | 00 |
| 4-2-13 | Remove wanted parts from donor car. Prepare steering box and wheel hubs for removing. | Rodney | 4 | 00 |
| 4-2-13 | Sand and fill inside of fender. | Joe | 10 | 00 |
| 4-2-13 | Sanding horn hardware for paint. | DJ | 2 | 00 |
| 4-2-13 | Sand, tape, prepare and hang starter for paint. Sand primer and fill crack on shift knob and paint. | Andrew | 3 | 00 |
| 4-3-13 | Body work on air cleaner and tape for primer. | Andrew | 5 | 00 |
| 4-3-13 | Sand and fill inside of left/right fender and clean. Prepare for right inside and spray with urethane primer. | Joe | 10 | 50 |
| 4-3-13 | Paint linkage for choke on motor. Install drive shaft and misc. parts on motor. | Gary | 3 | 00 |
| 4-3-13 | Hang, prepare and paint parts black. | Tim | 3 | 00 |
| 4-4-13 | Prime, sand, hang and paint air cleaner. Start sanding wheels. | Andrew | 5 | 00 |
| 4-4-13 | Cleaning parts for assembly. Pick up wheels from powder coater. Pick up Studebaker manual for reference. | Gary | 8 | 50 |
| 4-4-13 | Prepare and paint horn and hardware. | DJ | 2 | 50 |
| 4-4-13 | Sand, fill, clean, prepare and spray left front fender with reface. Block sand front panel. | Joe | 6 | 50 |
| 4-5-13 | Sand wheels and fill pits. | Andrew | 7 | 50 |
| 4-5-13 | Repair horn mount. | Rodney | 3 | 00 |
| 4-5-13 | Assemble horn. | DJ | 1 | 50 |
| 4-5-13 | Block sand front panel and spray with urethane primer. | Joe | 6 | 00 |
| 4-5-13 | Cleaning up parts for chassis. | Gary | 5 | 00 |
| 4-8-13 | Sand and fill wheel. | Andrew | 8 | 00 |
| 4-8-13 | Make pattern for engine pan. Bend up fuel line from pump to carburetor. Pick up pipe at exhaust store and bend down pipe for exhaust. | Gary | 8 | 50 |
| 4-8-13 | Make right side engine pan. | Rodney | 3 | 00 |
| 4-8-13 | Sand and block left front inside fender. | Joe | 9 | 00 |
| 4-9-13 | Sand wheel and fill pits. | Andrew | 8 | 00 |

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22145

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 2

| DATE | DESCRIPTION | BY | TIME WORKED | |
|---------|--|--------|-------------|-----|
| | | | HRS | MIN |
| 4-9-13 | Sand block reface primer on inside of fender. | Joe | 8 | 50 |
| 4-9-13 | Hem cutout for oil pan on right side engine pan and start fabricating mufflers. | Rodney | 6 | 00 |
| 4-9-13 | Make tail pipe. Fit gauge pan to frame. Prepare for paint. | Garv | 4 | 00 |
| 4-9-13 | Fill and sand on doors. | Dale | 3 | 00 |
| 4-10-13 | Grind, fill and sand on rear cab panel. | Dale | 8 | 00 |
| 4-10-13 | Sand and fill on wheel. Start sanding on last one. | Andrew | 8 | 00 |
| 4-10-13 | Fabricating muffler. | Rodney | 11 | 00 |
| 4-10-13 | Sand block reface primer on inside of fender. Block sand small parts. Prepare and clean inside of fender and small parts. Urethane prime fender. | Joe | 11 | 50 |
| 4-10-13 | Prepare and paint horn bracket. | DJ | 1 | 50 |
| 4-10-13 | Machine standoffs for engine. | Brad | 1 | 50 |
| 4-11-13 | Sand last wheel and fill pits. Tape wheels for prime and prime. | Andrew | 5 | 00 |
| 4-11-13 | Finish fabricating muffler, weld end caps and grind. | Rodney | 9 | 00 |
| 4-11-13 | Hammer and dolly out dents on roof and back of roof. Fill and sand on roof and back of roof. | Scott | 8 | 50 |
| 4-11-13 | Block sand inside of left front fender for paint. | Joe | 9 | 50 |
| 4-11-13 | Install muffler and paint with stainless steel heat paint. | Garv | 1 | 00 |
| 4-12-13 | Paint oil cap. Sand primer on wheels and prepare for paint. | Andrew | 4 | 50 |
| 4-12-13 | Sand right front fender inside for paint. | Joe | 9 | 00 |
| 4-12-13 | Fill and sand on back of roof and lower back of cab. | Scott | 7 | 50 |
| 4-13-13 | Tape up, hang, prepare and paint wheels. | Andrew | 3 | 00 |

TOTAL 263/50

D & D CLASSIC AUTO
 2300 MOTE DR
 COVINGTON OH 45318
 937-473-2229

SAM PETERS
 10001 ALLIANCE RD
 CINCINNATI OH 45242

WO#: 22163

1937 STUDEBAKER P/U
 513-702-7877

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|--|---------------------------------------|-------------|-----------------|--------------------|--------------|
| | SHOP MATERIAL | \$615.48 | | HAZ. WASTE REMOVAL | \$10.00 |
| 19' | NOR49566-80 SPAPER | \$66.12 | | SHIPPING CHARGES | \$142.33 |
| 39' | NOR49564-120 SPAPER | \$75.66 | | | |
| 42' | NOR49562-180 SPAPER | \$81.48 | | | |
| 40' | NOR49561-220 SPAPER | \$77.60 | | | |
| 59' | NOR49558-320 SPAPER | \$114.46 | | | |
| 15 | NOR39373-1000 W/DRY SPAPER | \$15.15 | | | |
| 13 | NOR39371-1500 W/DRY SPAPER | \$13.13 | | | |
| 3 | NOR03075-P400/320 PADS | \$9.24 | | | |
| 1 | NOR62320-2"/50 SP LOCK | \$1.96 | | | |
| 1.50 ROLL | NOR36319 2" TAPE | \$18.93 | | | |
| 10 | COR62960/80 SPAPER | \$7.40 | | | |
| 13 | COR62959/120 SPAPER | \$9.62 | | | |
| 14 | COR62957/180 SPAPER | \$10.36 | | | |
| 8 | COR62954/320 SPAPER | \$5.92 | | | |
| 1 QT | UP0684 DOLPHIN LITE WT BODY FILLER | \$17.10 | | | |
| 1 L | FILLER POLY METALLIC | \$62.40 | | | |
| 1/2 L | DOLPHIN GLAZE | \$9.72 | | | |
| 1/2 L | SC80 RM UNO BLACK PAINT | \$72.90 | | | |
| 3/4 GAL | 285-13 URETHANE PRIMER | \$173.90 | | | |
| 3 PT | 801-703 EPOXY PRIMER | \$86.55 | | | |
| 1.5 PT | REFACE UPOL | \$59.15 | | | |
| 5 | 663500 650-16 FSTONE TIRES | \$1,023.95 | | | |
| 6 | 853266 TR15 TUBES | \$132.21 | | | |
| | 5/16-24 D NUTS | \$9.43 | | | |
| 1 | 191088 FRT MOTOR MT | \$70.66 | | | |
| PARTS TOTAL | | \$2,840.48 | SUBLET TOTAL | | \$152.33 |
| 471.00 | \$40.00 | \$18,840.00 | LABOR TOTAL | | \$18,840.00 |
| LABOR TOTAL | | | PARTS TOTAL | | \$2,840.48 |
| 471.00 | HR AT \$40.00 PER HR | \$18,840.00 | SUBLET TOTAL | | \$152.33 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 5-10-13 | SUBTOTAL | | \$21,832.81 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$23,251.94 | TAX | | \$1,419.13 |
| | | | BALANCE DUE: | | \$23,251.94 |
| | | | CREDIT CK 2280: | | -\$16,587.89 |
| | | | AMOUNT DUE: | | \$6,664.05 |

****THIS INVOICE IS FOR ACCOUNTING PURPOSES****

You do not owe on this bill.

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22163

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 1

| DATE | DESCRIPTION | BY | TIME WORKED | |
|---------|--|--------|-------------|-----|
| | | | HRS | MIN |
| 4-15-13 | Sand block inside and outside of front fender for paint. | Joe | 9 | 50 |
| 4-15-13 | Untape wheels. | Andrew | | 50 |
| 4-16-13 | Sand and block outside of front fender. | Joe | 10 | 50 |
| 4-17-13 | Sand and block outside of fender and small parts for paint. | Joe | 9 | 50 |
| 4-17-13 | Fill and sand back of cab. | Scott | 3 | 50 |
| 4-18-13 | Make paint spray out. | Andrew | | 50 |
| 4-18-13 | Finish filling and sanding on outside of cab. Fill and sand in door jamb. Sand edges. Tape up, clean, prepare and spray cab with reface. | Scott | 13 | 00 |
| 4-18-13 | Cleaning chassis and engine. | DJ | 1 | 50 |
| 4-18-13 | Sand small parts for paint. Fill and sand left door opening on cab. | Joe | 11 | 50 |
| 4-18-13 | Take wheels/tires to be installed. Put back on frame. | Gary | 1 | 00 |
| 4-19-13 | Weld edge of hood and sand small parts. | Joe | 9 | 00 |
| 4-19-13 | Sand firewall. Fill and sand on firewall. | Scott | 8 | 00 |
| 4-22-13 | Metal finish and polish grill center bar. | Jim | 3 | 00 |
| 4-22-13 | Sand tailgate. Sand and fill edge of hood - sand for paint. | Joe | 9 | 50 |
| 4-22-13 | Block sand reface on roof, rear of cab and left door. | Scott | 8 | 00 |
| 4-23-13 | Remove left/right rear fenders on bed and sand. Block out side inside and weld crack on fender and grind welds. | Joe | 9 | 00 |
| 4-23-13 | Block sand reface. Remove left door and sand door jamb. Fit up cowl vent, fill and sand around vent. | Scott | 10 | 00 |
| 4-24-13 | Sand and block fender inside/out and fill. | Joe | 10 | 00 |
| 4-24-13 | Finish filling and sanding cowl vent. Finish sanding rear of cab. Sand and fill bottom flange around bottom of cab. Sand right door jamb. Sand dash. | Scott | 9 | 00 |
| 4-25-13 | Sand, block and fill inside/outside of fender. Sand side panel inside/outside for paint. | Joe | 10 | 00 |
| 4-25-13 | Hang doors. Clean, prepare and spray doors and left rear fender with urethane. Finish sanding cab, clean, prepare and spray with urethane primer. Clean, prepare and spray right rear fender with urethane. | Scott | 9 | 50 |
| 4-26-13 | Block sand cab for paint. | Scott | 7 | 00 |
| 4-26-13 | Sand left/right side panels inside/outside. Sand hood for paint. | Joe | 9 | 50 |
| 4-29-13 | Sand left/right rear fenders inside/outside for paint and front | | | |

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22163

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 2

| DATE | DESCRIPTION | BY | TIME WORKED | |
|---------|--|--------|-------------|-----|
| | | | HRS | MIN |
| | right fender. | Joe | 9 | 50 |
| 4-29-13 | Hammer oil filter, weld holes, grind, glue welds and start strap. | Rodney | 4 | 00 |
| 4-29-13 | Block sand cab for paint. | Scott | 10 | 50 |
| 4-30-13 | Finish oil filter strap. | Rodney | 2 | 00 |
| 4-30-13 | Sand fender for paint. Sand inside trunk bed. | Joe | 9 | 50 |
| 4-30-13 | Sand cab and jambs for paint. | Scott | 8 | 50 |
| 4-30-13 | Hang, prepare, seal and base four fenders and two hood sides yellow. | Tim | 7 | 50 |
| 5-1-13 | Touch up and prime grill. Mask and polish hood side to body trim | | | |
| | parts. | Jim | 7 | 50 |
| 5-1-13 | Sand, fill and prepare bed side for paint. | Joe | 9 | 50 |
| 5-1-13 | Prepare and clear misc. parts and fenders. Discuss truck with | | | |
| | customer. Sand door. | Tim | 8 | 50 |
| 5-1-13 | Sanding cab and jambs for paint. | Scott | 9 | 00 |
| 5-1-13 | Blast, prime and paint oil filter canister and clamp. | Tom | 2 | 00 |
| 5-2-13 | Wet sand and buff left rear fender. Wet sand right rear fender. | Andrew | 4 | 00 |
| 5-2-13 | Sand grill. Mask and block sand hood side louvers and mask | | | |
| | stainless. | Jim | 8 | 00 |
| 5-2-13 | Sand underside of bed, clean welds and fill. | Joe | 10 | 00 |
| 5-2-13 | Sand on cab. | Tim | 8 | 00 |
| 5-2-13 | Finish sanding cab for paint. Sand under floor of cab. Clean, | | | |
| | prepare and spray under floor with epoxy primer. Start sanding | | | |
| | right door for paint. | Scott | 9 | 00 |
| 5-3-13 | Wet sand and buff hood sides and left front fender. | Andrew | 7 | 00 |
| 5-3-13 | Block sand grill and spears. Scuff under sides of parts. | Jim | 2 | 50 |
| 5-3-13 | Sand under bed for paint and spot prime quarter panel. | Joe | 8 | 50 |
| 5-3-13 | Block sand right door and spot prime. | Scott | 6 | 50 |
| 5-3-13 | Sand on cab. | Tim | 8 | 50 |
| 5-6-13 | Sand spot primer on bed for paint. | Joe | 7 | 00 |
| 5-6-13 | Finish block sanding right door. Grind and sandblast door hinges. | | | |
| | Fill pits on hinges. Hang, clean, prepare and spray hinges with | | | |
| | epoxy primer. | Scott | 8 | 00 |
| 5-6-13 | Finish sanding filler out of cowl vent hole, seam seal, prepare, | | | |
| | seal and base. | Tim | 9 | 50 |
| 5-7-13 | Wet sand and buff right front fender. | Andrew | 7 | 00 |

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22163

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 3

| DATE | DESCRIPTION | BY | TIME WORKED | |
|---------|---|--------|-------------|-----|
| | | | HRS | MIN |
| 5-7-13 | Sand epoxy on door hinges, hang and spray with urethane primer. Sandblast interior trim and sand. | Scott | 8 | 00 |
| 5-7-13 | Base, clear and bake cab. | Tim | 8 | 00 |
| 5-8-13 | Finish sanding trim, hang, clean, prepare and spray with epoxy primer. Sand battery door, fill and sand. Start sanding epoxy on trim. | Scott | 10 | 00 |
| 5-8-13 | Tape up cab. Brush paint inside. Tape cab to paint underside and dash. | Andrew | 5 | 50 |
| 5-8-13 | Tape and paint bottom of cab. | Tim | 10 | 00 |
| 5-9-13 | Assemble grill and stainless. | Jim | 3 | 00 |
| 5-9-13 | Sand interior trim, hang and spray with urethane primer. Sand cowl vent handle and under hood brace for paint. Start sanding interior trim for paint. | Scott | 8 | 50 |
| 5-9-13 | Wet sand and buff cab. | Andrew | 8 | 00 |
| 5-9-13 | Hang parts. Set up bed and tailgate to paint an seam seal. | Tim | 8 | 00 |
| 5-10-13 | Fix seam sealer on back of cab. Sand, tape up dash and door jambs for paint. Wet sand and buff cowl vent door. Cover cab to paint bed. | Andrew | 7 | 50 |
| 5-10-13 | Assemble grill. Metal finish and straighten hood trim parts and polish. Metal finish and polish horn ring. | Jim | 7 | 00 |
| 5-10-13 | Prepare and paint door latches. Sand and polish door handles. Cleaning up hardware. | DJ | 7 | 00 |
| 5-10-13 | Sanding interior trim. | Scott | 7 | 50 |
| 5-10-13 | Prepare, seal, base and clear bed, grill surround, tailgate and misc. small parts. | Tim | 9 | 00 |

TOTAL 471/00

D & D CLASSIC AUTO
 2300 MOTE DR
 COVINGTON OH 45318
 937-473-2229

SAM PETERS
 10001 ALLIANCE RD
 CINCINNATI OH 45242

WO#: 22163

1937 STUDEBAKER P/U
 513-702-7877

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|------------------------------|----------------------|-------------|--------------|--------------------|-------------|
| | SHOP MATERIAL | \$615.48 | | HAZ. WASTE REMOVAL | \$0.00 |
| PARTS TOTAL | | \$615.48 | SUBLET TOTAL | | \$0.00 |
| 374.00 | \$40.00 | \$14,960.00 | LABOR TOTAL | | \$14,960.00 |
| LABOR TOTAL | | | PARTS TOTAL | | \$615.48 |
| 374.00 | HR AT \$40.00 PER HR | \$14,960.00 | SUBLET TOTAL | | \$0.00 |
| SUBTOTAL | | | SUBTOTAL | | \$15,575.48 |
| TAX | | | TAX | | \$1,012.41 |
| BALANCE DUE UPON RECEIPT IS: | | \$16,587.89 | BALANCE DUE: | | \$16,587.89 |

Handwritten notes:
 Paid 4/24/13
 ch #
 \$
 2280
~~16587.89~~
 \$16587.89

** THIS BILLING BRINGS YOU UP TO DATE AS OF:

4-15-13

WE ACCEPT M/CARD, VISA & DISCOVER

**D & D CLASSIC AUTO
2300 MOTE DR
COVINGTON OH 45318
937-473-2229**

**SAM PETERS
10001 ALLIANCE RD
CINCINNATI OH 45242**

WO#: 22203

YELLOW
**1937 STUDEBAKER P/U
513-702-7877**

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|---|--|-------------------|---------------------|--------------------|-------------------|
| | SHOP MATERIAL | \$615.48 | | HAZ. WASTE REMOVAL | \$10.00 |
| 1 | 1424 ENG., HLITE & BODY HARNESS | \$410.80 | | SHIPPING CHARGES | \$51.44 |
| 1 | 1425 DASH & ENGINE HARNESS | \$148.72 | | | |
| 1 | 1426 H.LITE BUCKET WIRES | \$56.16 | | | |
| 1 PR | 1700555-58 DOOR WINDOW W/STRIP | \$36.25 | | | |
| 1 PR | 18-0009-14 H.LITE BODY TO BRKT PAD | \$64.09 | | | |
| 1 PR | 18-0010-55 FRT DOOR VENT WINDOW W/STRIP | \$166.40 | | | |
| 1 PR | 18-0017-88 GEARSHIFT @FLOOR BOOT | \$56.36 | | | |
| 1 PR | 18-0018-24 BRK & CLUTCH PEDAL SH SEALS | \$45.53 | | | |
| 1 PR | 18-0023-14 H.LITE BRKT/RAD.SHELL PAD | \$53.71 | | | |
| 1 | 265488 W/S SEAL | \$104.00 | | | |
| 1 | 801360 UPPER DOOR SEAL | \$32.50 | | | |
| 1 | 266397 VENTILATER SEAL | \$49.40 | | | |
| 2 | 658258 BUMPER GROMMETS | \$52.00 | | | |
| 1 | 1284XAE47 COWL SEAL | \$19.50 | | | |
| 1 | 70-0555-58 DOOR WINDOW W/STRIP | \$36.25 | | | |
| PARTS TOTAL | | \$1,947.15 | SUBLET TOTAL | | \$61.44 |
| 104.50 | \$40.00 | \$4,180.00 | LABOR TOTAL | | \$4,180.00 |
| LABOR TOTAL | | | LABOR TOTAL | | \$4,180.00 |
| 104.50 | HR AT \$40.00 PER HR | \$4,180.00 | PARTS TOTAL | | \$1,947.15 |
| | | | SUBLET TOTAL | | \$61.44 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 6-21-13 | SUBTOTAL | | \$6,188.59 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$6,590.85 | TAX | | \$402.26 |
| | | | BALANCE DUE: | | \$6,590.85 |

****THIS INVOICE IS FOR ACCOUNTING PURPOSES****

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22203

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 1

| DATE | DESCRIPTION | BY | TIME WORKED | |
|---------|--|--------|-------------|-----|
| | | | HRS | MIN |
| 5-13-13 | Straighten, metal finish and polish stainless. Assemble stainless over painted parts. | Jim | 5 | 00 |
| 5-13-13 | Weld on tabs to L/R rear fenders. | Pete | 1 | 50 |
| 5-13-13 | Wet sand and buff bed extensions. Wet sand both doors and buff. Put cab on frame. | Andrew | 7 | 50 |
| 5-13-13 | Prepare, photograph and catalog parts for plating. | DJ | 1 | 00 |
| 5-13-13 | Make tabs to be welded on rear fenders. Fill and sand on rear fenders where tabs were welded. Sand rear stone guards. Remove mounting brackets on left stone guard - straighten and weld back on. Fill and sand on stone guards. | Scott | 8 | 00 |
| 5-13-13 | Paint misc. parts. | Tim | 8 | 00 |
| 5-14-13 | Wet sand and buff grill shell and headlights. | Andrew | 4 | 00 |
| 5-14-13 | Search for door hardware. | DJ | | 50 |
| 5-14-13 | Sandblast gas filler neck, hang and prime. Sand dash parts. Sand door inner structure pieces and paint black. | Scott | 6 | 00 |
| 5-14-13 | Hang doors and install door latches. | Gary | 2 | 00 |
| 5-14-13 | Hang, tape up, prepare, seal base and clear parts. | Tim | 9 | 50 |
| 5-15-13 | Assembly of front end. | Gary | 3 | 00 |
| 5-15-13 | Sand interior parts for paint. | Scott | 2 | 00 |
| 5-16-13 | Installing bed rear filler panels, tailgate and fenders. | Gary | 6 | 00 |
| 5-16-13 | Set bed on frame. Wet sand and buff rear fenders. | Andrew | 4 | 50 |
| 5-17-13 | Take parts to Brightworks. | DJ | | 50 |
| 5-20-13 | Adjust grill assembly. | Bobby | 1 | 00 |
| 5-20-13 | Sand running boards. | Scott | 1 | 00 |
| 5-21-13 | Beadblast oil filter canister and bracket. Replace missing square head bolts. | Tom | 1 | 50 |
| 5-22-13 | Wet sand and buff hood. | Andrew | 3 | 00 |
| 5-23-13 | Install hood on truck. | Andrew | 1 | 00 |
| 5-23-13 | Install hood. Work on trim for hood louvers in preparation of installing. | Gary | 6 | 50 |
| 6-14-13 | Locate interior parts and take to Joe Smith. | Tom | 1 | 00 |
| 6-18-13 | Body work on oil filler. | Andrew | 1 | 00 |
| 6-19-13 | Disassemble two gauge clusters. Clean glass gauge lenses. Clean bezels and other gauge parts. Remove windshield from donor car. | Gabe | 7 | 00 |

**D & D CLASSIC AUTO
2300 MOTE DR
COVINGTON OH 45318
937-473-2229**

**SAM PETERS
10001 ALLIANCE RD
CINCINNATI OH 45242**

WO#: 22285

**1937 STUDEBAKER P/U
513-702-7877**

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|---|----------------------------|-------------------|---------------------|--------------------|-------------------|
| | SHOP MATERIAL | \$116.00 | | HAZ. WASTE REMOVAL | \$10.00 |
| 1 | E70739 LOWER RADIATOR HOSE | \$19.50 | | | |
| | FITTINGS | \$33.70 | | | |
| 6 | 516 COPPER SP PLUGS | \$17.87 | | | |
| | FAS180/183/089 CLAMPS | \$41.60 | | | |
| 1 | CP7584 COPPER TUBING KIT | \$13.16 | | | |
| 1 | L546 V BELT | \$22.29 | | | |
| 3 | L548/49/50 V BELTS | \$69.42 | | | |
| 1 | 1042 OIL FILTER | \$9.10 | | | |
| 1 | 613 STIK HOSE | \$19.93 | | | |
| 1 | OIL CAP | \$286.00 | | | |
| 2 | HUB CAPS | \$156.00 | | | |
| 1 | SPEEDO FACE | \$65.00 | | | |
| PARTS TOTAL | | \$869.57 | SUBLET TOTAL | | \$10.00 |
| 72.50 | \$40.00 | \$2,900.00 | LABOR TOTAL | | \$2,900.00 |
| LABOR TOTAL | | | PARTS TOTAL | | \$869.57 |
| 72.50 | HR AT \$40.00 PER HR | \$2,900.00 | SUBLET TOTAL | | \$10.00 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 8-2-13 | SUBTOTAL | | \$3,779.57 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$4,025.24 | TAX | | \$245.67 |
| | | | BALANCE DUE: | | \$4,025.24 |

WE ACCEPT M/CARD, VISA & DISCOVER

****THIS INVOICE IS FOR ACCOUNTING PURPOSES****

**D & D CLASSIC AUTO
2300 MOTE DR
COVINGTON OH 45318
937-473-2229**

**SAM PETERS
10001 ALLIANCE RD
CINCINNATI OH 45242**

WO#: 22247

**1937 STUDEBAKER P/U
513-702-7877**

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|---|------------------------------------|--------------------|---------------------|-------------------|--------------------|
| | SHOP MATERIAL | \$424.00 | | HAZ WASTE REMOVAL | \$10.00 |
| | RUNNING BOARDS | \$741.00 | | HEMMS GLASS | |
| | FITTINGS | \$23.64 | | **6 PCS GLASS** | \$378.30 |
| | CNC525 BRAKE LINE | \$91.10 | | | |
| | MISC HARDWARE | \$30.72 | | | |
| | 68457 WEATHER PROOFING CAULKING | \$46.30 | | | |
| PARTS TOTAL | | \$1,356.76 | SUBLET TOTAL | | \$388.30 |
| 265.00 | \$40.00 | \$10,600.00 | LABOR TOTAL | | \$10,600.00 |
| LABOR TOTAL | | | PARTS TOTAL | | \$1,356.76 |
| 265.00 | HR AT \$40.00 PER HR | \$10,600.00 | SUBLET TOTAL | | \$388.30 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 7-19-13 | SUBTOTAL | | \$12,345.06 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$13,147.49 | TAX | | \$802.43 |
| | | | BALANCE DUE: | | \$13,147.49 |

WE ACCEPT M/CARD, VISA & DISCOVER

****THIS INVOICE IS FOR ACCOUNTING PURPOSES****

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22247

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 1

| DATE | DESCRIPTION | BY | TIME WORKED | |
|---------|--|--------|-------------|-----|
| | | | HRS | MIN |
| 6-24-13 | Getting coil ready for paint. | Garv | 2 | 00 |
| 6-24-13 | Modify hardware and install hood support brace and proper hardware on exterior door handles. Repair broken spring in door latch. | | | |
| | Install cowl vent seal and fit vent. Assemble right side hood trim. | Gabe | 8 | 00 |
| 6-25-13 | Assist with dash braces and wiring. | Brian | 2 | 50 |
| 6-25-13 | Begin running wiring in engine compartment and wiring components. | | | |
| | Make door check bumpers. Install both window regulators. Remove dash pad from donor car. | Gabe | 8 | 00 |
| 6-26-13 | Prepare parts to paint black. Prepare and tape headlight for paint. | Andrew | 1 | 00 |
| 6-26-13 | Begin fabricating and fitting up radiator mount brackets. | Steve | 7 | 00 |
| 6-26-13 | Install door check bumpers. Work on fuel lines. Mount junction block and park brake cable to firewall. Beadblast and paint washers for firewall pad and wiring hold downs. | Gabe | 7 | 00 |
| 6-27-13 | Paint brackets and misc. parts black. | Andrew | 1 | 00 |
| 6-27-13 | Finish radiator brackets. | Steve | 4 | 00 |
| 6-27-13 | Prepare, photograph, catalog and take parts to Brightworks for plating. | DJ | 1 | 50 |
| 6-27-13 | Assist with assembly. | Brian | 8 | 50 |
| 6-27-13 | Fit up firewall pad and put in place. Work on fuel lines. | Gabe | 6 | 50 |
| 6-28-13 | Work on heater, fitment of engine and firewall components. | Brian | 8 | 50 |
| 6-28-13 | Bolt firewall pad in place. Fit up heater box and put in place. | | | |
| | Fit parking brake cable through firewall pad. | Gabe | 8 | 00 |
| 7-1-13 | Sand and polish trim. | DJ | 1 | 00 |
| 7-1-13 | Assembly on truck. | Brian | 6 | 50 |
| 7-1-13 | Run wiring through firewall and connect to junction block. Adjust heater core and bolt on. Install wire hold downs and grommets. | | | |
| | Begin fitting front splash pan. | Gabe | 8 | 00 |
| 7-2-13 | Sand and buff window trim. | DJ | 1 | 00 |
| 7-2-13 | Work on windshield, floor pans and wiring. | Brian | 8 | 50 |
| 7-2-13 | Paint floor pans and prepare for installation. Check fitment of seat and windshield. Bolt the cab to frame. | Gabe | 8 | 00 |
| 7-3-13 | Work on floors, linkage, e-brake and firewall. | Brian | 4 | 00 |
| 7-3-13 | Install floor pans, throttle linkage and park brake parts. Fill transmission with fluid. | Gabe | 8 | 00 |

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22247

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 2

| DATE | DESCRIPTION | BY | TIME WORKED | |
|---------|---|-------|-------------|-----|
| | | | HRS | MIN |
| 7-3-13 | Fill and sand on running boards, hang and prime. | Scott | 4 | 00 |
| 7-5-13 | Install headlight bucket/gasket, spare tire bracket and right inner fender. Begin fitting left hood side. | Gabe | 8 | 00 |
| 7-6-13 | Adjust fitment of right side hood panel. | Scott | 1 | 00 |
| 7-8-13 | Install welting around both side panels. Continue fitting panels and all surrounding panels. | Gabe | 8 | 00 |
| 7-9-13 | Sanding windshield trim. | DJ | | 50 |
| 7-9-13 | Install fender welting along left fender and front of right fender. Align left fender and bolt into place. Work on core support alignment. Install top center piece of grill. | Gabe | 8 | 00 |
| 7-10-13 | Sanding windshield trim. | DJ | 6 | 50 |
| 7-10-13 | Work on running board. Assist with front end. | Brian | 4 | 00 |
| 7-10-13 | Install fender welting, align fender and bolt everything into place. Fit up both running boards and glue rubber on right side. | Gabe | 8 | 00 |
| 7-11-13 | Work on moldings. | Jim | 3 | 00 |
| 7-11-13 | Work on running boards and front end alignment. | Brian | 6 | 00 |
| 7-11-13 | Install splash pan and fender welting on right rear. Install front fender supports and upper radiator bracket. Work on radiator alignment and fitment of running board with the rubber. | Gabe | 8 | 00 |
| 7-12-13 | Work on stainless, metal finish, straighten and sand. | Jim | 5 | 50 |
| 7-12-13 | Work on running boards. | Brian | 6 | 00 |
| 7-12-13 | Glue rubber to left running board. Install fender welting to left rear fender. Align radiator. Modify hardware. | Gabe | 8 | 00 |
| 7-15-13 | Block sand hood moldings. | Jim | 1 | 00 |
| 7-15-13 | Install insulation between hood and brace. Make and install fuel line across front of truck. Work on running boards and hardware. | Gabe | 8 | 00 |
| 7-16-13 | Block and polish stainless trim. | Jim | 5 | 00 |
| 7-16-13 | Make and install fuel line to tank. Connect all lines and hoses from tank to pump. Modify hardware and paint brackets holding the fuel line. Install bolts in side of cab. | Gabe | 6 | 50 |
| 7-16-13 | Fitting rear splash guards. Move tabs on guard and weld back on for fitting. Sand reface on guards. | Scott | 7 | 50 |
| 7-17-13 | Trim, fit and install running boards. Work on hood trim. Repair rubber bumpers for hood side panels. | Gabe | 10 | 00 |

D & D CLASSIC AUTO
 2300 MOTE DR
 COVINGTON OH 45318
 937-473-2229

SAM PETERS
 10001 ALLIANCE RD
 CINCINNATI OH 45242

WO#: 22310

1937 STUDEBAKER P/U
 513-702-7877

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|--|----------------------|------------|-------------------------|--------------------|------------|
| | SHOP MATERIAL | \$180.00 | | HAZ. WASTE REMOVAL | \$10.00 |
| 1 | B34 V-BELT | \$14.55 | | SHIPPING CHARGES | \$12.03 |
| 1 | 83-102073 EXTRUSION | \$80.11 | | | |
| PARTS TOTAL | | \$274.66 | SUBLET TOTAL | | \$22.03 |
| 112.50 | \$40.00 | \$4,500.00 | LABOR TOTAL | | \$4,500.00 |
| LABOR TOTAL | | | PARTS TOTAL | | \$274.66 |
| 112.50 | HR AT \$40.00 PER HR | \$4,500.00 | SUBLET TOTAL | | \$22.03 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 9-13-13 | SUBTOTAL | | \$4,796.69 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$5,108.47 | TAX - HAMILTON CO. 6.5% | | \$311.78 |
| | | | BALANCE DUE: | | \$5,108.47 |

WE ACCEPT M/CARD, VISA & DISCOVER

****THIS INVOICE IS FOR ACCOUNTING PURPOSES****

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22310

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 1

| DATE | DESCRIPTION | BY | TIME WORKED | |
|---------|---|--------|-------------|-----|
| | | | HRS | MIN |
| 8-5-13 | Fabricate parts for radiator. | Jim | 1 | 50 |
| 8-5-13 | Make rubber bumpers for doors. Work on door function and fitment. | | | |
| | Beadblast and paint radiator cap. | Gabe | 6 | 50 |
| 8-6-13 | Fabricate parts for windshield trim. | Jim | 2 | 50 |
| 8-6-13 | Match and mix paint for dash and make spray out card. Final sand | | | |
| | of window frames and dash components - prepare and paint. | Andrew | 5 | 00 |
| 8-6-13 | Fabricate right door striker backing plate. Fit and adjust door | | | |
| | latches and strikers. | Gabe | 6 | 50 |
| 8-27-13 | Install windshield and inside trim. | Brian | 4 | 00 |
| 8-27-13 | Install windshield and windshield trim. Work on headlights. | Gabe | 1 | 50 |
| 8-28-13 | Repair headlight. | Gary | | 50 |
| 8-28-13 | Install front bumper and wiring into headlight reflectors. Make | | | |
| | headlight lense gaskets. Install and test bulbs. Beadblast and | | | |
| | paint reflector hardware. Install reflectors. | Gabe | 7 | 00 |
| 8-28-13 | Install front bumper and assists with headlights. | Brian | 4 | 50 |
| 8-29-13 | Straighten, metal finish and polish. | Jim | 8 | 00 |
| 8-29-13 | Making new gaskets and assembling wig wag taillights. | Gabe | 8 | 00 |
| 8-30-13 | Install right door seal and headlight trim. Clean headlight lenses | | | |
| | and install. | Gabe | 7 | 00 |
| 9-9-13 | Work on wiring. Adjust left fender to fit bumper brackets. | Gabe | 8 | 00 |
| 9-10-13 | Modify and fit left fender and welt. | Gabe | 6 | 50 |
| 9-10-13 | Assist with fitting rear fenders and brackets. | Brian | 5 | 50 |
| 9-11-13 | Install rear bumper brackets, bumper and bumper guards. Adjusting | | | |
| | front bumper for fitment issues. Modify hardware for bumper | | | |
| | brackets. Polish bumper bolts. | Gabe | 11 | 00 |
| 9-11-13 | Assist with bumpers and fitment issues. | Brian | 5 | 00 |
| 9-12-13 | Work on wiring. Adjust and set rear bumper. Make rubber bumpers and | | | |
| | install on hood latch. Straightening front right bumper bracket. | Gabe | 7 | 50 |
| 9-13-13 | Work on front bumper alignment and wiring. Install right door | | | |
| | seal and rear hood seal. | Gabe | 6 | 50 |

TOTAL 112/50

**D & D CLASSIC AUTO
2300 MOTE DR
COVINGTON OH 45318
937-473-2229**

**SAM PETERS
10001 ALLIANCE RD
CINCINNATI OH 45242**

WO#: 22364

**1937 STUDEBAKER P/U
513-702-7877**

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|---|-----------------------------|-------------------|--------------------------------|--------------------|-------------------|
| | SHOP MATERIAL | \$156.80 | | HAZ. WASTE REMOVAL | \$10.00 |
| 14 | SHEETS OF DYNAMAT INSULATON | \$667.38 | | | |
| 5 | ROLLS OF TAPE | \$82.05 | | | |
| | MISC HARDWARE | \$15.80 | | | |
| PARTS TOTAL | | \$922.03 | SUBLET TOTAL | | \$10.00 |
| 98.00 | \$40.00 | \$3,920.00 | LABOR TOTAL | | \$3,920.00 |
| LABOR TOTAL | | | PARTS TOTAL | | \$922.03 |
| 98.00 | HR AT \$40.00 PER HR | \$3,920.00 | SUBLET TOTAL | | \$10.00 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 9-27-13 | SUBTOTAL | | \$4,852.03 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$5,167.41 | TAX - HAMILTON CO. 6.5% | | \$315.38 |
| | | | BALANCE DUE: | | \$5,167.41 |

WE ACCEPT M/CARD, VISA & DISCOVER

****THIS INVOICE IS FOR ACCOUNTING PURPOSES****

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22364

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 1

| DATE | DESCRIPTION | BY | TIME WORKED | |
|---------|--|--------|-------------|-----|
| | | | HRS | MIN |
| 9-16-13 | Modify hardware, beadblast and paint. Work on fitting hood ornament pieces together and to hood. | Gabe | 6 | 50 |
| 9-17-13 | Fit hood ornament base. Install base, ornament and hood latch mechanism. Adjust hood catch. Begin assembling dome light. | Gabe | 7 | 50 |
| 9-18-13 | Paint dash emblem. | Andrew | 1 | 00 |
| 9-18-13 | Polish trim for glove box door. | Gabe | 2 | 00 |
| 9-20-13 | Polish trim for glove box door. Fitting seat components. | Gabe | 2 | 50 |
| 9-23-13 | Adjust glove box door and fit. Install dash trim. | Jim | 3 | 00 |
| 9-23-13 | Work on door window issue. Remove window. | Brian | 5 | 00 |
| 9-23-13 | Check prices and availability of red oak lumber for pick up bed. | Tom | 1 | 00 |
| 9-23-13 | Polish trim for radio delete plate. Assemble and install radio delete plate and glove box door. Beadblast, paint, assemble and install ash tray. Work on door window assembly. Measure for back glass. | Gabe | 8 | 00 |
| 9-24-13 | Complete dash trim and glove box installation. | Jim | 1 | 00 |
| 9-24-13 | Installing dynamat. | DJ | 2 | 50 |
| 9-24-13 | Run wiring and install dome light. Work on windshield wiper components. Work on vent window seals. | Gabe | 8 | 00 |
| 9-25-13 | Weld and grind pot metal windshield wiper linkage. | Jim | 1 | 00 |
| 9-25-13 | Polish air vents for dash. | Steve | 10 | 00 |
| 9-25-13 | Assist with windshield wipers. Work on door glass. | Brian | 4 | 50 |
| 9-25-13 | Installing dynamat. | DJ | 6 | 50 |
| 9-25-13 | Assembling and repairing wiper components. Polish hardware for wiper posts. Work on vent wing rubber. | Gabe | 8 | 00 |
| 9-26-13 | Installing dynamat. | DJ | 4 | 00 |
| 9-26-13 | Fitting back window and making seals. | Gabe | 7 | 00 |
| 9-26-13 | Weld brackets. | Rodney | 1 | 00 |
| 9-27-13 | Install defrost vents and ducts. Install wiper motor and ignition switch bezel. Work on fitting ignition switch in dash. | Gabe | 8 | 00 |

TOTAL 98/00

D & D CLASSIC AUTO
 2300 MOTE DR
 COVINGTON OH 45318
 937-473-2229

SAM PETERS
 10001 ALLIANCE RD
 CINCINNATI OH 45242

WO#: 22383

1937 STUDEBAKER P/U
 513-702-7877

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|--|---------------------------|-------------|--------------------------|--|-------------|
| | SHOP MATERIAL | \$579.20 | | HAZ. WASTE REMOVAL | \$10.00 |
| | MISC HARDWARE | \$200.47 | | JOHN WOLF | |
| | S4S RED OAK STRIPS | \$156.65 | | **RESTORE - FUEL GAUGE, TEMP. GAUGE & OIL PRESS** | |
| 1 | 08609 ADHESIVE | \$32.34 | | **REPAIR & REPAINT FACES** | \$682.50 |
| | FAS182/183/187 CLAMPS | \$39.00 | | SHIPPING CHARGES | \$15.87 |
| | 813-1226 BRAKE LINE | \$3.58 | | | |
| 2 | 728019 BATTERY TERMINALS | \$20.31 | | | |
| 2 | 728060 BATTERY CABLE LUGS | \$5.78 | | | |
| 1 | 11 BATTERY | \$123.97 | | | |
| | 1154LL MINI BULBS | \$7.75 | | | |
| 1 | 8920K265 STEEL ROD | \$7.93 | | | |
| 1 | 7C8144450 CHAIN COVERS | \$13.00 | | | |
| 1 | 3203951 INV. FLARE PLUG | \$2.58 | | | |
| PARTS TOTAL | | \$1,192.56 | SUBLET TOTAL | | \$708.37 |
| 362.00 | \$40.00 | \$14,480.00 | LABOR TOTAL | | \$14,480.00 |
| LABOR TOTAL | | | PARTS TOTAL | | \$1,192.56 |
| 362.00 | HR AT \$40.00 PER HR | \$14,480.00 | SUBLET TOTAL | | \$708.37 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 12-27-13 | SUBTOTAL | | \$16,380.93 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$17,486.64 | TAX - HAMILTON CO. 6.75% | | \$1,105.71 |
| | | | BALANCE DUE: | | \$17,486.64 |

WE ACCEPT M/CARD, VISA & DISCOVER

THIS INVOICE IS FOR ACCOUNTING PURPOSES

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22383

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 1

| DATE | DESCRIPTION | BY | TIME WORKED | |
|----------|---|--------|-------------|-----|
| | | | HRS | MIN |
| 9-30-13 | Plant oak boards to thickness, rip to proper width, trim to length and fit to bed. | Tom | 4 | 50 |
| 9-30-13 | Modify mounting holes for rear window. Install rubber for rear window. Fit and install ignition switch in dash. Adjust glove box fitment. Install defrost splitter. | Gabe | 8 | 00 |
| 10-1-13 | Cut, trim, drill and fit oak boards for pick up bed. | Tom | 7 | 00 |
| 10-1-13 | Beadblast and paint components for gauge cluster. Assemble gauge cluster. Polish stainless trim. Make new gaskets for gauge cluster. | Gabe | 8 | 00 |
| 10-2-13 | Assist with switches and gauges. | Brian | 4 | 00 |
| 10-2-13 | Disassemble and rebuild headlight switch. Install headlight switch. Work on fitting gauge cluster in dash. Make seal for rear window. | Gabe | 7 | 00 |
| 10-3-13 | Work on rear window. Set glass in vent wings. Assist with door garnish and vent wing latches. | Brian | 8 | 50 |
| 10-3-13 | Work on fitment of rear window. Install gauge cluster and starter pull cable. Assemble left window frame. Work on right window frame and vent wing hardware and brackets. | Gabe | 8 | 00 |
| 10-3-13 | Sand and grain fill wood for bed floor. | Andrew | 4 | 00 |
| 10-4-13 | Sand wood for bed. | Andrew | 2 | 00 |
| 10-4-13 | Hook up gauges. Wire dash. | Gabe | 4 | 50 |
| 10-7-13 | Setting glass for quarter glass. Work on wiring. | Brian | 4 | 00 |
| 10-7-13 | Ran wiring down column for horn. Wire dash lights. Install window felt on right window frame. | Gabe | 8 | 00 |
| 10-7-13 | Clear wood. | Andrew | 1 | 50 |
| 10-8-13 | Sand clear on wood. | Andrew | 1 | 00 |
| 10-8-13 | Fit window trim, window runner felt and window glass. Install felt. Work on new glass and hardware. | Gabe | 10 | 00 |
| 10-9-13 | Sand clear on wood and clear wood grain. | Andrew | 3 | 00 |
| 10-9-13 | Work on vent wings and installing door glass. | Brian | 4 | 50 |
| 10-9-13 | Install left side glass. Fit left side inside window frame. Work on right inside window frame assembly. | Gabe | 10 | 00 |
| 10-10-13 | Sand, tape and clear wood. | Andrew | 3 | 00 |
| 10-14-13 | Work on right door window felts, track, window and regulator. Install and wire instrument panel light switch. | Gabe | 7 | 50 |
| 10-15-13 | Fitting all window components in both doors. | Gabe | 8 | 50 |

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22383

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 2

| DATE | DESCRIPTION | BY | TIME WORKED | |
|----------|---|--------|-------------|-----|
| | | | HRS | MIN |
| 10-15-13 | Sand and paint mud guards. | DJ | 2 | 00 |
| 10-16-13 | Add brake fluid and coolant. Wire fuel sending unit. Fit left side door components. | Gabe | 8 | 50 |
| 10-17-13 | Fit and install right door upper door panel. Assemble right door components. Work on repairing and assembling wiper posts and transmissions. Make rubber bases for wiper parts. | Gabe | 9 | 00 |
| 10-18-13 | Fit and install hood trim. Assemble wiper transmission. Fit wiper parts. | Gabe | 5 | 50 |
| 10-18-13 | Clear wood. | Andrew | 1 | 00 |
| 10-21-13 | Sand, prepare and paint review mirror. Letter center caps. | Andrew | 4 | 00 |
| 10-21-13 | Install door handle and window crank springs and window crank handle on right door. Work on inside door handles and hood sides trim. | Gabe | 8 | 00 |
| 10-22-13 | Work on hood trim. | Brian | 3 | 50 |
| 10-22-13 | Fit and install hood sides trim. Work on wiper arms. | Gabe | 8 | 00 |
| 10-22-13 | Wet sand and buff wood. | Andrew | 4 | 00 |
| 10-22-13 | Work on window levers and side windows. | Brian | 4 | 50 |
| 10-23-13 | Remove door panels and trim. Modify inside door handles and opening mechanism. Install door panels, trim and door handles. Disassemble wiper arms, polish and reassemble. | Gabe | 8 | 00 |
| 10-23-13 | Work on taillights, door handles and wiring. | Brian | 4 | 50 |
| 10-24-13 | Making a working wig wag taillight. | Gabe | 8 | 00 |
| 10-25-13 | Fit components and begin assembling wig wag taillight. | Gabe | 5 | 00 |
| 10-25-13 | Fill and sand on inner engine panels, transmission cover - hang and spray with panels with urethane primer. | Scott | 3 | 00 |
| 10-28-13 | Sand inner engine panels. | Scott | 1 | 50 |
| 10-28-13 | Fitting taillight holder. Work on wig wag taillight. | Gabe | 4 | 00 |
| 10-29-13 | Make brackets to hold left taillight. | Gabe | 4 | 00 |
| 10-30-13 | Work on mounting holes for taillight bracket. Work on taillight bracket. | Gabe | 4 | 00 |
| 10-31-13 | Modify license plate bracket. Work on fitting taillight and fit brackets. | Gabe | 9 | 50 |
| 11-1-13 | Continue working on taillight brackets and mounting. | Gabe | 8 | 00 |
| 11-4-13 | Remake mounting brackets and modify mounting location for taillights. | Gabe | 8 | 00 |

D & D CLASSIC AUTO

DAILY LABOR LOG

NAME: SAM PETERS

WO: 225

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 3

| DATE | DESCRIPTION | BY | TIME WORKED | |
|----------|--|--------|-------------|-----|
| | | | HRS | MIN |
| 11-5-13 | Fabricate taillight bracket. | Steve | 1 | 50 |
| 11-5-13 | Install bumper. Fit taillight and taillight bracket. Beadblast light housing, license plate bracket and wig wag bracket for paint. | Gabe | 8 | 00 |
| 11-6-13 | Prepare and paint brackets and parts. | Andrew | 2 | 00 |
| 11-6-13 | Beadblast new bracket and prepare light for paint. | Gabe | 1 | 00 |
| 11-7-13 | Assemble taillight with new wiring and bulb. Install both tail-light brackets, license plate frame, taillight and wig wag. | Gabe | 4 | 00 |
| 11-8-13 | Work on fitting hood sides trim. | Gabe | 2 | 00 |
| 11-11-13 | Wire wig wag, taillight and heater. Install wiper post retainer. | Gabe | 7 | 50 |
| 11-14-13 | Install fuel filler neck. Add fuel and oil. Work on front hubs. Install test battery and hook up cables. Work on starting systems. | Gabe | 8 | 00 |
| 11-14-13 | Getting engine running. | Brian | 6 | 50 |
| 11-15-13 | Install ground straps on body, chassis and engine. Test electronic components. Work on starting engine. Grease right side suspension. | Gabe | 8 | 00 |
| 11-18-13 | Work on front wheel bearings. | Brian | 3 | 00 |
| 11-18-13 | Pack front bearings. Grease left side suspension. | Gabe | 3 | 00 |
| 11-20-13 | Bleed and fix brakes. Work on getting engine to run well. Remove and disassemble oil filter housing to fix leak. | Gabe | 9 | 00 |
| 11-20-13 | Bleed and fix all brake lines and work on running condition. | Brian | 8 | 50 |
| 11-21-13 | Work on oil filter and timing. | Brian | 4 | 00 |
| 11-21-13 | Fit and install both rear splash shields. Work on oil filter housing and install. Install hub caps. | Gabe | 6 | 00 |
| 11-22-13 | Fit and install spare tire holder. Make grommets and bushings. Make and install battery cable. Hook up starter switch. Clean and install accelerator pedal. Work on engine idling. | Gabe | 8 | 00 |
| 11-27-13 | Go to Joe Smiths and work on covering holes in floor pans. | Gabe | 2 | 00 |
| 12-3-13 | Clean and paint sun visor hardware. Repair wood mounting blocks for sun visors then went to Joe Smiths to install. | Gabe | 3 | 00 |
| 12-10-13 | Go to Joe Smiths and work on sill plates. | Jim | | 50 |
| 12-16-13 | Pick up truck at Joe Smiths. | Gary | 2 | 00 |
| 12-18-13 | Polishing stainless steel hardware. | Tom | 1 | 00 |
| 12-19-13 | Pick up tailgate chain and links. | Tom | | 50 |
| 12-20-13 | Glue down wood in bed. | Tom | 1 | 00 |
| 12-26-13 | Modify and paint tailgate chains. Blast and paint hardware for | | | |

**D & D CLASSIC AUTO
2300 MOTE DR
COVINGTON OH 45318
937-473-2229**

**SAM PETERS
10001 ALLIANCE RD
CINCINNATI OH 45242**

WO#: 22507

**1937 STUDEBAKER P/U
513-702-7877**

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|---|--------------------------------|-------------------|---------------------------------|--------------------|-------------------|
| | SHOP MATERIAL | \$55.20 | | HAZ. WASTE REMOVAL | \$10.00 |
| | MISC. HARDWARE | \$57.00 | | SHIPPING CHARGES | \$25.33 |
| 1 SET | 64-15362 EXH BRACKETS/CLAMPS | \$56.54 | | HEMMS GLASS | \$86.19 |
| 1 | 196673 CUP | \$5.85 | | | |
| 1 | 189393 T.PIPE STRAP | \$8.45 | | | |
| 2 | 51A17528 WIPER BLADES | \$14.30 | | | |
| 2 | 48-70356A MOLDING CLIPS | \$13.00 | | | |
| 1 | 40-13740 DASH TOGGLE SWITCH | \$19.50 | | | |
| 1' | 8541K32 BLACK NYLON ROD | \$28.76 | | | |
| 1 | 462SK61 PULL LEVER GLOBE VAVLE | \$82.32 | | | |
| 1 | 4916K2 SOLENOID CONTR. VALVE | \$51.77 | | | |
| 1 | 5153K33 TUBE FITTINGS | \$18.94 | | | |
| PARTS TOTAL | | \$411.63 | SUBLET TOTAL | | \$121.52 |
| 34.50 | \$40.00 | \$1,380.00 | LABOR TOTAL | | \$1,380.00 |
| LABOR TOTAL | | | LABOR TOTAL | | \$1,380.00 |
| 34.50 | HR AT \$40.00 PER HR | \$1,380.00 | PARTS TOTAL | | \$411.63 |
| | | | SUBLET TOTAL | | \$121.52 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 3-7-14 | SUBTOTAL | | \$1,913.15 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$2,042.29 | TAX - HAMILTON CO. 6.75% | | \$129.14 |
| | | | BALANCE DUE: | | \$2,042.29 |

WE ACCEPT M/CARD, VISA & DISCOVER

****THIS INVOICE IS FOR ACCOUNTING PURPOSES****

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22507

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 1

| DATE | DESCRIPTION | BY | TIME WORKED | |
|----------|--|------|-------------|-----|
| | | | HRS | MIN |
| 12-31-13 | Install trim on hoodsides. | Tom | 1 | 50 |
| 1-6-14 | Shim and adjust front clip and shim core support. Adjust hood. | Tom | 4 | 00 |
| 1-8-14 | Check chassis and component fasteners. Fabricate tailpipe and muffler hangers. | Tom | 4 | 00 |
| 1-13-14 | Installing windshield. | Tom | | 50 |
| 2-6-14 | Remove and metal finish sill plates. | Jim | 1 | 50 |
| 2-6-14 | Finish up windshield and interior trim. | Tom | 2 | 50 |
| 2-7-14 | Fit, hammer, metal finish and install sill plates. | Jim | 6 | 50 |
| 2-21-14 | Locate and order grill badge. | Tom | 1 | 00 |
| 2-27-14 | Install grill badge. Locate and order whistle valve for wig-wag taillight. | Tom | 1 | 00 |
| 3-4-14 | Research and locate electrical solenoid for wig-wag. | Tom | 1 | 00 |
| 3-5-14 | Install solenoid. Run vacuum line to solenoid. Remove wig-wag and disassemble for repair. | Tom | 4 | 00 |
| 3-6-14 | Work on rear taillights. | Rick | 2 | 00 |
| 3-6-14 | Repair wig-wag. | Tom | 5 | 00 |

TOTAL 34/50

D & D CLASSIC AUTO
 2300 MOTE DR
 COVINGTON OH 45318
 937-473-2229

SAM PETERS
 10001 ALLIANCE RD
 CINCINNATI OH 45242

WO#: 22623

1937 STUDEBAKER P/U
 513-702-7877

CUST# 727

| QTY | PARTS ITEM | AMOUNT | QTY | SUBLET LABOR | AMOUNT |
|--|--|------------|-------------------------|--------------------|------------|
| | SHOP MATERIAL | \$149.60 | | HAZ. WASTE REMOVAL | \$15.00 |
| 1 | 555-63010 VACUUM RESERVIOR CANISTER | \$55.63 | | | |
| 1 | 271463780782 DOOR LOCK | \$32.50 | | | |
| 1 | 782-1070 SPE-4 FUSE | \$4.48 | | | |
| PARTS TOTAL | | \$242.21 | SUBLET TOTAL | | \$15.00 |
| 93.50 | \$40.00 | \$3,740.00 | LABOR TOTAL | | \$3,740.00 |
| LABOR TOTAL | | | PARTS TOTAL | | \$242.21 |
| 93.50 | HR AT \$40.00 PER HR | \$3,740.00 | SUBLET TOTAL | | \$15.00 |
| ** THIS BILLING BRINGS YOU UP TO DATE AS OF: | | 6-23-14 | SUBTOTAL | | \$3,997.21 |
| ** BALANCE DUE UPON RECEIPT IS: | | \$4,257.03 | TAX - HAMILTON CO. 6.5% | | \$259.82 |
| | | | BALANCE DUE: | | \$4,257.03 |

WE ACCEPT M/CARD, VISA & DISCOVER

THIS INVOICE IS FOR ACCOUNTING PURPOSES

D & D CLASSIC AUTO DAILY LABOR LOG

NAME: SAM PETERS

WO: 22623

VEHICLE: 1937 STUDEBAKER P/U

C. NUM: 727

SERIAL: _____

PAGE: 1

| DATE | DESCRIPTION | BY | TIME WORKED | |
|---------|--|--------|-------------|-----|
| | | | HRS | MIN |
| 3-10-14 | Drill and tap hardware for vacuum line for wig-wag. | Tom | 1 | 00 |
| 3-25-14 | Wig-wag taillight. | Rick | 2 | 00 |
| 3-25-14 | Install vacuum tank for wig-wag - still not enough vacuum, remove wig-wag for disassembly. | Tom | 4 | 00 |
| 3-28-14 | Disassemble wig-wag. Make new leathers for vacuum motor. | Tom | 4 | 00 |
| 3-31-14 | Install new leather and reassemble wig-wag - still not working. | Tom | 4 | 00 |
| 4-23-14 | Start to install wiper arms on passenger side - needs spindle wheel assembly rebuilt. | Tom D. | 3 | 00 |
| 4-23-14 | Work on wiper arms and posts. | Gabe | 1 | 00 |
| 4-24-14 | Rebuilding passenger side wiper assembly. | Tom D. | 3 | 00 |
| 4-24-14 | Repair windshield wiper bracket. | Jim | 1 | 00 |
| 4-24-14 | Prepare, catalog and photograph parts for plating. | DJ | | 50 |
| 4-25-14 | Take plating to Brightworks. | DJ | | 50 |
| 4-29-14 | Paint u-bolts and bracket. | Andrew | | 50 |
| 4-29-14 | Fabricate, prepare and prime air cleaner support bracket. | Tom | 6 | 00 |
| 4-30-14 | Paint work on truck. | Andrew | | 50 |
| 5-2-14 | Paint work on truck. | Andrew | 1 | 50 |
| 5-2-14 | Pick up plating at Brightworks. | DJ | | 50 |
| 5-5-14 | Assemble wiper arm transmission tower. Install tower and wiper arm. | | | |
| | Reinstall glove box. | Tom D. | 4 | 00 |
| 5-5-14 | Paint work on truck. | Andrew | 1 | 00 |
| 5-6-14 | Clean inside and vacuum. | DJ | 1 | 50 |
| 5-6-14 | Work on running condition. | Brian | 2 | 50 |
| 5-6-14 | Time tune and check for running and operating problems. | Gabe | 2 | 50 |
| 5-7-14 | Cleaning interior and body. | DJ | 1 | 50 |
| 5-9-14 | Detail on body and interior. | DJ | 6 | 00 |
| 5-19-14 | Work on speedometer and fuel gauge (not working). | Gabe | 4 | 00 |
| 5-19-14 | Work on speedometer and fuel gauge. | Brian | 3 | 50 |
| 5-20-14 | Paint work on truck. | Andrew | 2 | 00 |
| 5-21-14 | Paint work on truck. | Andrew | 1 | 50 |
| 5-28-14 | Work on fuel gauge and charging system. | Brian | 3 | 00 |
| 5-28-14 | Work on fuel gauge and sending unit. | Gabe | 1 | 50 |
| 6-2-14 | Remove and disassemble wig-wag taillights. | Gabe | 1 | 00 |
| 6-2-14 | Work on wipers and oil pressure. | Brian | 7 | 50 |



Invoice

Date 6/6/2013

Invoice # 5569

937.773.5127 • ryan@brightwk.com
1708 Commerce Drive • Piqua, OH 45356

Bill To:

Sam Peters
10001 Alliance Rd
Cincinnati, OH 45242

Ship To:

D&D Classic Auto Restoration
2300 Mote Dr
Covington, OH 45318

| Quantity | Description | Rate | Amount |
|---|---|----------------------|-------------------|
| 25 | LABOR/HOURLY | 60.00 | 1,500.00T |
| | SHOP MATERIAL | 12.00% | 180.00T |
| | HAZARDOUS WASTE (2.00 MIN. CHARGE) | 2.00% | 30.00T |
| | ITEM 14 IGNITION SWITCH BEZEL | | |
| | ITEM 15, 16 LIGHT SWITCH BEZEL & KNOB | | |
| | ITEM 17 HEADER BOX KNOB | | |
| | ITEM 22 ASHTRAY KNOB | | |
| | ITEM 23 WIPER KNOB | | |
| | ITEM 25 DOME LIGHT | | |
| | ITEM 27 THRU 30 VISOR ARMS & BASES | | |
| | ITEM 33, 34 LEFT INSIDE DOOR HANDLE & ESCUTCHEON | | |
| | ITEM 35, 36 LEFT WINDOW CRANK HANDLE & ESCUTCHEON | | |
| | ITEM 37, 38 RIGHT INSIDE DOOR HANDLE & ESCUTCHEON | | |
| | ITEM 39, 40 RIGHT SIDE WINDOW CRANK HANDLE & ESCUTCHEON | | |
| | ITEM 44, 45 CHOKE & THROTTLE CABLES | | |
| | ITEM 46 GLOVE BOX LOCK HOUSING | | |
| | ITEM 66 HORN BUTTON RING | | |
| | TOTAL PARTS AND/OR SETS - 23 | | |
| <p><i>Paid</i> <i>7/2/13</i> <i>Ch # 2345</i></p> | | | |
| | | Sales Tax ... | \$115.43 |
| | | Total | \$1,825.43 |

4522.00

"passion for restoring brightwork for the world's finest rolling art"

Make checks payable to Bright Works.
Visa, Mastercard, and Discover Card are accepted.
Thank you for your business--we appreciate it very much!

Any items left in-house at Bright Works with an invoice balance unpaid after 90 days will become the property of Bright Works.

Payments/Credits \$0.00
Balance Due Upon Receipt \$1,825.43

Visit our website at www.brightworkrestoration.com



Invoice

Date 6/19/2013

Invoice # 5588

937.773.5127 • ryan@brightwk.com
1708 Commerce Drive • Piqua, OH 45356

Bill To:

Sam Peters
10001 Alliance Rd
Cincinnati, OH 45242

Ship To:

D&D Classic Auto Restoration
2300 Mote Dr
Covington, OH 45318

| Customer Phone | | Customer Fax | | Project | |
|---------------------|---|--------------------------|--------------------------------|---------------------|--|
| 513-702-7877 (Cell) | | | | DD727/37 STUDEBAKER | |
| Quantity | Description | Rate | Amount | | |
| 22 | LABOR/HOURLY SHOP MATERIAL HAZARDOUS WASTE (2.00 MIN. CHARGE) | 60.00 12.00% 2.00% | 1,320.00T 158.40T 26.40T | | |
| | ITEM 10 THRU 13 WIPER BEZELS & NUTS ITEM 31 HOOD ORNAMENT BASE ITEM 41, 42 WIPER ARM PIVOTS ITEM 61 SPARE TIRE MOUNT ROD ITEM 62 SPARE TIRE MOUNT HOLD DOWN ITEM 63 SPARE TIRE MOUNT WING NUT ITEM 64 SPARE TIRE MOUNT TOP SUPPORT ITEM 65 SPARE TIRE MOUNT BOTTOM SUPPORT | | | | |
| | TOTAL PARTS AND/OR SETS - 12 | | | | |
| | | Sales Tax ... | \$101.57 | | |

yellow

"passionately restoring brightwork for the world's finest rolling art"

*Paid
7/2/13
CH 2345*

Make checks payable to Bright Works.
Visa, Mastercard, and Discover Card are accepted.
Thank you for your business--we appreciate it very much!

Total \$1,606.37

Any items left in-house at Bright Works with an invoice balance unpaid after 90 days will become the property of Bright Works.

Payments/Credits \$0.00

Balance Due Upon Receipt \$1,606.37

Visit our website at www.brightworkrestoration.com



Invoice

Date 8/26/2013

Invoice # 5676

937.773.5127 • ryan@brightwk.com
1708 Commerce Drive • Piqua, OH 45356

Bill To:

Sam Peters
10001 Alliance Rd
Cincinnati, OH 45242

Ship To:

D&D Classic Auto Restoration
2300 Mote Dr
Covington, OH 45318

| Customer Phone | | Customer Fax | | Project | |
|---------------------|---|--------------------------|-----------------------------|----------------|--|
| 513-702-7877 (Cell) | | | | '37 STUDEBAKER | |
| Quantity | Description | Rate | Amount | | |
| 12 | LABOR/HOURLY SHOP MATERIAL HAZARDOUS WASTE (2.00 MIN. CHARGE) | 60.00 12.00% 2.00% | 720.00T 86.40T 14.40T | | |
| | ITEM 1, 2 HEAD LIGHT REFLECTORS - SILVER ITEM 24 GLOVE BOX EMBLEM ITEM 32 HOOD ORNAMENT ITEM 54 RIGHT TAIL LIGHT COVER ITEM 55, 56 RIGHT TAIL LIGHT HOUSING ASSEMBLY ITEM 57 THRU 60 RIGHT TAIL LIGHT SWING ARM, TOP COVER, CAGE, & BOTTOM COVER ITEM 71, 72 DOME LIGHT & RETAINER RING TOTAL PARTS AND/OR SETS - 13 | | | | |
| | | Sales Tax ... | \$55.40 | | |
| | | Total | \$876.20 | | |

"passionately restoring brightwork for the world's finest rolling art"

*Paid 9/9/13
CL # 2404
\$ 876.20*

**Make checks payable to Bright Works.
Visa, Mastercard, and Discover Card are accepted.
Thank you for your business--we appreciate it very much!**

Any items left in-house at Bright Works with an invoice balance unpaid after 90 days will become the property of Bright Works.

Payments/Credits \$0.00
Balance Due Upon Receipt \$876.20

Visit our website at www.brightworkrestoration.com



Invoice

Date 9/25/2013

Invoice # 5704

937.773.5127 • ryan@brightwk.com
1708 Commerce Drive • Piqua, OH 45356

Bill To:

Sam Peters
10001 Alliance Rd
Cincinnati, OH 45242

Ship To:

D&D Classic Auto Restoration
2300 Mote Dr
Covington, OH 45318

| Quantity | Description | Rate | Amount |
|---|---|--------------------------|--------------------------------|
| 32 | LABOR/HOURLY SHOP MATERIAL HAZARDOUS WASTE (2.00 MIN. CHARGE) | 60.00 12.00% 2.00% | 1,920.00T 230.40T 38.40T |
| THE ITEMS LISTED BELOW WERE PICKED UP BY D & D AUTO RESTORATION ON 08/27/2013 | | | |
| ITEM 3 FRONT BUMPER ITEM 4, 5 FRONT BUMPER GUARDS ITEM 6 REAR BUMPER ITEM 7, 8 REAR BUMPER GUARDS ITEM 47 LEFT TAIL LIGHT COVER ITEM 48, 49 LEFT TAIL LIGHT HOUSING ASSEMBLY ITEM 50 THRU 53 LEFT TAIL LIGHT SWING ARM, TOP COVER, CAGE, & BOTTOM COVER | | | |
| TOTAL PARTS AND/OR SETS PICKED UP COMPLETED - 13 | | | |
| | | Sales Tax ... | \$153.22 |
| | | Total | \$2,342.02 |

"passionately restoring brightwork for the world's finest rolling art"

*Paid 9/30/13
ch# 2428*

Make checks payable to Bright Works.
Visa, Mastercard, and Discover Card are accepted.
Thank you for your business--we appreciate it very much!

Any items left in-house at Bright Works with an invoice balance unpaid after 90 days will become the property of Bright Works.

Payments/Credits \$0.00
Balance Due Upon Receipt \$2,342.02

Visit our website at www.brightworkrestoration.com



Invoice

Date 10/21/2013

Invoice # 5742

937.773.5127 • ryan@brightwk.com
1708 Commerce Drive • Piqua, OH 45356

Bill To:

Sam Peters
10001 Alliance Rd
Cincinnati, OH 45242

Ship To:

D&D Classic Auto Restoration
2300 Mote Dr
Covington, OH 45318

| Quantity | Description | Rate | Amount |
|--|---|--------------------------|--------------------------------|
| 56 | LABOR/HOURLY SHOP MATERIAL HAZARDOUS WASTE (2.00 MIN. CHARGE) | 60.00 12.00% 2.00% | 3,360.00T 403.20T 67.20T |
| | ITEM 18 THRU 21 HEATER BOX TOP & BOTTOM DOOR TRIM & KNOBS ITEM 26 DASH TRIM ITEM 43 HOOD TRIM ITEM 66 THRU 70 HUB CAPS ITEM 73 THRU 76 VENT WINDOW FRAMES W/ LEVERS | | |
| | TOTAL PARTS AND/OR SETS BEING INVOICED FOR THE CONCLUSION OF THIS PROJECT - 15 | | |
| <p><i>"passionately restoring brightwork for the world's finest rolling art"</i></p> <p><i>Paid 10/23/13 C# 2449 \$4098.53</i></p> | | | |
| | Sales Tax ... | | \$268.13 |
| | Total | | \$4,098.53 |

Make checks payable to Bright Works.
Visa, Mastercard, and Discover Card are accepted.
Thank you for your business--we appreciate it very much!

Any items left in-house at Bright Works with an invoice balance unpaid after 90 days will become the property of Bright Works.

Payments/Credits \$0.00
Balance Due Upon Receipt \$4,098.53

Visit our website at www.brightworkrestoration.com