

A step-by-step guide on how to correctly assemble the mudguard to the bike.

1. Start by loosening the nuts using a wrench and remove the washers from the screw that is connected to the brake cable.



2. Assemble the mudguard between the front fork and the frame, ensuring that the holes on the mudguard align with the hole on the front fork.



3. Insert the bolt through the hole in the mudguard and then through the hole in the front fork. Reattach the washers you removed in step 1.



4. Screw the nuts back on and tighten them securely using a wrench. Make sure the mudguard is firmly in place and that no parts are loose.

