




OPERATING INSTRUCTIONS SPACEMAKER15/25 HOSE



SPACEMAKER15



SPACEMAKER25



- 1.) PLACE CUFF WITH TIGHTENING STRAP ON OUTLET OF BLOWER.
- 2.) BLOWER SHOULD BE PLACED 5 FEET, UPWIND, FROM ENTRY.
- 3.) UNSUPPORTED DUCT SHOULD BE LOCATED AT SADDLE OR ANY PLACE WHERE ENTRY OR EGRESS SPACE IS RESTRICTED.