



motorola

QUICK START GUIDE

For a full explanation of all features and instructions, please refer to the User's Guide.

1. Setting up your Digital Video Baby Monitor

MODELS:


MBP621

MBP621-2

MBP621-3


MBP621-4

A. Baby unit power supply



1. Insert the DC plug of the power adapter with the smaller DC plug into the DC jack on the side of the baby unit, as shown.
2. Connect the other end of the power adapter to a suitable mains power socket.


B. Parent unit battery installation and power supply



A rechargeable battery pack is supplied and should be fitted, so that the parent unit can be carried to another location without losing the link and picture from the baby unit(s). Charge the parent unit before using it for the first time or when the parent unit indicates that battery is low.

1. Remove the belt clip/stand if it is attached to the parent unit.
2. Slide off the battery compartment cover.
3. Insert the plug of the rechargeable battery pack into the jack inside the battery compartment, and fit the battery pack into the compartment.
4. Slide the battery compartment cover back until it clicks into place, and re-attach the belt clip/stand.
5. Insert the DC plug of the power adapter with the bigger DC plug into the DC jack on the side of the parent unit.
6. Connect the other end of the power adapter to a suitable mains power socket.
7. The battery level indicator comes on.

C. Belt clip/stand on parent unit



Belt clip position Desktop position

1. The belt clip/stand attaches to the back of the parent unit and clips into the locking slots on each side.

NOTE

It will only fit one way, as indicated by UP and the arrows on the inner side of the clip.





















2. The unit comes with the accessory fitted in the belt clip position.
3. You can convert it into the desktop position by simply pulling the back part of the clip out slightly and then rotating it by half a turn, as shown in the diagram on the left.



WARNING:

Strangulation Hazard. Children have STRANGLED in cords. Keep this cord out of the reach of children (more than 3ft (1m) away). Never use extension cords with AC Adapters. Only use the AC Adapters provided.

2. Basic explanation of the display icons

| Parent Unit | | |
|---|----------------------------|---|
|  | Connection status | <p> displays when strong signal strength is detected between the baby unit and the parent unit.</p> <p>,  or  displays when moderate signal strength is detected between the baby unit and the parent unit.</p> <p> displays when the link between the baby unit and the parent unit is lost.</p> <p> displays when the parent unit is searching for a baby unit.</p> |
|  | Current view status | Displays the number of the baby unit that is being viewed. |
|  | Zoom | Displays when the camera on the baby unit is zoomed in. |
|  | Volume off | Displays when the volume is turned off. |
|  | Sound activation | <p>- You can turn Sound activation function ON or OFF. To check on your baby whenever there is sound in the baby's room, please turn it ON.</p> <p>- Displays when sound activation is ON. When the baby unit detects a sound in the baby's room, the video image of the baby will be displayed on the parent unit.</p> |
| 16°C | Current temperature | Displays the current room temperature of the selected baby unit. |
|  | Battery status | <p> scrolls when the battery is charging;  displays when the battery is fully charged;  displays when the battery is low and needs charging;  displays when you do not have a battery installed but operates using AC power, or the battery has been installed incorrectly.</p> |
|  | Camera selection | You can select the baby unit you want to view, or view all baby units in Scan Mode. |
|  | Brightness | You can change the brightness of the screen. |
|  | Sensitivity | You can change the sound sensitivity level of the baby unit. The higher the sound sensitivity level, the more sensitive the baby unit is in detecting sounds and transmitting them to the parent unit. |
|  | Pairing | The system comes with baby unit(s) already paired with the parent unit. You can add or replace baby units. |

3. General Information

If your product is not working properly...

1. Read this Quick Start Guide or the User's Guide.
2. Visit our website: www.motorola.com
3. Contact Customer Service:

+44 (0) 844 557 0890 (UK only)

+44 (0) 8187 62092 (ROI)



Manufactured, distributed or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylised M Logo, are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. All other trademarks are the property of their respective owners.

© 2014 Motorola Mobility LLC. All rights reserved.



Printed in China
UK_EN Version 4.0