

Smart IP Controller 2.0

Quick Setup Guide

1 Introduction

Smart IP Controller is a mobile app designed for the daily control of zones in a Genelec Smart IP system. The app is quick to set up on any Apple iOS or Android phone or tablet and provides straightforward control of your installed loudspeakers, including volume adjustment, preset recall, and zone power.

The app free to download from:

- Apple App Store
- Google Play Store



The app automatically discovers zones configured in Smart IP Manager. If no zones have been set up, all loudspeakers appear as a single Default Zone and can be controlled together.

2 Network Connection

For the app to communicate with your loudspeakers, your phone or tablet must be connected by Wi-Fi to the same network as the Smart IP system.

Checking your Wi-Fi connection

- Open the settings of your mobile device.
- Navigate to the Wi-Fi section and confirm Wi-Fi is enabled.
- Check the network name, it must match the network your loudspeakers are installed on. If you are unsure, contact your system installer or IT administrator.

Once connected to the correct network, return to the app.

3


Adding Zones

After installing the app, configure it to control the zones you need. Zones are defined using Smart IP Manager, and the app can be set up to control one or several zones. Launch the app and follow the steps below.




1. Get Started

Press the Get Started button. The app will discover all zones created in Smart IP Manager, or the Default Zone if none have been configured.




2. Select a Zone

Tap the zone you want to add.



3. Confirm Connection

A confirmation window appears, tap Connect. If the loudspeakers use non-default login credentials, you will be prompted to enter them now.



4. Continue or Finish


The zone appears in the Saved Zones list. Add further zones, tap a saved zone to open it, or press Done to go to the main control page.

Editing Zones

Select any saved zone to access its settings. Three options are available:

4.1 Volume Limits


Set a minimum and maximum volume range for the zone. The range spans -130 dB to 0 dB, where 0 dB represents full output. Use this to prevent the volume exceeding an appropriate level for the space.



4.2 Zone Image


Assign an optional image to help identify the zone at a glance. Tap the edit button and choose from:

- A built-in default icon
- A photo taken with your device camera
- An image loaded from your device gallery



4.3 Delete Zone

View the loudspeakers assigned to the zone and remove it from the app if required. This does not affect the zone configuration in Smart IP Manager.



5 Controlling a Zone

Each zone is presented as a Zone View, displaying the zone name, the number of Smart IP loudspeakers in that zone, and all available controls. All controls act simultaneously on every loudspeaker within the zone.

Control Functions

Volume + / -

Raises or lowers the volume level for all loudspeakers in the zone.

Animated Bars

Indicates whether audio is actively playing in the zone.

Volume Fader

Slide left or right to adjust volume continuously.

Mute


Silences all loudspeakers without changing the volume setting.

Preset Recall

Loads a preset created in Smart IP Manager.

Power On / Off

Switches all loudspeakers in the zone on or off.



To add more zones or edit existing zone settings, tap the Settings icon in the top right corner of the main screen.

Factory & Headquarters

Genelec Oy
Olvitie 5
FI-74100 Iisalmi
Finland
T +358 17 83 881
genelec@genelec.com

China

Beijing Genelec Audio
Room 101, Building B33
Universal Business Park
No.10 Jiuxianqiao Road
Chaoyang District
Beijing 100015
China
T +86 10 5823 2014
T +86 400 700 1978
genelec.china@genelec.com

USA

Genelec Inc.
7 Tech Circle
Natick MA 01760
USA
T +1 508 652 0900
genelec.usa@genelec.com

Sweden

Genelec Sweden
Tureholmsvägen 12
125 35 Älvsjö
Sweden
T +46 8 449 5220
sweden@genelec.com

Japan

Genelec Japan Inc
2-22-21 Akasaka
Minato-ku
JP-107-0052 Tokyo
Japan
T +81 3 6441 0591
genelec.japan@genelec.com