


WATCH MANUAL

MICHAEL HILL
FINE JEWELLERS

ANALOGUE | 2 OR 3 HANDS, DATE

A. DISPLAY



*Date position may be located at different position depending on the model.
*Dial positions and layout of the face might vary depending on the watch model.

B. SETTING THE TIME

- 1 Pull the crown out to the 2nd position.
- 2 Turn the crown to set hour and minute hands.
- 3 Push the crown back to the normal position.

C. SETTING THE DATE

- 1 Pull the crown out to the 1st position.
- 2 Turn the crown to set the date.
*If the date is set between the hours of around 9:00 PM and 3:00 AM, the date may not change the following day.
- 3 After the date has been set, push the crown back to the normal position.

ANALOGUE | 2 OR 3 HANDS, DATE

D. WARNING



WARNING





**THIS PRODUCT
CONTAINS A
BUTTON BATTERY**

AUSTRALIA
Australian Poisons Information Centre
13 11 26

NEW ZEALAND
New Zealand Poisons Information Centre
0800 764 766

CANADA
Canada Poisons Information Centre
1 844 764 7669

Dispose of used button batteries immediately.

If swallowed or placed inside any part of the body, the battery can cause serious injuries. It can cause severe or fatal injuries within two hours or less. Button batteries are hazardous. Keep batteries out of reach of children. If you think the battery may have been swallowed or placed inside any part of the body, you should contact your local Poisons Information Centre immediately for 24/7 fast, expert advice.