


# WATCH MANUAL

MICHAEL HILL  
FINE JEWELLERS

# ANALOGUE | 2 OR 3 HANDS, DATE

## A. DISPLAY

---



\*Dial positions and layout of the face might vary depending on the watch model.

## B. SETTING THE TIME

---

- 1 Pull the crown out to the 1st position.
- 2 Turn the crown to set hour and minute hands.
- 3 Push the crown back to the normal position.

## C. WARNING

---

 **WARNING** 



**THIS PRODUCT CONTAINS A BUTTON BATTERY**

If swallowed or placed inside any part of the body, the battery can cause serious injuries. It can cause severe or fatal injuries within two hours or less. Button batteries are hazardous. Keep batteries out of reach of children. If you think the battery may have been swallowed or placed inside any part of the body, you should contact your local Poisons Information Centre immediately for 24/7 fast, expert advice.

**AUSTRALIA**  
Australian Poisons Information Centre  
13 11 26

**NEW ZEALAND**  
New Zealand Poisons Information Centre  
0800 764 766

**CANADA**  
Canada Poisons Information Centre  
1 844 764 7669

Dispose of used button batteries immediately.