





Quick Start Guide

Beo Grace


I. Download the Bang & Olufsen App




11. Open case to start Bluetooth pairing



III. Set up in the Bang & Olufsen App




IV. Insert earphones



Earphone controls




	Media	Calls
● Press	▶ Play/Pause	☎ Accept
●● Double press	> Next	☎ Reject/ End call
●●● Triple press	< Previous	☎ Reject/ End call
■ Press and hold	⚡ ANC/Transparency	
Take out one earphone	Quick listening mode	




NearTap™ for media and calls	
●●● Continuous taps R	+ Volume up
●●● Continuous taps L	- Volume down

Case controls




Lid open with both earphones inside		
 Press and hold (5 sec.)	Bluetooth pairing	Solid white when completed
 Press or press and hold	Stop Bluetooth pairing	
 Press and hold (15 sec.)	Factory reset	Solid orange when completed

USB-C and wireless charging



Box overview



For user guide, see:

Se betjeningsvejledning på:

Användarhandledning finns här:

Die Bedienungsanleitung finden Sie unter:

Voor de gebruikershandleiding, zie:

Pour accéder au manuel de l'utilisateur,
consultez le site:

Si desea descargar la guía de usuario, visite:

Per la guida utente, vedere:

Para aceder ao manual do utilizador, visite:

Uživatelskou příručku naleznete zde:

A használati útmutatót itt találja:

Pentru ghidul de utilizare, consultați:

ユーザーガイドは次のリンク先をご覧ください。:

사용 설명서는 에서 찾아볼 수 있습니다:

如要查看用户指南, 请访问:

如需使用指南:



on.beo.com/support or Bang & Olufsen app

Contact our support for help



on.beo.com/call

Global 24/7 English hotline

+44 20 39 36 14 83

