

QUICK GUIDE TO ACCESSIBILITY FEATURES

(for use with WOW! Accessible DVR or Mini)

SCREEN READER

- To turn on the screen reader, press and hold the A button - the left-most button in the line of buttons between the PAUSE circle and the number pad on your remote - or two seconds.

AUDIO DESCRIPTION

- To turn on Audio Description, press and hold the C button - the second from the right in the line of buttons between the PAUSE circle and the number pad on your remote.

CLOSED CAPTIONING

- To turn on closed captioning, press and hold the B button - the second from the left in the line of buttons between the PAUSE circle and the number pad on your remote.

For additional features and setup options, please see complete user guides.