


DUALCHEF 425G BZ

Aufbauanleitung | Assembly Instruction



OUTDOORCHEF
SWISS INNOVATION

Achtung

Bitte notieren Sie auf der Rückseite Ihrer Gebrauchsanweisung die Serien-Nummer. Je nach Grillmodell finden Sie die Nummer auf dem Datensticker, welcher sich entweder am Grillgestell oder auf der Bodenplatte befindet. **OUTDOORCHEF** kann Garantie und Ersatzteillieferungen nur mit der Serien-Nummer bearbeiten. Outdoorchef AG operates a policy of continuous product development and improvement. As such we reserve the right to alter product design and or technical specification without giving any prior notice.

Attention

Please write your serial number on the backside of the manual for future reference. You will find the number on the data plate attached to the trolley or the bottom plate depending on the grill model. **OUTDOORCHEF** can only supply spare parts and honour warranty returns when the serial number is available.

INHALTSVERZEICHNIS | TABLE OF CONTENTS


S. 4-5	Montagematerial Hardware Set
S. 6-26	Aufbauanleitung Assembly Instruction
S. 28-29	Sicherheitshinweis Safety Instruction
S. 30-39	Ersatzteile Spare Parts


Lesen Sie die separate Bedienungsanleitung sorgfältig durch, bevor Sie Ihren OUTDOOR**CHEF** Grill in Betrieb nehmen.


Please read the separate user manual carefully before using your OUTDOOR**CHEF** Barbeque.


DUALCHEF 425G BZ


18.379.51


M5 X 12.5 Hexagon step screw		
8x	xg	
18.371.34		

M5 X 12 Hexagon screw		
8x	xh	
18.371.35		

M6 X 16 Hexagon screw		
44x	xi	
18.371.36		

M4 X 10		
26x	xk	
18.371.37		


M6 X 12 Wing screw		
4x	xl	
18.371.39		


M5 X 12		
4x	xm	
18.371.40		

M6 Spring washer		
16x	(R)	
18.371.06		


M6 Washer		
16x	(b)	
18.370.61		


M5 Washer		
4x	(ak)	
18.371.38		


Lid protection pin		
2x	(al)	
18.371.41		


Door protection pin		
2x	(am)	
18.371.42		

Cable tree fixation clip		
3x	(an)	
18.371.43		


Tool for hexagon screw		
1x	(ao)	
18.371.44		

Side table stopper		
1x	(bg)	
18.760.25		

Wrench (S14 & S11)		
1x	(aq)	
18.371.47		

Wrench (S19 & S17)		
2x	(ap)	
18.371.46		

Crosshead screwdriver B (85mm)		
1x	(as)	
18.371.49		


Crosshead screwdriver A (201mm)		
1x	(ar)	
18.371.48		

NON rechargeable battery 1.5V (AAA)		
2x		



Rechargeable battery 2400 mAh (AA)		
4x		

DUALCHEF 425G BZ

1.
- | | | | | | | | |
|------------|-----|---|-------------|------------|-----|---|-------------|
| xi | 16× |  | (18.371.36) | (R) | 16× |  | (18.371.06) |
| (b) | 16× |  | (18.370.61) | | | | |



2.




3.
- xi



3 ×



(18.371.36)



4.




5.

xi

10×




(18.371.36)



6.

xh 4 ×  (18.371.35) **xm** 4 ×  (18.371.40)




7.
- xi

4 ×




(18.371.36)



8.

xi 6 ×  (18.371.36)







DUALCHEF 425G BZ

9.

xl




4 × 

(18.371.39)





xl

10.





11.

xh 4 ×  (18.371.35)	ak 4 ×  (18.371.38)
xk 10 ×  (18.371.37)	




12.

xk 16X  (18.371.37)




13.
- xg



4 ×




(18.371.34)





14.




15.




16.





17.




18.




19.



20.




21.




TO TAKE NOTES:


22.



23.



DUALCHEF 425G BZ





SPAREPARTS			ERSATZTEIL-LISTE
Pos.	Art. Nr.	Description	Beschreibung
1	18.720.01	Lid, black	Deckel, schwarz
2	18.770.03	Lid handle tube	Deckelgriff
3	18.710.05	Heat indicator °C/°F - DGS®, complete	Temperatur Anzeiger °C/°F - DGS®, Komplett
4	18.740.00	Lid Protection pin set 4pcs.	Deckel Schutzstift Set 4 Stk.
5	18.710.07	Warming grid	Warmhalterost
6	18.710.00	Cooking grid small	Grillrost klein
7	18.710.01	Cooking grid big	Grillrost gross
8	18.790.00	Grid lifter	Grillrostheber
9	18.710.03	DGS® Zone Divider	DGS® Zone Divider
10	18.710.04	DGS® Heat Diffuser	DGS® Heat Diffuser
11	18.710.02	DGS® Protection Bars	DGS® Protection Bars
12	18.730.10	DGS® Twin Burner	DGS® Twin Burner
13	18.730.09	Burner fixation	Brennerbefestigung
14	18.720.05	BBQ Base	Grill Gehäuse
15	18.730.29	Control panel, 425 G / 30mbar	Bedienungskonsole 425 G / 30mbar
15	18.730.30	Control panel, 425 G / 50mbar	Bedienungskonsole 425 G / 50mbar
16	18.740.02	Control Knob	Gasregulierknopf
17	18.730.19	Piezo electrode	Piezo-Elektrode
18	18.750.00	Side table, right	Seitentablar, rechts
19	18.750.09	Blazing table, complete / 30/50mbar	Blazingbrennertablar, komplett / 30/50mbar
20	18.750.10	Blazing Burner + Base / 30/50mbar	Blazing Brenner + Gehäuse/ 30/50mbar
21	18.750.05	Side burner lid	Seitenbrennerdeckel
22	18.740.06	Control knob including stopper	Gasregulierknopf mit Stopper
23	18.710.18	Cooking Grid stainless steel	Grillrost Edelstahl
24	18.710.15	Grid Stair right	Höhenverstellung Grillrost rechts
25	18.710.17	Grid Stair left	Höhenverstellung Grillrost links
26	18.710.16	Drip pan	Fettauffangschale
27	18.730.43	Electrode	Elektrode
28	18.730.16	Puls ignition (5 outputs)	"Elektrozündung (5 Ausgänge) "
29	18.730.33	Ignition wire (B1 & B2 & SB)	Zündkabel (B1 & B2 & SB)
30	18.730.34	Ignition wire (B3 + B4)	Zündkabel (B3 + B4)
31	18.710.09	Collection sheet	Fettauffang-Blech
32	18.710.10	Drip pan	Fettauffangschale
33	18.710.12	Drip pan handle	Fettauffangschalengriff
34	18.760.00	Cabinet sheet left	Kastenwand links
35	18.760.01	Cabinet sheet right 4B	Kastenwand rechts 4B
36	18.760.05	Rear cabinet sheet 4B	Hintere Kastenwand 4B
37	18.760.09	Bottom sheet S 425 G	Bodenplatte S 425 G
38	18.322.29	Bottle jacket	Flaschenschale
39	18.760.24	Bottle fixation	Flaschenhalterung

DUALCHEF 425G BZ

SPAREPARTS			ERSATZTEIL-LISTE
Pos.	Art. Nr.	Description	Beschreibung
40	18.760.11	Front bar	Frontbügel
41	18.760.14	Door left, black	Türe links, schwarz
42	18.760.16	Door right, black	Türe rechts, schwarz
43	18.770.02	Doorhinge	Türscharnier
44	18.770.05	Doorhandle	Türgriff
45	18.760.20	Accessories box 4B	Zubehörkasten 4B
46	18.760.22	Dividing wall Accessories	Trennwand Zubehör
47	18.740.05	Door protection pin set 2 pcs.	Türen Schutzstift Set 2 Stk
48	18.770.00	Caster	Lenkrolle
49	18.770.01	Caster with brake	Lenkrolle mit Bremse
50	18.780.00	Electronic box	Elektronikbox
51	18.780.01	Transformer	Transformator
52	18.780.03	Power cable E+F (EU) plug	Stromkabel E+F (EU) Stecker
53	18.780.05	Power cable J (CH) plug	Stromkabel J (CH) Stecker
54	18.740.04	Cable fixing clips	Kabelbefestigungsclips
55	18.360.14	Bottle strap	Flaschengurt
56	18.710.13	Cabinet cover	Kastenabdeckung
57	18.750.08	Side tabel support I&r	Seitentablarhalterung I&r
58	14.911.62	Adapter 5/8"UNF- 1/4"LH	Adapter 5/8"UNF - 1/4"LH
59	18.760.26	Tool holder	Werkzeughalter
60	18.379.51	Hardware set	Schraubenset
61	14.911.38	Gas hose & regulator CH	Gasschlauch & Regler CH
61	14.911.40	Gas hose & regulator DE,AT	Gasschlauch & Regler DE,AT
61	14.911.42	Gas hose & regulator DK,FI,IS,NO,PT,SP	Gasschlauch & Regler DK,FI,IS,NO,PT,SP
61	14.911.51	Gas hose & regulator IT, GR	Gasschlauch & Regler IT,GR
61	14.911.47	Gas hose & regulator BG	Gasschlauch & Regler BG
61	14.911.43	Gas hose & regulator GB	Gasschlauch & Regler GB
61	14.911.58	Gas hose & regulator HU	Gasschlauch & Regler HU
61	14.911.56	Gas hose & regulator MT	Gasschlauch & Regler MT
61	14.911.49	Gas hose & regulator PL	Gasschlauch & Regler PL
61	14.911.47	Gas hose & regulator SE	Gasschlauch & Regler SE
61	14.911.53	Gas hose & regulator AL,BA,HR,CZ,IL,LT,MK,MD,RO,RS,SK,SI	Gasschlauch & Regler AL,BA,HR,CZ,IL,LT,MK,MD,RO,RS,SK,SI
62	14.921.25	Gas hose FR	Gasschlauch FR



A



A		LID HINGE	DECKELSCHARNIER
Pos.	Art. Nr.	Description	Beschreibung
A1	18.371.45	M8 x 15 Lid axle	M8 x 15 Deckelachse
A2	18.371.50	Lid axle washer	Deckelachsen-Scheibe
A3	18.371.51	M8 washer	M8 x 15 Deckelachse U-Scheibe
A4	18.371.52	M8 Lock nut	M8 Stop-Schraube


DUALCHEF 425G BZ

B



B		LID HANDLE	DECKELGRIFF
Pos.	Art. Nr.	Description	Beschreibung
B1	18.371.53	Protection washer lid handle	Schutz-Unterlagscheibe Deckelgriff
B2	18.371.54	Hexagon screw	Inbusschraube
B3	18.371.55	Lid lining cover	Abdeckung
B4	18.371.56	Screw	Schraube



C




C	IGNITOR SIDE TABLE		SEITENBRENNER-ZÜNDER
Pos.	Art. Nr.	Description	Beschreibung
C1	18.371.58	M4 Screw	M4 Schraube
C2	18.371.03	Protection Waher	Schutz-Unterlagscheibe
C3	18.371.57	M4 Washer	M4 Unterlagsscheibe
C4	18.371.04	M4 Spring washer	M4 Federring
C5	18.370.48	M4 Nut	M4 Mutter

DUALCHEF 425G BZ

D




D		E-BOX AND IGNITION	E-BOX UND ZÜNDUNGSBOX
Pos.	Art. Nr.	Description	Beschreibung
D1	18.371.59	Screw	Schraube
D2	18.371.58	M4 Screw	M4 Schraube




E1		BACK PLUG	STROMSTECKER
Pos.	Art. Nr.	Description	Beschreibung
E1	18.371.60	Screw	Schraube
E2	18.371.58	Screw	Schraube

F



F	GRID STAIR		HÖHENVERSTELLUNG GRILLROST
Pos.	Art. Nr.	Description	Beschreibung
F1	18.371.89	M4 Screw	M4 Schraube

G



G1		BURNER	BRENNER
Pos.	Art. Nr.	Description	Beschreibung
G1	18.371.58	M4 Screw	M4 Schraube



Outdoorchef AG | Eggbühlstrasse 28 | Postfach | 8050 Zürich | Switzerland
Outdoorchef Benelux B.V. | Databankweg 26 | 3821 AL Amersfoort | The Netherlands
Outdoorchef Austria GmbH | Handelskai 94-96 / 23rd & 24th F | 1200 Vienna | Austria
Outdoorchef Deutschland GmbH | Ochsenmattstr. 10 | 79618 Rheinfelden | Germany