

How to Remove and Reposition a Smart Plug Appliance

Description

This page shows how to remove and reposition a Smart Plug Appliance. The Appliance Smart Plug will have a 3 prong plug in. It can be used with any appliance that can be powered off.



Please read through the directions in its entirety before commencing.

Instructional Video Link

This Video link illustrates how to re-install the Smart Plug

<https://www.youtube.com/watch?v=fGvPEmiltg4>

Removal of a Smart Plug

1. As soon as the Smart Plug has been unplugged from ac power, it will be immediately disconnected.

Important Considerations When Repositioning a Smart Plug

1. A Smart Plug can be added to your Smart Home Mesh Network
2. Your Smart Home Mesh Network may also include electrically or battery powered devices such as smart light bulbs, smart plugs, smart thermostats, smart door locks which also repeat the signal and communicate with other devices

Repositioning of a Smart Plug

1. Place the Smart Plug into an electrical outlet
2. Log into your TELUS Smart Home App
3. Click on the menu button on the top left corner
4. Select Add Device
5. Select Lighting and Appliance Control
6. Select Go Control Plug-In for Appliances with Night Light
7. Select Begin Installation
8. Select Continue
9. Follow the on Screen instructions to complete your set up
10. Trigger the Plug by pressing the button on the device twice
11. Name your Device
12. Your Plug-In should now be added