

How to Remove and Reposition a Smart Light Dimmer

Description

This page shows how to remove and reposition a Smart Plug Light Dimmer. The Smart Plug will have 2, 2 prong plug-ins. Can be used with any light that can be powered off.



Please read through the directions in its entirety before commencing.

Instructional Video Link

This Support page and Video illustrate how to re-install the Smart Plug

[TELUS | How to install your Smart Plug - Dimmer](#)

Removal of a Smart Plug Dimmer Switch

1. As soon as the Smart Plug has been unplugged from ac power, it will be immediately disconnected.

Important Considerations When Repositioning a Smart Plug Dimmer Switch

1. A Smart Plug will be added to your Smart Home Mesh Network

2. Your Smart Home Mesh Network may also include electrically or battery powered devices such as smart light bulbs, smart plugs, smart thermostats, smart door locks which also repeat the signal and communicate with other devices

Repositioning of a Smart Plug Dimmer Switch

1. Place the Smart Plug into an electrical outlet
2. Log into your TELUS Smart Home App
3. Click on the menu button on the top left corner
4. Select Add Device
5. Select Lighting and Appliance Control
6. Select Go Control Plug-In for Appliances with Night Light
7. Select Begin Installation
8. Select Continue
9. Follow the on Screen instructions to complete your set up
10. Trigger the Plug by pressing the button on the device twice
11. Name your Device
12. Your Plug-In should now be added