


Programming your remote


4-digit brand codes for TVs, DVD players, and amps

Direct Code Programming TV

Stand 6-8 feet away from the TV and ensure there is a line of sight between the remote and the digital box.

- Make sure the TV and digital box are on.
- There are 3 lights on the remote green for OPTIK, red for TV and yellow for AUX.
Press until the device of your choice is illuminated on your remote.
Use TV to program the remote for your TV set or AUX for all other devices.
Note: after 10 seconds of inactivity in TV or AUX mode, your remote will default back to OPTIK mode.
- Turn on the device that you would like to program the remote for.
This could be your TV set, or an auxiliary device such as an amplifier, DVD or Blue-Ray player.
- Press  or a minimum of 3 seconds, LED flashes twice
- Enter the 4-digit numerical code from the code list, LED flashes twice.
The LED will be on for 2 seconds in the case of a typing error

Factory Reset

- Press  for a minimum of 3 seconds, LED flashes twice
- Enter the code '1000' — LED flashes twice
Reset has been completed; remote is set back to original factory settings

TV Brands

A

A.R.Systems _____	1466	1809	1478	1402	1400	1263
	1257					
AB IPBox _____	2023					
Accent _____	1399	1140				
Accurian _____	2334					
Acer _____	2269	1764	1434			
Acme _____	2169					
Action _____	2316	1677	1402	1258	1140	
ad notam _____	1830					
Admiral _____	1994	1909	1908	1868	1790	1402
	1263	1181	1140			
Advent _____	1960	2028	2022	2018	2006	2004
	1754	1416	1399	1313		
Adventura _____	2362	2163				
Adyson _____	1402	1270				
AEG _____	1463	1466	1450	1449	1840	1781
	1597	1486	1473	1455	1447	1411
	1374					
Agashi _____	1402					
Agath _____	1596					
AgfaPhoto _____	1649	1574				
Aiko _____	1958	1957	1955	1140		
AIM _____	1399	1402				
Airis _____	1728	1692	1685	1656	1561	
Aiwa _____	2367	2364	2363	2217	1770	1508
	1503	1402	1401	1156		
Akai _____	1400	1394	1449	2351	1402	1434
	2342	2182	1976	1646	1352	1350
	2343	2328	2203	2065	2049	1980
	1974	1886	1818	1701	1671	1651
	1636	1631	1548	1454	1451	1450
	1447	1417	1411	1401	1399	1390
	1362	1286	1140			
Akira _____	1707	1399	1772			
Akura _____	1434	1651	1449	1402	1263	1140
Alba _____	1394	1787	1721	1790	1752	1675
	1406	1402	1382	1302	1299	1263
	1146	1145				

TV Brands _____ 4-digit television brand codes

Albatron _____	2296					
Albiral _____	1402	1785				
Alfa _____	1402					
Alleron _____	2307					
Allstar _____	1466	1402				
Alphatronics _____	1543					
Alphatronik _____	1617					
Altek _____	1707					
Altus _____	1449	1377	1791	1468	1447	1411
Amark _____	1868					
America Action _____	1963					
American High _____	1258					
Americana _____	1258					
Amoi _____	1739					
Amstrad _____	1345	1804	1572	1140		
Amtron _____	1961					
Anam National _____	2359	2254	1963	1961		
Andersson _____	1434					
Anglo _____	1263					
Anitech _____	1400	1466	1402	1270	1263	1140
Ansonic _____	1394	1466	1450	1787	1486	1455
	1434	1263	1140			
AOC _____	1699	2188	1700	2285	2284	2283
	2203	2190	2176	2053	2012	1898
	1698	1402	1389			
Aomni _____	1744					
Apex Digital _____	1636	2145	1978	2373	2277	2239
	2237	2227	2223	1967	1772	1639
Apro _____	1688					
Aquavision _____	2129	1311				
Arc En Ciel _____	1820	1814				
Arcelik _____	1463	1449	1377	1791	1447	1411
Archer _____	1868					
Arctic _____	1449	1447	1411			
Arena _____	1434	1449	1447	1411	1394	
Aristona _____	1400	1407	1402	1374	1399	1398
Art Tech _____	1402	1401				
Arthur-Martin _____	1463	1473				
Asberg _____	1402	1790	1401			

TV Brands _____ 4-digit television brand codes

Asora _____	1140					
Aspect _____	2257					
Astar _____	2276	2052	1692			
Astra _____	1449	1447	1411	1402	1140	
Asuka _____	1263					
Atec _____	1311					
Atlantic _____	1402					
Atlas _____	1400					
Atoro _____	1140					
Audinac _____	1963					
Audio Technica _____	1186					
Audiosonic _____	1449	1402	1377	1447	1411	1401
	1263	1140				
Audioton _____	1140					
Audiovox _____	1897	2388	2357	2334	2333	2319
	2300	2199	2159	2135	2131	2119
	1963	1961	1957	1879	1878	1831
	1740	1402				
Aver Media _____	1709					
AviSMART _____	2042					
AWA _____	1402	1140				
Axion _____	1964	1740				
Axxion _____	1140					

B

Bang & Olufsen _____	2063	1514				
Basic Line _____	1394	1449	1434	1402	1450	1787
	1781	1624	1455	1447	1143	
Bauer _____	1181	1822	1402	1399	1265	
Baur _____	1400	1639	1399	1508	1503	1402
	1345	1626	1509	1448	1401	1396
	1140					
Baysonic _____	1994	1963	1948	1263		
Beaulieu _____	1402	1399				
BEC _____	1677	1402				
Becrese _____	1680	1677	1671	1639	1626	1402
Beko _____	1449	1463	1377	1780	1680	1468
	1450	1818	1791	1787	1649	1469
	1464	1451	1447	1411	1402	1394
Belcor _____	2190	2188				

TV Brands _____ 4-digit television brand codes

Bell & Howell _____	2216	2215	2213	1624	1402	1181
Belson _____	1707	1547	1831	1781	1756	1738
	1687	1685	1652	1651	1600	1585
	1566	1554	1515	1434	1413	1387
Benchmark-Beaumarck __	1402	1258				
BenQ _____	2270	2269	2272	2271	2268	2209
	1684					
Beon _____	1790	1402				
Bestar _____	1402	1140				
BGH _____	2056	1754				
Bigston _____	1140					
Blackstripe _____	1639	1626	1624	1258		
Blaupunkt _____	1686	1463	1402	1822	1820	1814
	1473	1429	1400	1399	1146	1145
Blautech _____	1474					
Blue Sky _____	1449	1394	1434	1339	1466	1450
	1411	1402	2035	1791	1787	1781
	1741	1685	1486	1455	1447	1413
	1382	1146	1145			
Blusens _____	1604	1612	1608	1580	1577	1748
	1685	1616	1581	1579	1578	1545
	1544					
Boigle _____	1599					
Bosch _____	1473	1463	1402	1399		
Boxford _____	1457	1732	1462			
Bradford _____	1963	1961				
Brandt _____	1339	1449	1181	1824	1823	1401
	1820	1818	1814	1700	1468	1434
	1396	1382				
Braun _____	1827	1455	1396			
Brendstar _____	1140					
Brignton _____	1574	1558				
Brinkmann _____	1790					
Brionvega _____	1402	1784	1476	1401		
Broksonic _____	1989	1980	1994	1990	1988	1987
	1948	1947	1299			
Brokwood _____	2190	2188				
Brother _____	1483	1263				
Bruns _____	1788					
Bush _____	1394	1302	1449	1377	1787	1791
	1721	1699	1447	1411	1406	1402
	1395	1374	1263	1254	1146	1145
Byd:sign _____	1883					

TV Brands _____ 4-digit television brand codes

C

Campomatic _____	1636					
Candle _____	2188	2362	2203	2190	2165	2164
	2163	1615				
Canon _____	1402	1399				
Capehart _____	1402					
Capsonic _____	1402	1263				
Caratec _____	1649					
Carnivale _____	2203					
Carrefour _____	1402					
Carver _____	2007	1402				
Casio _____	1984	1603	1466	1402		
Cathay _____	1402					
CCE _____	2029	1878	1418			
CCI _____	1588					
Celebrity _____	1886	1884				
Celera _____	1636					
Centrios _____	2355					
Centrum _____	1377					
Centurion _____	2188	1402				
CGE _____	1790	1140				
CGM _____	1140					
Champion _____	2217					
Changhong _____	1636	1640	2230	1685	1633	
Charisma _____	1523					
Charpy _____	1660					
CIE _____	1572	1143	1140			
Cihan _____	1402					
Cimline _____	1721					
Cineral _____	1957	1955	1879			
Cinex _____	1466	1450	1486	1455		
Citizen _____	2311	2188	1980	1258	2362	2355
	2312	2255	2224	2203	2190	2165
	2164	1990	1976	1961	1958	1957
	1955	1879	1639	1615	1402	
Clarion _____	1963					
Clarivox _____	1811	1789	1782	1402		
Claton _____	1394					
Clatronic _____	1449	2057	1790	1558	1466	1447
	1411	1402	1254	1140		

TV Brands _____ 4-digit television brand codes

Claud _____	1401					
CMX/Commax _____	2304	1840	1756	1945	1705	1691
	1690	1689	1649	1597	1559	
Coby _____	1552	2280	2279	2278	2251	2250
	2249	2162	2112	2111	2104	2103
	2101	2100	2055			
Color Voice _____	2169					
Colortyme _____	2188	2190	2169	1402	1258	
Combi _____	1561					
Commercial Solutions _____	2082	2077				
Computec _____	1466					
Computron _____	1402	1140				
Concerto _____	2188	2190	1615			
Concorde _____	1140					
Condor _____	1402	1790	1466	1140		
Conia _____	1651	1449				
Conic _____	1677	1402				
Conrac _____	1791					
Constructa _____	1400					
Contec _____	1963	1961	1140			
Continental _____	2253	1449	1447	1411	1146	1145
Continental Edison _____	1434	1840	1146	1823	1820	1814
	1145					
Coradir _____	2295					
Corfung _____	1263					
Cornea _____	1615					
Cosmel _____	1140					
Craig _____	1963	1961	1402			
Croma _____	1385					
Crosley _____	2078	2013	2007	2006	1884	1677
	1402					
Crosswood _____	1394	1449	1468	1447	1411	
Crown _____	1449	1402	1377	2343	2006	1963
	1961	1791	1785	1685	1660	1469
	1447	1411	1401	1181	1140	
Crown Mustang _____	2343					
Crystal _____	1402	1399				
CTX _____	1868	1861				
Curtis _____	1402	2277	2252	2041	1840	1790
	1685	1639	1624	1479	1258	
CXC _____	1963	1961				

TV Brands _____ 4-digit television brand codes

Cybercom _____ 1377
 Cyberpix _____ 1434
 Cytron _____ 2252 2170

D

Daenyx _____ 2343 1963
 Daewoo _____ 1154 1404 1155 1156 1151 2343
 2188 1959 1878 1833 1402 2384
 2350 2327 2306 2216 2190 2169
 1958 1957 1956 1955 1898 1880
 1879 1874 1873 1872 1871 1870
 1869 1863 1757 1688 1575 1574
 1557 1466 1463 1449 1447 1406
 1377 1374 1152 1150 1143 1140
 Daichi _____ 1140
 Daimond _____ 1399
 Dalco _____ 1773 1772
 Dangaard _____ 1713 1707 1651 1612 1611 1576
 1574 1573
 Dantax _____ 1449 1377 1447 1411 1402 1382
 Davis _____ 1401
 Dawa _____ 1402 1401
 Daytek _____ 1758
 Daytron _____ 2188 2190 1963 1626
 DCE _____ 1394 1449 1447 1411 1402
 Decca _____ 1402 1466 1803 1486 1430
 Dell _____ 2376 1776 2377 2044 2043 2040
 2034 1615 1614 1404
 Denon _____ 1662 1508 1765 1162
 Denver _____ 1701 1574 1686 1685 1649 1631
 1613 1611 1609 1573 1558 1472
 1140
 Desmet _____ 1402 1140
 Diamond _____ 1140
 Diamond Vision _____ 2110 2109 2108 2106 1551
 Diboss _____ 1466 1465
 Digihome _____ 1434 1382
 Digiline _____ 1787 1400
 Digiloc _____ 1640 1551
 Digimate _____ 2152
 Digistar _____ 2373 2372 2371 2370 2024 2022
 1953 1952 1614

TV Brands _____ 4-digit television brand codes

Digital _____	1377	1449				
Digital Lifestyles _____	2338					
Digital+ _____	1377					
Digitech _____	1345	1394				
DIKOM _____	1597					
Dimensia _____	2078					
Disney _____	2050	1990	1983			
Dixi _____	1788	1402	1140			
DLD _____	1659					
DMTech _____	1394	1434	1718	1568	1482	1436
	1382					
DQT _____	1778	1586				
Drean _____	1418					
DSE _____	2372					
Dual _____	1402	1449	1434	1399	1377	1345
	1721	1411	1406	1405	1403	1140
Dukane _____	2257	2091				
Dumont _____	2190	2070	2068	1793	1790	
Durabrand _____	1449	2374	1377	2375	2128	2030
	1996	1994	1993	1990	1963	1615
	1447	1434	1411	1394		
Dynamic _____	1140					
Dynatech _____	2188					
Dynatron _____	1729					
Dynex _____	1841	2320	1993	1842		

E

E-Max _____	1758	1692				
E-motion _____	1686	1685				
easy touch _____	1685					
Eaton _____	1258					
ECG _____	1840	1631				
Ecron _____	1394	1449	1402			
Edison Minerva _____	1146	1145				
Elbe _____	1394	1434	1377	1466	1450	1402
	1400	1382	1799	1758	1734	1731
	1685	1563	1556	1463	1456	1455
	1449	1411				
Elbit _____	1402	1408	1401			

TV Brands _____ 4-digit television brand codes

Elecs _____	1402					
Electric CO _____	1641					
Electric Mirror _____	1753					
Electro Tech _____	1140					
Electroband _____	1886	1884				
Electrograph _____	1744					
Electrohome _____	2188	2311	2190	2147	2144	1994
	1980	1677	1624	1602	1434	
Elekta _____	1377	1263	1140			
Elektra _____	2070	1878				
Elektronika _____	1402					
Element Electronics _____	1651	2194	1729			
Elemis _____	1466	2057	1486	1434	1394	
Elfunk _____	1382	1394				
Elin _____	1466	1402	1140			
Elite _____	1935	1639	1624	1402	1258	
Elmak _____	1786	1415	1414	1402		
Elman _____	1818	1793				
Elta _____	1449	1447	1411	1402	1140	
Emerson _____	1394	1449	1729	2324	2188	1878
	1450	1402	2323	2307	2305	2254
	2218	2216	2215	2213	2190	2178
	2166	2151	2137	2136	2130	2109
	2108	1994	1990	1989	1987	1963
	1961	1949	1948	1947	1943	1879
	1873	1811	1787	1686	1615	1455
	1447	1411	1183	1155		
Emprex _____	2340	2339	2338			
Encross _____	1754					
enox _____	1651					
Envision _____	2188	2284	2203	2190	2185	2184
	2012	1700	1699	1389		
EON _____	1258					
Epson _____	1986	1985				
Erres _____	1400	1499	1402	1399	1823	1398
	1374					
ESA _____	2324	1974				
ESC _____	1402	1140				
Essentiel b _____	1781	1756	1702	1651	1629	1434
	1402	1385	1382			
Eternity _____	1758	1686				
Etron _____	1402	1140				
Euro-Feel _____	1263					

TV Brands _____ 4-digit television brand codes

Euroline _____	1449 1394	1713 1377	1447	1434	1411	1402
Euroman _____	1402	1263				
Europa _____	1449	1447	1411			
Europhon _____	1799	1793	1663	1402		
Everton _____	1686					
Excelsior _____	1374					
Expert _____	1354					

F

Fenner _____	1377 1140	1787	1449	1447	1411	1402
Ferguson _____	1402 1639 1823 1686 1508 1166	1399 1509 1822 1677 1466	1824 1503 1820 1676 1401	1339 1400 1818 1675 1393	1802 1370 1803 1643 1372	1680 1829 1717 1626 1341
Fidelis _____	1402	1140				
Filsai _____	1140					
Finlandia _____	1624	1824				
Finlux _____	1400 1399 1790 1430 1352	1434 1364 1784 1411 1140	1350 1358 1761 1402	1449 1356 1486 1394	1382 1351 1456 1362	1466 1794 1447 1354
First Line _____	1400 1791 1447	1449 1787 1411	1394 1705 1401	1402 1624 1143	1434 1503 1140	1377 1466
Fisher _____	1624 2213	2217 1795	1788 1626	2216 1508	2215 1148	2214
Flint _____	1402					
Fluid _____	2353	2331	2330	1998	1973	
Force _____	1758					
Formenti _____	1402	1401				
Fortress _____	1181					
Frontech _____	1824	1263	1140			
Fujimaru _____	1651					
Fujitsu _____	1510 1791	2307 1213	1938	1937	1936	1935
Fujitsu Siemens _____	1615	1510				
Fulton _____	1478	1466				

TV Brands _____ 4-digit television brand codes

Funai _____	1729	1449	1434	1394	1377	2324
	2323	2321	2307	1963	1961	1884
	1779	1574	1510	1447	1411	1390
	1389	1263	1140			

Futuretec_____1961

Futuretech_____1963

G

Galaxis_____1790 1402

Galaxy_____1790

Galeria_____1140

Gateway_____2274 2272

GBC_____1402 1140

GE_____2188 2077 1519 2246 2198 2190
 2183 2181 2147 2146 2144 2143
 2085 2083 2082 2078 2076 2075
 1902 1879 1824 1636 1615

GEC_____1400 1677 1508 1402

Geloso_____1140

Gemsound_____1140

General_____1463 1772 1473 1140

General Electric_____2082

General Technic_____1140

Genexxa_____1402

Gericom_____1791 1745 1311

GFM_____1729 2324

Giant_____1402

Gibraltar_____2203 2190 2070 2068

Gitem_____1402 1824 1820 1399

Global Home_____2372

GMG_____1790 1140

Go Video_____2293

GoGEN_____1434

Goldhand_____1140

Goldi_____1404

GoldStar_____1466 1449 1615 1402 2188 2176
 1798 1602 1418 1284 2384 2203
 2190 2189 1898 1866 1677 1614
 1571 1452 1447 1401 1399 1263
 1258 1146 1145 1140 1138

TV Brands _____ 4-digit television brand codes

Goldy _____	1772					
Goodmans _____	1400	1394	1402	1434	1302	1787
	1686	1646	1466	1377	1791	1758
	1714	1685	1651	1601	1570	1553
	1472	1449	1447	1411	1410	1404
	1401	1382	1378	1339	1298	1288
	1160	1156	1154	1143	1140	
GPM _____	1140					
Gradiente _____	2310	2190	2128	1914	1912	1615
Gradin _____	1402					
Graetz _____	1394	1382	1434	1449	1377	1626
	1413	1411				
Gran Prix _____	1704	1703	1466	1705	1486	
Granada _____	1208	1624	1402	1676	1671	1639
	1407	1401	1181	1824	1803	1675
	1430	1400	1399	1374	1362	1355
	1354	1166				
Grandin _____	1394	1434	1449	1382	1377	1791
	1787	1731	1571	1463	1447	1411
	1402					
Grenadier _____	1402	1140				
Gronic _____	1402					
Grundig _____	1400	1217	1463	1402	1758	1449
	1146	1407	1377	2343	2057	1822
	1783	1781	1721	1614	1602	1601
	1513	1485	1474	1473	1469	1438
	1435	1418	1399	1387	1299	1218
	1216	1215	1214	1145	1141	
Grundy _____	2307	1961				
Grunkel _____	1394	1685	1575	1434		
Grunpy _____	1963					
GTT _____	1790	1140				
Guestvision _____	2014					
Gvision _____	2123					
H						
H&B _____	1394	1791	1746	1377		
Haier _____	1602	2374	1951	1624	1615	2375
	2373	2271	2097	1950	1884	1840
	1698	1686	1407	1269	1264	1261
	1173					
Halifax _____	1263					
Hallmark _____	2188	2190	1615			

TV Brands _____ 4-digit television brand codes

Hanns.G _____	2349					
Hannspree _____	1736	1621	2349	2211	2210	
Hanseatic _____	1402	1399	1154	1449	1156	1798
	1784	1699	1466	1464	1411	1406
	1140					
Hantarex _____	1402	1648	1401	1140		
Harley Davidson _____	2128	1258				
Harman/Kardon _____	2007					
Harvard _____	1963	1961				
Havermy _____	1908					
HB _____	1449	1394	1377	2292	1791	1781
	1661	1568	1469	1468	1463	1451
	1390					
HB Ingelen _____	1394	1447				
HCM _____	1263	1140				
Heathkit _____	1402					
Helios _____	1745					
Hello Kitty _____	1879					
Hewlett Packard _____	2378	2380	2379			
Hifivox _____	1820	1814				
Hiline _____	1140					
Himitsu _____	1963					
Hinari _____	1466	1402	1140			
Hisawa _____	1449					
Hisense _____	1706	2373	2365	2290	2289	2288
	2287	2286	2194	2054	2016	1772
	1705					
Hitachi _____	1671	1434	2257	1662	1394	1680
	1676	1382	1675	1672	1669	1664
	1679	1677	1663	1402	1354	2258
	2188	1681	1674	1670	1665	1639
	1407	1404	1350	2360	2266	2265
	2264	2263	2261	2260	2259	2190
	2092	2091	1997	1954	1916	1823
	1814	1763	1699	1682	1673	1668
	1649	1626	1615	1430	1429	1406
	1188	1181	1156	1154		
Hitech _____	1719					
Höher _____	1394	1449	1434	1377	1447	1402
Home Electronics _____	1781	1732				
Horizont _____	1449	1447	1411	1402		
Hornyphon _____	1402	1401				

TV Brands _____ 4-digit television brand codes

HP _____	2378	2381	2380			
Humax _____	1694	1744	1696	1695	1149	
Huspi Elektronik _____	1790					
Hyper _____	1402	1140				
Hypervision _____	1437					
Hypson _____	1402	1449	1434	1413	1411	1263
	1140					
Hyundai _____	1382	1760	1449	1377	2187	1982
	1781	1777	1772	1759	1754	1719
	1707	1474	1447	1434	1411	1261
	1260	1172	1153			
I						
I-Inc _____	2267					
I.V. _____	1402					
ICE _____	1402	1263	1140			
Iekei _____	1599					
Ikusi _____	1458					
ILO _____	2291	2281	2361	2244	2351	2282
	2240	1993				
IMA _____	1961					
Imperial _____	1790	1402	1632	1631	1595	1474
	1401					
Indesit _____	1822					
Indiana _____	1402					
Infinity _____	2045	2013	2006	1402		
InFocus _____	2325					
Infratex _____	1402	1810	1809	1805	1787	1786
	1781	1771	1766	1406	1303	1262
Ingelen _____	1449	1731	1780	1447	1411	
Ingersoll _____	1140					
Initial _____	2291	2281	2282			
Inno Hit _____	1402	1434	1413	1401	1140	
Innova _____	1418					
Insignia _____	1841	1838	2324	2320	2319	2318
	2298	1993	2375	2370	2323	2291
	2288	2252	2067	2065	2064	2022
	1995	1994	1992	1991	1990	1896
	1660	1602				
Integra _____	2167					
Inteq _____	2070					

TV Brands _____ 4-digit television brand codes

InterACTV _____	1443					
Interbay _____	1140					
Interbuy _____	1270	1263				
Interdiscount _____	1824	1823	1820	1508	1402	1399
Interfunk _____	1400	1399	1402	1820	1790	1626
	1401					
Intertronic _____	1402					
Intervision _____	1798	1762	1400	1270	1263	1140
Ipure _____	1649	1758	1631	1542		
Irradio _____	1402	1449	1377	1466	1447	1401
	1140					
IRT _____	1879	1878				
Iskra _____	1449	1447	1411			
ISP _____	1374					
IST _____	1402					
Isukai _____	1402					
ITL _____	1140					
ITS _____	1140					
ITT _____	1181	1434	1449	1624	1350	1814
	1794	1721	1626	1473	1463	1447
	1411	1402	1399	1362	1354	1339
	1140					
ITT Nokia _____	1963					
ITV _____	1466	1263				
IX _____	2348					

J

Jacson _____	1795					
Janeil _____	2362	2163				
JBL _____	2013	2007	2006	1402		
JC Penney _____	2225	2188	1258	2246	2226	2224
	2203	2190	2183	2181	2166	2165
	2164	2147	2146	2144	2143	2085
	2082	2078	1976	1898	1639	1615
JCB _____	1886	1884				
JCM _____	2150					
JDB _____	1732					
JEC _____	1639					
Jensen _____	2188	1960	1660	2303	2252	2190
	2008	1892	1416			

TV Brands _____ 4-digit television brand codes

Jetpoint _____	1402	1399	1258			
Jinlipu _____	1140					
JMB _____	1686					
John Lewis _____	1591					
Jumbotronic _____	1402					
JVC _____	1186	1182	1187	1184	1188	1189
	1994	1916	1624	1615	1205	1190
	1185	1183	2212	2158	2157	1935
	1919	1918	1917	1915	1914	1913
	1911	1794	1402	1401	1171	

K

Kaiser _____	1402	1401				
Kaisui _____	1402	1140				
Kambrook _____	1823					
Karcher _____	1466	1402	1799	1486	1401	1377
	1140					
Kawasho _____	2188	2190	1886			
KEC _____	1963	1961				
Ken Brown _____	2386	1994	1948			
Kendo _____	1394	1434	1339	1449	1731	1466
	1402	1382	1815	1721	1447	1432
	1390	1140				
Kenia _____	2203					
Kenmark _____	1378	1686				
Kennex _____	1404					
Kenstar _____	1654	1592				
Kenwood _____	1602	2188	2203	2190	1606	
Kerion _____	1402					
Keymat _____	1661	1639	1594	1312		
Kimay _____	1263					
Kiota _____	2007	1140				
Kishu _____	1707					
Kiton _____	1394					
KLH _____	1636	2237				
Kloss Novabeam _____	2362	2163	1258			
Kneissel _____	1402	1789	1787	1731	1563	1404
	1143					
Kobic _____	1140					
Kogan _____	1840	1686				

TV Brands _____ 4-digit television brand codes

Kogi _____	2123					
Kolster _____	1402					
Konichi _____	1140					
Konka _____	2107	2385	2369	2368	2298	2065
	2064	2027	1961	1838	1767	1267
	1159					
Kopernikus _____	1636	1402				
Korpel _____	1402					
Kortek _____	1747					
Kost _____	1877	1466				
Kotron _____	1551					
Kreisen _____	1754					
Kriminal Forsorgen _____	1453					
KTC _____	1756					
KTV _____	2203	2171	1963	1961		
Kuasho _____	1402					
L						
Lasonic _____	2108	2106				
Latona _____	1744					
Lavis _____	1402	1789	1143			
LCD _____	1569					
Leader _____	1140					
Legend _____	2022	1402	1140			
Lenco _____	1833	1686	1434	1141	1140	1756
	1612	1449	1406	1402	1263	1158
	1143					
Lenoir _____	1402	1140				
Lenuss _____	1293					
Level _____	1711					
Lexus _____	1263					
Leyco _____	1402	1263				
LG _____	1615	1602	1466	1603	1614	1449
	2190	2188	1434	2384	2346	2203
	2202	2198	2191	2176	2127	2077
	2070	1898	1866	1808	1654	1619
	1606	1571	1452	1447	1402	
Liesenkötter _____	1402	1399				
Life _____	1140					
Lifetec _____	1394	1402	1787	1509	1466	1449
	1411	1406	1263	1143	1140	

TV Brands _____ 4-digit television brand codes

Linitron _____	1181					
Liquidvideo _____	2356	1964				
Listo _____	1434	1382	1394			
LLoyd's _____	2128	1140				
LodgeNet _____	2313					
Lodos _____	1394					
Loewe _____	1401	1384	1423	1381	1208	1455
	1426	1399	2033	2015	2013	2006
	1787	1446	1402	1396	1392	
Logik _____	1654	2331	2149	1717	1688	1605
	1601	1402				
Logix _____	1686					
Luma _____	1402	1140				
Lumatron _____	1394	1707	1787	1568	1390	
Lux-May _____	1402	1811				
Luxman _____	2188	2190	1615			
Luxor _____	1434	1394	1382	1350	1402	1364
	1356	1794	1470	1461	1430	1413
	1359	1358	1354	1352	1140	
LXI _____	2225	2188	2246	2226	2224	2216
	2215	2213	2190	2082	2078	2013
	2007	2006	1624	1615	1402	1181
Lynx _____	2372					

M

M Electronic _____	1356	1818	1402	1364	1362	1358
	1354	1140				
M&S _____	2007	1948				
MAG _____	1651					
Magnadyne _____	1402	1793	1790	1466	1401	1140
Magnafon _____	1799	1793	1402			
Magnasonic _____	2307	1624	1466	1402	1181	
Magnavox _____	1400	1383	2324	2317	2188	2045
	2003	1493	1380	2383	2382	2357
	2308	2281	2203	2190	2165	2164
	2048	2047	2046	2039	2038	2037
	2036	2035	2026	2017	2013	2007
	2006	2004	1940	1909	1700	1677
	1602	1431	1426	1404	1402	
Magnex _____	1402					
Magnum _____	1450	1449	1377	2057	1481	1455
	1447	1411	1402			

TV Brands _____ 4-digit television brand codes

Man City _____	1686					
Mandor _____	1263					
Manesth _____	1721	1402	1263			
Manhattan _____	1394	1434	1382			
Marantz _____	2188	2167	1402	1374	2261	2203
	2190	2019	2013	2007	2006	1743
	1662	1418	1399	1398	1383	
Mark _____	1394	1449	1402	1791	1447	1411
	1401	1143				
Marusys _____	1296					
Mascom _____	1466	1631	1463	1486	1483	1450
	1422	1351				
Match Italia _____	1402					
Matsui _____	1394	1302	1624	1309	1510	1466
	1307	1140	1725	1723	1721	1717
	1643	1601	1572	1382	1306	1304
	1254	1156	1146	1145		
Matsushita _____	1924	1205				
Maxam _____	1140					
Maxent _____	2358					
Maxwell _____	1791					
MCE _____	1140					
McMichael _____	1677					
McPerson _____	1472					
Media Center _____	2381					
Media Station _____	1644					
Media TV _____	1406					
Medialine _____	1831					
Mediator _____	1402					
Medion _____	1394	1449	1434	1450	1402	1791
	1646	1466	1377	1350	2244	2174
	2173	2032	1983	1787	1601	1566
	1480	1468	1455	1447	1411	1406
	1382	1351				
Megas _____	1731					
Megatron _____	2188	2261	2257	2190	1671	1662
	1615					
Melbox _____	1782					
Melectronic _____	1449	1447	1411	1362	1357	1356
	1354					
Memorex _____	2348	2188	2308	2307	2217	2216
	2215	2213	2190	1994	1993	1990
	1988	1980	1934	1932	1892	1841
	1624	1615	1475	1299	1263	

TV Brands _____ 4-digit television brand codes

Memory _____	1434					
Mercury _____	1402	1140				
Meteor _____	1799					
Metz _____	1394	1540	1541	2094	1839	1822
	1791	1787	1466	1434	1402	1399
	1369	1368	1367	1366	1365	1318
MGA _____	2188	1399	2307	2203	2190	2147
	2144	1898	1892	1615	1602	
Micromax _____	1394	1781	1449			
Microspot _____	1641	1382				
Midland _____	2246	2082	2070	2068		
Minerva _____	1645	1217	1146	1145		
Minoka _____	1402					
Minsonic _____	1141					
Mintek _____	2291	2281				
Minutz _____	2146	2143				
Mirage _____	1449	1447				
Mirai _____	1510	1735	1567	1505		
Mitsai _____	1686	1408				
Mitsubishi _____	1166	1394	1168	2188	1892	1399
	2307	2190	2147	2144	1908	1902
	1898	1895	1894	1893	1881	1743
	1742	1615	1602	1407	1404	1402
	1169	1165	1140			
Mivar _____	1800	1710				
Monitor _____	1258					
Monivision _____	2296					
Moteva _____	2215	1912				
Motorola _____	1908	1868				
MTC _____	2188	1258	2224	2203	2190	1976
	1898	1615	1401			
Multichoice _____	1828	1775	1730	1438		
Multimedia _____	1139					
Multitec _____	1394					
Multitech _____	1963	1961	1466	1402	1401	1140
Multivision _____	2132					
Mustek _____	1656					
Mx Onda _____	1655	1651	1561	1466	1453	1253
Myron & Davis _____	1745					

TV Brands _____ 4-digit television brand codes

N

NAD _____	2225	2188	1615	2236	2226	2224
	2190	2001	1997	1418		
Naim _____	1439					
Namsunc _____	1140					
NAP _____	1401					
National _____	1402	1772	1399	1205		
Naxa _____	1686					
NEC _____	1743	2188	2167	1742	1590	2348
	2335	2207	2203	2190	2169	2168
	1898	1881	1754	1744	1615	1589
	1311	1258	1140			
Neckermann _____	1400	1402	1399	1722	1721	1509
	1508	1503	1499	1466	1449	1447
	1406	1401	1182	1140		
NEI _____	1402	1811	1401			
NEO _____	1377	1781	1772	1769	1768	1449
	1447	1411	1144	1141		
Neovia _____	1745	1466	1296			
Net-TV _____	2244					
Netsat _____	1418					
Nevir _____	1597					
Newtech _____	1402					
NEX _____	1719					
Nexus _____	2194					
Nexxtech _____	2370	2247				
Nikkai _____	1402	1377	1639	1449	1411	1263
Nikkei _____	1449	1707	1592	1447	1411	
Nikko _____	2188	2203	2190	1958	1957	1955
	1812	1615	1466			
Niko _____	2297					
Nimbro _____	1686					
Nissan _____	1258					
Noblex _____	2216	1148	1140			
Nobliko _____	1793					
Nogamatic _____	1820	1814				
Nokia _____	1402	1362	1350	1624	1364	1357
	1356	1355	1352	1140	1963	1864
	1794	1790	1721	1626	1399	1363
	1361	1359	1358	1354	1353	1263
	1258	1254				

TV Brands _____ 4-digit television brand codes

Norcent _____	2329	1772	1700	2373	2327	2297
	2160	2053	1736	1699		
Nordmende _____	1824	1339	1825	1449	1377	2179
	1823	1821	1820	1818	1814	1750
	1654	1600	1594	1447	1434	1411
	1404	1401	1307	1181		
Nortek _____	1402					
Northern Star _____	1744					
Norwood Micro _____	2244					
Notts Forest _____	1686					
Nova _____	1402					
Novatronic _____	1402	1401	1140			
Novox _____	1650	1565				
NPG _____	1636					
NTC _____	1958	1957	1955			
Nu-Tec _____	2295					
NuVision _____	2072					



O General _____	1140					
Oceanic _____	1624	1356	1181	1364	1362	1358
	1354					
ODYS _____	1649	1832	1831	1740	1733	1712
	1658	1618	1597	1555	1552	
Okano _____	1801	1140				
OKI _____	1434	1382	1377	1686	1636	1566
	1469	1463	1406	1394		
Olevia _____	2345	2200	2193	2113	2344	2204
	2114					
Olympic _____	1140					
Olympus _____	1402	1399				
Onceas _____	1140					
Oncommand _____	2014					
Onida _____	1402					
Onkyo _____	1296					
ONN _____	1688	1377				
Onwa _____	1963	1961	1722			
Opera _____	1707	1420	1402			
Optanka _____	1181					
Optimus _____	1205	2216	1997	1934	1932	1924
	1318					

TV Brands _____ 4-digit television brand codes

Optoma _____	2332	2210				
Optonica _____	2207	1908	1868			
Orava _____	1408	1402				
Orbit _____	1402					
Orbitech _____	1404					
Orian _____	1773					
Orient _____	1140					
Orion _____	1402	1394	1302	1449	1758	1400
	1725	1450	1434	1401	1377	1307
	1306	1305	1172	1994	1993	1990
	1989	1987	1949	1948	1813	1791
	1722	1721	1601	1572	1509	1455
	1447	1417	1413	1319	1309	1308
	1303	1300	1299	1281	1268	1263
	1170	1162	1140			
Osaki _____	1402					
Otake _____	1722	1721	1308			
Otava _____	1466	1478	1477	1428		
OTF _____	1140					
Otic _____	1651					
Otrum _____	1401					
Otto Versand _____	1400	1402	1181	1399	1639	1508
	1208	1509	1503	1466	1345	1824
	1818	1813	1798	1722	1721	1626
	1499	1406	1396	1140		
OVP _____	1460	1459				

P

Pacific _____	1449	1307	1447			
Packard Bell _____	1957					
Pael _____	1466					
Palladium _____	1394	1402	1401	1449	1466	1411
	1399	1390	1377			
Palsonic _____	1402					
Panama _____	1402	1263				
Panashiba _____	1140					
Panasonic _____	1400	1208	1205	1925	1402	1931
	1927	1508	1209	2258	2171	2013
	2006	1934	1933	1932	1930	1929
	1928	1926	1924	1923	1922	1921
	1822	1401	1399	1382	1211	1210
	1206	1204				

TV Brands _____ 4-digit television brand codes

Panavision _____	1774	1449	1447	1411		
Panavox _____	1864	1140				
Panorama _____	1140					
Panoramic _____	1820					
PARK _____	1686					
Pathe Marconi _____	1820	1814				
Pausa _____	1140					
PCE/PEC _____	1639	1626	1624	1258		
Peacock _____	1684	1568	1311			
Perfekt _____	1402					
Petters _____	1651					
Philco _____	2188	1790	2385	2324	2262	2203
	2190	2165	2164	2026	2013	2007
	2006	1994	1957	1898	1879	1878
	1789	1677	1662	1602	1402	1140
Philex _____	1399					
Philips _____	1400	1374	1492	1493	1402	1401
	1398	1407	1399	1383	1389	1466
	1393	1499	1397	1378	2013	2007
	2005	2003	1698	1494	1426	1404
	1388	1380	1379	1181	2271	2190
	2188	2183	2181	2165	2164	2126
	2059	2051	2046	2045	2038	2028
	2026	2020	2017	2011	2010	2006
	2004	2002	1837	1823	1822	1818
	1814	1677	1639	1602	1508	1498
	1434	1418	1391	1375	1154	
Phocus _____	1377	1449	1791	1468	1447	1411
	1217					
Phoenix _____	1402					
Phonola _____	1400	1402	1449	1447		
Phonotrend _____	1755					
Pioneer _____	1400	1318	1531	1402	1528	2188
	2091	1530	1527	1523	2190	2167
	2092	2090	2001	1999	1997	1923
	1823	1743	1639	1532	1529	1526
	1525	1524	1401	1399	1321	1320
	1317	1316	1315	1314		
Piva _____	2105					
PKS _____	1401					
Planar _____	2348	2243	1699			
Plantron _____	1402	1263	1140			
Platinum _____	1715					

TV Brands _____ 4-digit television brand codes

Playsonic _____	1449	1394	1377	1469	1447	1411
Polaris _____	1474					
Polaroid _____	1651	2096	1636	2232	1897	2388
	2387	2372	2347	2273	2252	2244
	2112	2067	2065	2064	2054	2021
	2016	1892	1882	1877	1862	1831
	1745	1660	1602			
Policom _____	1820					
Portland _____	2188	2190	1958	1957	1898	1879
	1878	1873	1872	1402		
Powerpoint _____	1707	1449	1402			
Prandoni Prince _____	1466					
Precision _____	2024	1565				
Price Club _____	1976					
Prima _____	1960	1615	2371	2370	2028	2022
	1841	1639	1624	1416	1402	1399
	1263	1258	1140			
Princess _____	1449	1377	1451	1447	1140	
Princeton Graphics _____	2124	1868				
Pringston _____	1449	1447	1402			
Pro Basic _____	1724					
Proelco _____	1402					
Profectis _____	1434					
Profex _____	1140					
Profilo _____	1466	1450	1440	1640	1486	1483
	1456	1455				
Profitronic _____	1466	1402				
ProLine _____	1394	1434	1382	1784	1688	1686
	1584	1553	1487	1453	1449	1447
	1430	1413	1411	1404	1374	1156
Promethean _____	1622					
ProScan _____	2246	2203	2194	2150	2115	2085
	2082	2079	2078	2077	2075	1258
Prosonic _____	1449	1686	1575	1574	1463	1434
	1394	1377	1707	1612	1611	1573
	1478	1447	1411	1382		
Protec _____	1402	1263				
ProTech _____	1394	1402	1787	1400		
Protek _____	1685	1434				
Proton _____	2188	2190	2153	2148	1876	1867
	1823	1615				
Protron _____	2195	2152				

TV Brands _____ 4-digit television brand codes

Proview _____	1651	2248	2200			
Provision _____	1449	1466	1447	1400		
Pulsar _____	2190	2070	2068			
Pulser _____	2188	1677	1402	1258		
Punktal _____	1944					
Pye _____	1400	1402	1407	1399	1946	1401
	1398					
Pyle _____	2041					

Q

Qty1 _____	1402					
Quadro _____	1394	1719	1434	1402	1796	1382
	1692	1427	1390	1170		
Quasar _____	1208	1205	2171	2073	2013	1934
	1933	1932	1925	1924	1922	1140
Quelle _____	1400	1394	1402	1399	1639	1509
	1208	1508	1503	1466	1356	1345
	1829	1824	1801	1795	1787	1722
	1721	1626	1572	1499	1423	1401
	1398	1396	1390	1364	1362	1358
	1354	1182	1140			

R

R-Line _____	1402					
Radio Shack _____	2207	2188	1615	2216	2215	2213
	2203	2190	2082	2078	1963	1961
	1624	1205	1181			
Radiola _____	1400	1407	1398	1374	1402	1399
	1492	1393				
RadioMarelli _____	1402					
Radiotone _____	1394	2057	1787	1466	1402	1263
	1140					
Radix _____	1626					
RCA _____	2077	2078	2188	2150	2087	2085
	1519	1284	1258	2246	2190	2177
	2175	2156	2155	2154	2147	2092
	2088	2086	2084	2082	2081	2080
	2079	2076	2075	2074	2073	2067
	1908	1902	1898	1878	1871	1740
	1602	1518	1401			

TV Brands _____ 4-digit television brand codes

Realistic _____	2207	2188	1615	2216	2215	2213
	2203	2190	2078	1963	1961	1624
	1205					
Recor _____	1402	1399				
Record _____	1402	1137				
Red Star _____	1466	1486				
Reflexion _____	2133	1649				
Regal _____	1449	1447				
Regente _____	1140					
Relisys _____	1651					
RevolutionHD _____	1744					
Revox _____	1401	1402				
RFT _____	1788	1404	1836	1406	1374	
Rice Club _____	1258					
Roadstar _____	1449	1394	1402	1377	1302	1791
	1477	1447	1411	1400	1390	1263
	1140					
Rosita _____	1140					
Rowa _____	1140					
Royal _____	1449	1447	1402	1263	1262	1140
Runco _____	2203	2167	2070	2068	1743	1258

S

SABA _____	1824	1339	1382	1449	1823	1814
	1434	1372	1826	1820	1818	1793
	1700	1468	1447	1394	1341	1157
Sagem _____	1731	1726	1716			
Saisho _____	1721	1572	1402	1399		
Saivod _____	1394	1449	1466	1450	1434	1787
	1613	1574	1486	1455	1447	
Sakio _____	1263	1140				
Sakura _____	1140					
Salora _____	1434	1631	1350	1649	1624	1402
	1356	1794	1783	1781	1685	1612
	1568	1542	1482	1466	1463	1456
	1455	1450	1422	1396	1382	1364
	1362	1360	1358	1357	1354	1351
Sambers _____	1799	1793	1466			
Sampo _____	2188	2203	2190			

TV Brands _____ 4-digit television brand codes

Samsung _____	1286	1296	1284	1448	1466	1287
	1976	1488	1407	1402	1491	1489
	1472	1258	2188	1970	1615	1285
	1141	2384	2246	2224	2205	2203
	2190	2172	2058	2025	1975	1974
	1972	1971	1969	1968	1942	1898
	1801	1685	1639	1602	1500	1490
	1473	1433	1418	1401	1399	1386
	1297	1295	1294	1292	1291	1289
	1283	1266	1263	1205	1148	1147
	1140					
Samsux _____	2188					
Samtron _____	1976					
Sansei _____	1957	1879				
Sansui _____	1402	1399	1993	1980	2299	1994
	1990	1989	1987	1300	1299	1263
	1258	1140				
Santeca _____	2206					
Sanyo _____	1624	1394	1434	1623	1627	1466
	1449	1382	2339	2217	2216	2215
	2214	2213	2208	2190	2007	1795
	1788	1643	1626	1625	1620	1486
	1447	1140				
SBR _____	1402					
Scansonic _____	1515	1449				
Sceptre _____	1978	1890	1977	1888	1887	
Schaub Lorenz _____	1394	1434	1449	1707	1377	1463
	1791	1781	1754	1705	1661	1649
	1640	1639	1631	1587	1568	1469
	1468	1447	1411			
Schneider _____	1400	1402	1394	1466	1449	1406
	1374	1434	1401	1450	1399	1398
	1345	2057	1787	1690	1597	1492
	1486	1481	1472	1465	1456	1455
	1447	1442	1424	1420	1419	1411
	1408	1407	1393	1382	1373	1263
	1254	1140				
Scientific Labs _____	1456	1402				
Scotch _____	2188	2190	1615			
Scott _____	2222	2188	1756	2307	2190	2137
	1963	1961	1949	1948	1615	1613
	1598	1550	1434			
Screenlant Tft _____	1406					
SEA _____	1434					

TV Brands _____ 4-digit television brand codes

Sears _____	2225	2188	1615	2323	2307	2246
	2226	2224	2217	2216	2215	2214
	2213	2190	2095	2082	2078	2013
	2007	1980	1976	1907	1624	1602
SEC _____	1254					
SEG _____	1394	1434	1382	1140	1788	1787
	1710	1685	1649	1636	1574	1549
	1509	1463	1449	1441	1413	1411
	1406	1402	1395	1390	1263	
Sèleco _____	1784	1402	1828	1824	1815	1814
	1806	1443	1400			
Selectron _____	2373	2031				
Semivox _____	1994	1963	1948			
Semp _____	2233	2226	2224	1639		
Sencor _____	1631	1840	1838	1756	1707	1649
	1463	1377				
Sense _____	2199					
Sentra _____	1639					
Serie Dorada _____	1615	2226	2203	1963		
Serino _____	1731					
Sharp _____	1400	1181	1176	1903	1434	1177
	2207	2188	1910	1402	1175	1174
	2302	2285	2190	2118	2117	1939
	1909	1908	1907	1906	1905	1904
	1901	1900	1899	1868	1824	1818
	1699	1698	1680	1639	1630	1531
	1399	1286	1179	1178	1155	
Sheng Chia _____	1908					
Sherwood _____	2309					
Shintom _____	1466					
Shintoshi _____	1466					
Shivaki _____	1377	1466	1402	1399	1137	
Shogun _____	2190	2188				
Shorai _____	1722					
Show _____	1140					
Siam _____	1418					
Siarem _____	1793					
Sicatel _____	1792					
Siemens _____	1466	1820	1814	1811	1676	1510
	1499	1486	1416	1408	1407	1402
Siena _____	1402					
Siera _____	1402					

TV Brands _____ 4-digit television brand codes

Sierra _____	1400	1402	1399			
Sigmax _____	1258					
Signature _____	2130	2007	1639			
Signet _____	1877					
Silma _____	1402	1401				
Silva Schneider _____	1466	1703	1631	1781	1704	1649
	1640	1629	1574	1450	1440	1434
	1406	1402	1394	2057	1783	1705
	1686	1566	1562	1557	1486	1483
	1465	1463	1456	1455	1422	1140
SilverCrest _____	1434	1394	1382	2174	1413	
Simpson _____	2165	2164				
Singer _____	1402	1793	1401	1140		
Sinotec _____	1466					
Sinudyne _____	1402	1449	1417	1401	1377	1813
	1799	1793	1781	1721	1572	1508
	1468	1447	1404	1399	1307	
Sky _____	1758	1737	1601	1583	1560	1418
	1313	1265				
Sky Media _____	1686	1685	1654	1574	1546	1758
	1736	1720	1693	1649	1641	1635
	1601	1593	1583	1566	1560	1313
	1311	1265				
Skyworth _____	1181	2294				
Smaragd _____	1146	1145				
SMARTVISION _____	1639	1474				
Snyder _____	1402					
Sogo _____	1450	1449	1455	1447	1411	
Sole _____	1746	1744	1466	1465	1142	
Sonitron _____	1624	1626				
SONiX _____	1758	1641				
Sonoko _____	1402	1401	1263	1140		
Sonolor _____	1624					
Sontec _____	1402					
Sony _____	1400	1503	1508	1509	1507	1499
	1181	1889	1163	1162	1884	1506
	1504	1500	1402	2062	2061	1891
	1886	1885	1823	1512	1502	1501
	1434	1399	1315	1287	1164	1161
Soundcolor _____	1466	1791	1486	1468	1449	1447
	1411	1394	1377			

TV Brands _____ 4-digit television brand codes

Soundesign _____	2188	2307	2190	2165	2164	1963
	1961	1615	1258			
Soundmaster _____	1140					
Sova _____	2354	2301	2300			
Soyo _____	2267	2102	1865			
Space Tek _____	1599					
Spectra _____	2108	1143				
Spectravisio _____	2186					
Spectrician _____	1402					
Spectroniq _____	1651					
Splash Vision _____	1697					
Sr2000 _____	1624					
SSS _____	2190	1963	1961			
Standard _____	1140					
Star _____	1377	1772	1719	1466	1402	1261
Star General _____	1773					
Starlite _____	1963	1961	1466	1140		
Starlux _____	1140					
Staßfurt _____	1788					
Strato _____	1377	1707	1263			
Studio Experience _____	2296					
SunBriteTV _____	2161	1888				
Sungoo _____	1645					
Sunkai _____	1721	1649	1572	1449	1447	1411
Sunny _____	1685					
Sunrise _____	1147					
Sunstar _____	1140					
Sunstech _____	1574	1580	1840	1613	1612	1575
	1568	1453	1434			
Sunwatt _____	1402					
Sunwood _____	1402					
Superscan _____	2095	2324	2323	1908	1907	
Supersonic _____	1399	2196	2097	1686	1615	
Supertech _____	1402	1140				
Supra _____	2190	1875	1140			
Supratech _____	1659	1657	2116	1749	1723	1653
	1649	1549				
Supremacy _____	2362	2163				

TV Brands _____ 4-digit television brand codes

Supreme _____	1886	1884				
SVA _____	1745	2373	2324	1772		
SWEDX _____	2180					
Sweex _____	1649	1566	1548			
Swisstec _____	1758	1686	1685	1583	1755	1745
	1737	1736	1720	1693	1654	1641
	1635	1601	1593	1582	1574	1566
	1560	1449	1313	1311	1265	
Syc Line _____	1140					
Sylvania _____	1729	2324	2321	2188	2322	2203
	2190	2165	2164	2054	2048	2026
	2013	2007	1990	1906	1602	1443
	1402					
Symphonic _____	2324	2323	2137	2136	1963	1961
	1729					
Syntax _____	2200	2113	2345	2193	2114	
Syntax-Brilliant _____	2200					

T

Tadistar _____	1466					
Tahoci _____	2255					
Talent _____	1615					
Tandberg _____	1820	1651	1394			
Tandy _____	1908	1868	1181			
Targa _____	2174	1296				
Tashiko _____	2225	2128	1677			
Tatung _____	1402	2244	1466	1401	2272	2271
	2243	2242	2241	1803	1680	1486
	1478	1470	1462	1456	1430	1374
	1290	1146				
Tauras _____	1629					
TCL _____	2088	2089	1840	1520	1434	1340
TCM _____	1377	1449				
Teac _____	2134	1546	1413			
Teak _____	1399	1402	1140			
TEC _____	1811	1143	1140			
Techline _____	1434	1394	1382	1463	1390	
Technica _____	1394	1450	1434	1781	1455	1258
Technical _____	1434	1382	1413	1394		

TV Brands _____ 4-digit television brand codes

Technics _____	1208	1402	1924	1503	1401	1205
Technika _____	1686	1605	1434	1574	1546	1833
	1651	1631	1394	1382		
Techniland _____	1402	1401				
Technisat _____	1404	1374	1836	1807	1781	1402
	1400	1388				
Technisson _____	1449	1447	1411			
Technol _____	1399	1402	1140			
Technosonic _____	1402					
Technotrend _____	1755	1402				
Techwood _____	1434	1394	1382	2188	1413	2190
	1615	1387	1258	1178		
Tecnimagen _____	1402	1449	1398			
Tecnison _____	1466	1140				
TECO _____	1649					
Tedelex _____	1402	1140				
Teknant _____	1402	1401	1140			
Teknika _____	2188	2307	2227	2224	2190	2165
	2164	2163	2007	1976	1963	1961
	1958	1957	1922	1898	1892	1615
	1258	1205				
Tekon _____	1258	1140				
Teleavia _____	1823	1822	1820	1818	1814	
Teleco _____	1444					
Telefac _____	1140					
Telefunken _____	1434	1339	1449	1824	1823	1814
	1440	1976	1829	1822	1821	1820
	1818	1817	1816	1791	1700	1615
	1468	1447	1402	1394	1389	1382
	1376	1372	1371	1362		
Teleopta _____	1140					
Telerent _____	1401					
Telestar _____	1466	1404	2057	1820	1486	1456
	1140					
Telesystem _____	1463	1434	1377			
Teletech _____	1394	1434	1382	1787	1487	1140
Teleview _____	1466	1450	1486	1455		
Telra _____	1466	1486				
Tempest _____	1140					
Tensai _____	1402	1798	1791	1468	1466	1451
	1449	1447	1401	1399	1140	

TV Brands _____ 4-digit television brand codes

Tenson _____	1140					
Tera _____	2190	2188	1867			
TERRA _____	1683	1649	1602	1389		
Terris _____	1434					
Tesco _____	1686					
Tesla _____	1449	1402	1786	1468	1466	1447
	1445	1411	1377			
Tevion _____	1449	1394	1686	1466	1382	2244
	1787	1744	1741	1707	1646	1593
	1486	1480	1447	1411	1406	1377
Thomas _____	1677	1402	1258			
Thomson _____	1339	1824	1823	1181	1154	1818
	1520	1829	1822	1820	1817	1814
	1802	1700	1686	1654	1600	1594
	1468	1466	1449	1424	1420	1372
	1344	1342	1341	1340	1338	1157
	1156					
Thorn _____	1402	1399	1677	1639	1166	1826
	1824	1823	1822	1820	1818	1802
	1676	1643	1626	1625	1508	1466
	1401	1393	1255			
Thorn-Ferguson _____	1402	1399	1829	1823	1822	1820
	1818	1802	1509	1508	1401	
Time _____	1568	1377				
TMK _____	2188	1615	2190	1258		
TNCi _____	2070					
Tobo _____	1140					
Tokai _____	1402	1398	1382			
Tokyo _____	1258	1147				
Tophouse _____	2343	2065	1963			
Toshebia _____	1772					
Toshiba _____	1400	1639	1630	2224	1637	1394
	1449	2226	2238	2234	2219	1980
	1434	1402	1399	1284	1258	1205
	2314	2245	2229	2168	1302	2352
	2335	2236	2235	2231	2225	2221
	2220	2216	2215	2213	2207	2167
	1981	1976	1908	1662	1643	1642
	1638	1634	1628	1626	1624	1615
	1602	1488	1447	1401	1377	1301
	1299	1217	1209	1156	1140	
Tosonic _____	1258					
ToteVision _____	2128					
Transonic _____	1402					

TV Brands _____ 4-digit television brand codes

TRC _____	1466	1140			
Trevi _____	2228	1574	1566	1140	
Triad _____	1402	1399			
Triax _____	1471	1339			
Trilux _____	1402	1787	1629	1404	1374
Triumph _____	1572				
TriVision _____	1140				
TruTech _____	2139	2366	2142	2141	2140
TVS _____	1994				
TWF _____	1741	1707			

U

Uher _____	1402	1509	1401	1399		
Ultravox _____	1402					
UMA _____	1399	1402	1823	1820	1814	
UMC _____	1686	1685	1654	1574	1546	1758
	1736	1720	1693	1649	1641	1635
	1601	1593	1583	1566	1560	1313
	1311	1265				
Unimor _____	1402					
United _____	1449	1434	1394	1612	1566	1382
	1377	1302	1791	1707	1651	1611
	1576	1574	1573	1447	1411	1402
UnityDigitalTV _____	1296					
Universal _____	2183	2181	2146	2143		
Universum _____	1400	1402	1394	1508	1434	1399
	1787	1509	1350	1820	1790	1466
	1401	1395	1390	1362	1351	1263
	1140					
Univox _____	1402					
Uranya _____	1140					
US Logic _____	2244					

V

Vanguard _____	1434	1140			
Vasilinec _____	1140				
Veco _____	1402	1140			
Vector _____	1613				
Vector Research _____	2203				

TV Brands _____ 4-digit television brand codes

Venturer _____	2199					
Veseg _____	1382	1434				
Vestel _____	1434	1394	1402	1382	1787	1413
	1639	1441	1395	1390	1374	
Vexa _____	1402	1140				
Victor _____	1916	1914	1186			
Videcon _____	1402					
Video System _____	1402					
Videseven _____	1758	1601	1510			
Videoton _____	1434	1823	1819	1790		
Vidikron _____	2007	1743				
Vidion _____	1140					
Viditel _____	1263					
Vidtech _____	2188	2190	1898	1615		
Viewpia _____	1754					
ViewSonic _____	1310	2095	2360	2275	2122	2120
	1737	1421	2319	2274	2121	2091
	2012	1841	1727	1700	1560	1389
Viking _____	2362	2163				
Viore _____	2361	2328	2326	1840	1686	1286
Visart _____	2341					
Vision _____	1449	1447	1140			
Vision Plus _____	1686					
Visual Innovations _____	1686					
VIVAX _____	1660	1708	1685	1639	1474	1377
	2066	1750	1706	1649	1636	1468
	1467	1422	1402			
Vizio _____	1607	1610	2272	2271	2268	2197
	2192	2120	2095	1751		
Vogells _____	1599					
Vortec _____	1402					
VOX _____	1434	1425				
Voxson _____	1449	1377	1466	1447	1411	1402
VTQ _____	1788					

TV Brands _____ 4-digit television brand codes

W

Waltham _____	1394	1434	1382			
Wards _____	2207	2188	2085	1615	2307	2236
	2226	2216	2203	2190	2183	2181
	2164	2146	2143	2138	2137	2136
	2082	2078	2070	2013	2007	2006
	2001	1963	1898	1884	1869	1402
	1258	1186				
Watson _____	1394	1449	1402	1787	1646	1583
	1447	1434	1411	1390	1140	
Watt Radio _____	1799	1793	1790	1466		
Waycon _____	2226					
Wegavox _____	1790	1402	1401	1140		
Welltech _____	1449	1447				
Welstar _____	1394	1434	1583			
Weltblick _____	1402					
Westinghouse _____	1884	2120	2315	2125	1979	1978
	1967	1966	1889	1879	1503	1155
Wharfedale _____	1382	1377				
White-Westinghouse _____	1394	1402	1399	1878	2384	1994
	1979	1889	1873	1872	1871	1790
	1624	1426	1408			
Wilson _____	1685					
Winco _____	1946					
Windsor _____	1394	1818	1787	1434	1382	
Winston _____	1402	1401	1140			
Winternitz _____	1140					
Wizja _____	1374					
World of Vision _____	1449	1311	1282			
World-Tech _____	1143					
Worldview _____	1402	1399	1140			
Wyse _____	1700					

X

Xion _____	1565
Xoro _____	1756

TV Brands _____ 4-digit television brand codes

Y

Yalos _____	1741					
Yamaha _____	2188	2360	2203	2190	1898	1672
	1671	1666	1639	1602	1205	
Yevici _____	1140					
Yokan _____	1402					
Yoko _____	1402	1624	1820	1434	1263	1143
	1140					
York _____	1626	1402				
Yoshita _____	1402					
Yotaka _____	1402					

Z

Zanussi _____	1603	1434				
Zenith _____	1602	1615	2257	1517	2068	2360
	2256	2203	2201	2190	2188	2130
	2128	2082	2071	2070	2069	1994
	1990	1989	1987	1957	1955	1884
	1878	1872	1869	1700	1662	1418
	1402	1284				

DVD/BluRay Player Brands

A

Acer _____	1234					
AEG _____	1280	1278	1649			
Afreey _____	1659					
AgfaPhoto _____	1610					
Airis _____	1521					
Aiwa _____	1738	1737	1206			
Akai _____	1650	1649	1624	1560	1259	1233
	1211					
AKI _____	1609	1608				
Akira _____	1634					
Akura _____	1465					
Alba _____	1622	1514	1473	1259	1206	1205
All-Tel _____	1101					
Altek _____	1636					
Amoisonic _____	1721					
Amstrad _____	1259					
Ansonic _____	1278	1573	1524			
Appro _____	1618					
Arcam _____	1254					
Arcelik _____	1275	1266				
Arena _____	1233					
Aristona _____	1298					
Arthur-Martin _____	1280					
Ascomtec _____	1502					
Audiosonic _____	1560					
Auvio _____	1489					
Axil _____	1522	1260	1257			

B

Bang & Olufsen _____	1761	1412				
Basic Line _____	1259					
Baze _____	1579					
Beko _____	1610	1275	1273	1266		
Belgacom _____	1421					

DVD/BluRay Player Brands _____ 4-digit DVD/BluRay player brand codes

Bellagio _____	1576					
Belson _____	1769	1753	1634	1539	1507	
Bensten _____	1766					
Best Buy _____	1765					
Blaupunkt _____	1622	1280				
Blue Sky _____	1278	1747	1642	1489	1259	1229
	1221	1220	1206			
Blusens _____	1585	1619	1559	1558	1557	1555
	1531	1482				
Bosch _____	1280					
Bose _____	1758	1212				
Boxford _____	1675	1674	1450			
Brandt _____	1221	1220	1747			
Brignton _____	1555					
Brionvega _____	1274					
Britannia _____	1504					
Bush _____	1622	1573	1560	1541	1537	1524
	1514	1486	1259	1237	1206	1149

C

Cablecom _____	1298					
Cambridge _____	1787	1786	1759	1463	1267	
Caratec _____	1612					
CAT _____	1493	1492	1491	1487		
Centrum _____	1492	1259				
CGV _____	1473	1463				
Changhong _____	1784					
Charisma _____	1426					
Cinemateq _____	1442					
Cinex _____	1278					
Clatronic _____	1649	1537	1455			
Clayton _____	1259					
CMX/Commax _____	1455	1477	1793	1792	1613	1567
	1528	1522	1516	1511	1508	1485
	1483	1476	1474	1472	1466	1461
	1458	1454	1448	1447	1445	1268
Combi _____	1651					
Conceptronic _____	1506					
Conia _____	1721	1573				

DVD/BluRay Player Brands _____ 4-digit DVD/BluRay player brand codes

Continental Edison _____	1233	1792			
Crown _____	1747	1560			
Cybercom _____	1524				
Cyberhome _____	1658	1657	1656		
Cyrus _____	1707	1248			
Cytron _____	1747	1552	1524		

D

Daewoo _____	1752	1618	1555	1449	1321	1114
	1103	1102	1100			
Dalton _____	1487					
Dangaard _____	1585	1648	1636	1556	1555	
Dansai _____	1645					
Dantax _____	1514	1261				
Daytek _____	1575					
DCE _____	1503					
Decca _____	1278					
Denon _____	1111	1134	1164	1112	1110	1168
	1166	1165	1109			
Denver _____	1624	1585	1555	1788	1770	1649
	1647	1598	1581	1556	1537	1499
Diamond _____	1747	1514	1463			
Digihome _____	1259	1233				
Digiloc _____	1505					
Digitech _____	1259					
DIK _____	1524	1446				
Dinamic _____	1649					
Dk Digital _____	1524					
DMTech _____	1653	1540	1277	1233		
DQT _____	1741	1565				
Dragon _____	1524					
Dual _____	1747	1562	1524	1259		

E

E-Boda _____	1514				
E-Max _____	1720	1623	1461	1459	1456
eBench _____	1703				
ECG _____	1598				

DVD/BluRay Player Brands _____ 4-digit DVD/BluRay player brand codes

Eclipse _____	1514	1463				
Elbe _____	1582	1571	1569	1530	1525	1517
	1478	1462	1461	1271	1261	1259
	1233					
Electrohome _____	1233					
Elemis _____	1278					
Elta _____	1560	1497	1649	1632		
Emerson _____	1617	1175				
Encore _____	1659					
Essentiel b _____	1708	1497	1481	1455		
Euroline _____	1649	1648	1257			

F

Ferguson _____	1532	1220	1790	1789	1773	1747
	1652	1523				
Final _____	1677					
Finlux _____	1234	1278	1463	1449	1261	1257
	1237	1233				
First Line _____	1747	1383				
Fluid _____	1794					
Fonestar _____	1635	1633				
Fujitsu Siemens _____	1175					
Funai _____	1309	1755	1745	1206		

G

Game _____	1638					
GE _____	1622					
General _____	1280					
GoGEN _____	1233					
GoldStar _____	1175	1181				
Goodmans _____	1747	1648	1560	1537	1514	1501
	1272	1104				
Gorenje _____	1350					
GPX _____	1175					
Graetz _____	1261	1257				
Gran Prix _____	1628	1278	1647	1631	1630	1627
Granada _____	1130					
Grandin _____	1233					

DVD/BluRay Player Brands _____ 4-digit DVD/BluRay player brand codes

Grundig _____	1407	1326	1280	1760	1722	1713
	1699	1643	1551	1514	1473	1463
	1411	1410	1409	1408	1406	1303
	1275	1259	1240	1206	1205	1178
	1175	1134				

H

H&B _____	1537	1259				
Haier _____	1586					
Hanseatic _____	1273					
Harman/Kardon _____	1667	1669				
HB _____	1540					
HCM _____	1649					
Henß _____	1259					
Himage _____	1486	1453				
Hitachi _____	1666	1663	1731	1665	1664	1234
	1233	1612	1261			
Höher _____	1446	1259				
Home Electronics _____	1449					
Hoyo _____	1564					
Hyundai _____	1636	1233				

I

Imperial _____	1708					
Ingelen _____	1649					
Insignia _____	1684					
Ipure _____	1709	1610				
ISP _____	1298	1206				
ITT _____	1234	1280	1217			

J

Jamo _____	1570	1255				
JBL _____	1667					
Jeutech _____	1488					
JMB _____	1206					
Jocel _____	1608					
JVC _____	1120	1114	1121	1123	1118	1116
	1200	1162	1129	1128	1127	1126
	1125	1124	1122	1119	1115	1113

DVD/BluRay Player Brands _____ 4-digit DVD/BluRay player brand codes

K

Karcher _____	1278					
Kendo _____	1259	1220	1234	1221		
Kenmark _____	1617	1264				
Kenwood _____	1678	1175	1679	1134	1682	1681
	1680	1298	1161	1138		
Kiiro _____	1609	1608				
Kingavon _____	1537					
Kiss _____	1252	1262	1246			
Koda _____	1537					
Kogan _____	1792					
Konka _____	1536					
Koss _____	1747					
Kotron _____	1505					
Kriminal Forsorgen _____	1269					

L

Labwave _____	1574	1568				
Labway _____	1535					
Lasonic _____	1564					
Lecson _____	1645	1267				
Lenco _____	1752	1747	1708	1616	1585	1537
	1524	1259	1233			
LG _____	1175	1183	1185	1176	1756	1698
	1584	1186	1184	1182	1180	1179
	1177					
Lifetec _____	1747	1524				
Linn _____	1253	1247				
Listo _____	1625	1553				
Liteon _____	1655					
Loewe _____	1130	1297	1763	1444	1366	1334
	1303	1175				
Logik _____	1795	1777	1618	1583		
Loomax _____	1471					
Lumatron _____	1634	1540	1490	1259		
Luxor _____	1261	1234	1233			

DVD/BluRay Player Brands _____ 4-digit DVD/BluRay player brand codes

M

Magnavox _____	1298					
Magnex _____	1514					
Marantz _____	1298	1228	1164	1338	1305	1304
	1227	1226	1166	1165	1111	
Mark _____	1490	1259				
Mascom _____	1278	1598	1271			
Matsui _____	1259	1747	1662	1206		
Maxim _____	1453					
MBL _____	1304					
MBO _____	1560					
Mbyn _____	1256	1250				
Media Station _____	1599					
Medialine _____	1753					
Mediencom _____	1644	1509	1504			
Medion _____	1779	1778	1748	1747	1694	1539
	1524	1479	1452	1446	1278	1233
Megatone _____	1457					
Memorex _____	1524	1282				
Metz _____	1424	1259	1438	1429	1428	
Mico _____	1514	1463				
Microboss _____	1609					
Micromax _____	1206					
Microsoft _____	1740	1416				
Minax _____	1259					
Minowa _____	1101					
Mirai _____	1673					
Mitsubishi _____	1574	1259	1106			
Mizuda _____	1537					
MP _____	1489					
MPX _____	1489					
MTC _____	1626					
Multitech _____	1278					
Mustek _____	1676	1675	1674	1672		
Mx Onda _____	1747	1520	1514	1463	1269	
Myryad _____	1235					

DVD/BluRay Player Brands _____ 4-digit DVD/BluRay player brand codes

N

NAD _____	1671					
Naim _____	1249					
Nevir _____	1233					
Nikkei _____	1636					
Nintaus _____	1518					
Nordmende _____	1524	1221	1220			
NPG _____	1784	1460				

O

ODYS _____	1753	1752	1751	1750	1686	1614
	1612	1611	1610	1587	1529	1515
	1470	1468				
OKI _____	1784	1774	1261	1234	1233	
Onkyo _____	1691	1693	1688	1744	1692	1690
	1689	1687				
ONN _____	1618					
Optim _____	1645	1489				
Optimus _____	1429	1428				
Orion _____	1206	1266	1257	1208	1207	1203
Oritron _____	1747					

P

P&B _____	1537					
Pacific _____	1573	1524	1259			
Palladium _____	1278	1259	1206			
Panasonic _____	1130	1134	1131	1146	1144	1135
	1145	1151	1153	1139	1133	1159
	1158	1157	1132	1430	1261	1210
	1163	1160	1155	1154	1152	1148
	1147	1143	1142	1141	1140	1137
	1136					
Peacock _____	1540					
Philips _____	1298	1301	1296	1309	1308	1306
	1362	1304	1303	1302	1287	1363
	1357	1345	1344	1343	1342	1242
	1316	1311	1310	1299	1297	1290
	1730	1365	1356	1355	1353	1352
	1351	1348	1341	1332	1331	1328
	1321	1314	1313	1307	1295	1245
	1236	1230	1747	1685	1684	1683

DVD/BluRay Player Brands _____ 4-digit DVD/BluRay player brand codes

Philips _____	1655	1654	1622	1533	1368	1367
	1364	1361	1360	1359	1358	1354
	1349	1347	1346	1340	1339	1337
	1336	1335	1333	1330	1329	1327
	1324	1323	1322	1320	1319	1318
	1317	1315	1312	1305	1300	1294
	1292	1291	1289	1288	1286	1285
	1270	1244	1243	1241	1239	1192

Phocus_____1407

Pioneer _____	1424	1439	1426	1440	1417	1438
	1434	1421	1441	1437	1436	1435
	1433	1432	1431	1430	1429	1428
	1427	1423	1422	1420	1419	1418
	1298	1215	1214	1213		

Polsat_____1568

Popcorn_____1696

Powerpoint_____1634 1609 1608

Prima_____1650

Primare_____1276

Pro2_____1452

Profilo_____1278

ProLine_____1747 1279 1618 1617 1563 1501
1283 1281 1278 1269 1265

ProScan_____1416

Prosonic_____1616 1585 1257 1636 1556 1555
1464 1261 1233

Provision_____1675 1620 1537

Q

Quadro_____1701 1641 1639 1526

Quelle_____1259

R

Radiola_____1298

RCA_____1416

Realmagic_____1554

REC_____1650 1504 1149 1134

Red Star_____1278 1649 1592 1573 1527 1512
1500 1452

Reel_____1443

Reflexion_____1776 1612

DVD/BluRay Player Brands _____ 4-digit DVD/BluRay player brand codes

Rex _____	1513					
Roadstar _____	1560	1537	1259	1149		
Romeo _____	1469					
Rotel _____	1615	1125				
Rowa _____	1573	1622	1428			
S						
SABA _____	1220	1747	1261	1257	1233	1221
Saivod _____	1278	1585	1573			
Salora _____	1233	1780	1612	1610	1598	1585
	1540	1525	1517	1497	1461	1277
	1271					
Sampo _____	1659					
Samsung _____	1194	1731	1201	1733	1193	1734
	1405	1735	1284	1202	1197	1727
	1724	1401	1398	1195	1757	1754
	1736	1732	1729	1728	1726	1725
	1723	1404	1403	1402	1400	1399
	1397	1199	1198	1196	1192	1191
	1190	1189	1188	1187	1171	1170
	1169	1134				
Sansui _____	1514	1463	1206			
Sanyo _____	1699	1278	1233	1261	1206	1100
Scansonic _____	1413					
Schaub Lorenz _____	1234	1702	1649	1647	1636	1634
	1607	1598	1540	1497		
Schneider _____	1298	1278	1747	1649	1591	1590
	1589	1561	1524	1304	1175	
Scott _____	1747	1708	1609	1608	1585	1520
	1309					
Screenlant Tft _____	1591	1590				
SEG _____	1259	1257	1784	1702	1575	1574
	1572	1510	1455	1100		
Sencor _____	1780	1598				
Sharp _____	1172	1108	1173	1711	1259	1234
	1233	1206	1203	1174	1167	1107
Sherwood _____	1670	1622	1175			
Shinco _____	1622					
Siemens _____	1278	1306				
Sigma _____	1554					
Silva Schneider _____	1446	1451	1278	1780	1649	1641
	1630	1629	1628	1627	1598	1591
	1590	1562	1524	1497	1496	

DVD/BluRay Player Brands _____ 4-digit DVD/BluRay player brand codes

SilverCrest _____	1779	1706	1705	1704	1702	1640
	1259	1233				
Sinotec _____	1721					
Sky Media _____	1660	1617	1555			
Skyworth _____	1650					
SM Electronics _____	1560					
Smart _____	1609	1259				
SMARTVISION _____	1771					
SMC _____	1541					
Sony _____	1383	1376	1378	1389	1369	1394
	1392	1386	1385	1393	1391	1387
	1377	1739	1637	1396	1395	1390
	1388	1384	1382	1381	1380	1379
	1375	1374	1373	1372	1371	1370
	1306	1213	1112	1105		
Soundcolor _____	1278	1259				
Standard _____	1747	1649				
Starmedia _____	1537					
Strong _____	1568					
Sunkai _____	1449					
Sunstech _____	1585	1796	1766	1569	1558	1555
	1540	1525	1269	1233		
Sunwood _____	1649					
Supertech _____	1480					
Supratech _____	1769	1697	1662	1577	1510	
Sweex _____	1612	1539				
Swisstec _____	1660	1617	1555			
Sylvania _____	1755					

T

Tandberg _____	1259					
Targa _____	1779					
Tatung _____	1278	1534				
Tboston _____	1522					
TCL _____	1223	1220				
TCM _____	1561					
Teac _____	1775	1671	1573	1494	1429	
Techline _____	1259					
Technical _____	1257	1233				

DVD/BluRay Player Brands _____ 4-digit DVD/BluRay player brand codes

Technics _____	1131	1134	1135	1158	1133	1130
	1159	1156	1154	1153	1152	1151
	1150	1145	1143	1142	1132	
Technika _____	1684	1583	1233	1797	1796	1752
	1617	1555				
Technotrend _____	1407					
Techwood _____	1233	1261	1259	1257	1234	
Telefunken _____	1233	1220	1263	1234	1231	1221
Telestar _____	1278					
Telesystem _____	1233					
Teletech _____	1283	1259				
Teleview _____	1278					
Telra _____	1278					
Tensai _____	1747	1560				
TERRA _____	1586	1232				
Terratec _____	1453					
Terris _____	1791					
Tevion _____	1747	1278	1749	1712	1701	1636
Theta Digital _____	1429					
Thomson _____	1218	1220	1415	1221	1298	1762
	1617	1467	1416	1263	1225	1224
	1223	1222	1219			
Time _____	1540					
Tokai _____	1659	1649				
Tokaido _____	1659					
Topfield _____	1668					
Toshiba _____	1600	1717	1601	1782	1719	1716
	1715	1700	1606	1233	1799	1798
	1785	1718	1714	1695	1666	1605
	1604	1603	1602	1596	1206	1204
	1130	1127				
Tredex _____	1489					
TrekStor _____	1495					
Trevi _____	1783	1539				
Triax _____	1568	1224				

DVD/BluRay Player Brands _____ 4-digit DVD/BluRay player brand codes

U

Umax _____	1560	1535				
UMC _____	1660	1617	1555			
Unibrain _____	1720					
Unicorn _____	1475					
United _____	1585	1261	1675	1649	1647	1646
	1636	1621	1556	1555	1539	1538
	1266	1259	1257	1233	1206	
Universum _____	1259	1710	1597	1570	1175	

V

Vector _____	1585					
Vestel _____	1261	1257	1233	1716	1259	1234
VIVAX _____	1526	1764	1772	1768	1767	1766
Vizio _____	1519	1498				
VOX _____	1233					
Voxson _____	1524					

W

Walkvision _____	1622					
Waltham _____	1233					
Welkin _____	1524					
Wharfedale _____	1659	1514	1463	1279	1267	1258
	1257					
Woxter _____	1632	1593				

X

Xoro _____	1595	1512	1484			
Xwave _____	1535					

Y

Yakumo _____	1581	1580	1578			
Yamaha _____	1298	1134	1545	1666	1663	1661
	1600	1550	1549	1548	1547	1546
	1350	1345	1297			
Yamakawa _____	1746	1594				
Yelo _____	1609	1608				

Amplifier Brands

A

Accuphase_____	3347	3198			
AEG_____	3246				
Aiwa_____	3372	3376	3375	3371	3369
Akai_____	3311	3348	3339	3306	
Alba_____	3342	3179	3160		
Alco_____	3253	3176			
Amstrad_____	3160	3377	3312	3309	3164
Arcam_____	3229	3228	3224	3217	
Artdio_____	3363				
Arthur-Martin_____	3246				
Avantgarde_____	3224				

B

Bang & Olufsen_____	3271				
Blaupunkt_____	3246				
Bosch_____	3246				
Bose_____	3391	3397	3390	3396	
Boxford_____	3305				
Braun_____	3392				
Bush_____	3364	3190	3160		

C

Cambridge_____	3398	3224	3221	3403	3404	3402
	3401	3400	3399	3236		
Casio_____	3195					
CMX/Commax_____	3282	3283	3288	3285	3284	
Creek_____	3320					
Crestron_____	3216					
Crown_____	3171					
Cyrus_____	3217					

Amp Brands _____ 4-digit amplifier brand codes

D

Daewoo _____	3353	3125				
Davis _____	3224					
Denon _____	3112	3108	3115	3114	3150	3116
	3325	3151	3149	3117	3113	3111
	3109	3107				
Diora _____	3394					
Dual _____	3314	3307				

E

Eclipse _____	3201					
Elbe _____	3282					
Elta _____	3387					

F

Ferguson _____	3287					
Fidek _____	3321					
Fisher _____	3323	3322	3250			

G

General _____	3246					
GoldStar _____	3187					
Goodmans _____	3348	3317	3190			
Gorenje _____	3295					
Grundig _____	3246	3365	3310	3270	3244	3224
	3186	3185	3180			
Gryphon _____	3224					

H

Harman/Kardon _____	3332	3338	3331			
Hifidelio _____	3225					
Hitachi _____	3325	3204				

Amp Brands _____ 4-digit amplifier brand codes

I

ITT _____ 3378 3246

J

Jamo _____ 3237

JBL _____ 3239 3206

JVC _____ 3125 3124 3381 3297 3199 3132
 _____ 3131 3127 3126 3123 3106

K

Kenwood _____ 3355 3315 3313 3327 3224 3178
 _____ 3110

L

Lenco _____ 3190

LG _____ 3195 3187 3178 3182

Linn _____ 3224 3222 3217

Logitech _____ 3366

Luxman _____ 3336 3335 3333 3153

M

Marantz _____ 3217 3224 3242 3235 3215 3151
 _____ 3114

Matsui _____ 3251

MBL _____ 3241

Medion _____ 3308 3160

Mercedes-Benz _____ 3395 3200

Meridian _____ 3224

Minowa _____ 3289

Mission _____ 3226

Musical _____ 3168

Amp Brands _____ 4-digit amplifier brand codes

N

NAD _____	3354					
Naim _____	3217					
Nakamichi _____	3367	3326				
Niam _____	3224					
Nokia _____	3378	3181				

O

Okano _____	3349	3345				
Onkyo _____	3359	3204	3362	3360	3358	3357
	3356	3318	3205			

P

Palladium _____	3339	3334	3202	3161		
Panasonic _____	3133	3141	3136	3134	3144	3143
	3138					
Peacock _____	3366	3363	3321			
Philips _____	3217	3219	3224	3254	3218	3260
	3259	3243	3261	3256	3236	3393
	3262	3258	3257	3255	3247	3238
	3235	3233	3232	3230	3221	3220
Pioneer _____	3209	3274	3208	3207	3279	3224
	3211	3210	3280	3278	3277	3276
	3275	3213	3212			
Primare _____	3245					
Pro-Logic _____	3346					

Q

Quad _____						
3224 _____						
Quadro _____	3304					

Amp Brands _____ 4-digit amplifier brand codes

R

Radiola _____	3217					
Radiotone _____	3165					
Radmor _____	3238	3234	3231			
Reel _____	3281					
Revox _____	3235	3233	3232	3227		
Rotel _____	3385	3384	3340			

S

Samsung _____	3155	3370	3269	3154	3382	3253
	3199	3148	3147			
Sanyo _____	3323	3324	3316			
Schneider _____	3190	3160	3378	3339	3191	3189
	3169	3167	3386	3350	3224	3217
	3187	3165	3163	3383	3379	3377
	3374	3368	3345	3342	3328	3291
	3289	3194	3193	3192	3177	3175
	3174	3173	3172	3170	3164	3162
Sharp _____	3118	3120	3119	3110		
Sherwood _____	3344	3337	3203			
Siemens _____	3160	3350	3252	3249	3187	3353
	3352	3351	3348	3345	3343	3248
	3224	3223	3183	3162		
Silva Schneider _____	3188	3187				
SilverCrest _____	3282					
Sinotec _____	3166					
Sony _____	3265	3103	3267	3263	3268	3266
	3264	3208	3112	3105	3104	
Supertech _____	3190					

T

Teac _____	3286					
Technics _____	3133	3141	3136	3146	3145	3142
	3140	3139	3137	3134		
Thomson _____	3272	3341	3224	3214		
Topfield _____	3128					
Toshiba _____	3120					

Amp Brands _____ 4-digit amplifier brand codes

U

Uher _____ 3380

Universum _____ 3382 3348 3345 3194 3190 3155

V

Vincent _____ 3290

Vizio _____ 3273

Y

Yamaha _____ 3297 3294 3293 3296 3329 3298
 3292 3389 3388 3330 3319 3303
 3302 3301 3300 3299 3295 3121