

# Saga Logger – Display Icons and Alerts Directory

**Shipment status** — Shows "Free" if not in an active shipment

**Temperature** — Shows last registered temperature and max/min values if in a shipment

**Battery status** — Shows remaining percentage and charging status

**Alarm status** — Empty if no alarm has occurred during the shipment

**Cloud connection status** — Shows the connection status at the last wake-up

## Shipment status







<b>Free</b>	The device is in standby mode and has not received any information about being allocated to a shipment.
<b>Paired</b>	The device has received shipment information from the Cloud, starting conditions have not yet been met.
<b>Shipping</b>	The device is paired to a shipment that met start conditions; data is uploaded to the Cloud as per wake-up interval.
<b>Stopping</b>	The stop button is pushed while the device is in an active shipment.
<b>Stopped</b>	Stopping conditions are met; the logger has been delivered.

## Temperature status





<p>Max 24.8°C</p> <p><b>23.5°C</b></p> <p>Min 22.4°C</p>	The center displays the last registered temperature. Max/min range is shown above/below while the device is in an active shipment. Max/min temperature ranges are defined within the shipment creation.
<p>Display does not function in the current temperature.</p>	The display is inactive due to the <b>temperature being below 0°C or above 50°C</b> . The device continues to function and collect data within its operating range.

# Saga Logger – Display Icons and Alerts Directory


## Battery status

	The display shows a USB icon for a few minutes whenever the device is plugged into a USB port on a charging station or a computer.
	The battery is currently charging – it can charge in a Controlant charging station, USB charging adapter or computer USB port.
	The device is plugged-in, battery is fully charged.
	The remaining battery percentage.
	The device's internal heat reached 40°C / 104F. Charging will re-start once the device cools down.
 <b>Low power mode</b> Logger is now in low power mode. Please charge device.	The battery level is below 10%.


## Cloud connection status

	<b>Syncing:</b> The device is attempting to connect and sync with the Cloud.
	<b>Connected:</b> The device has successfully connected to the Cloud during its last wake-up.
	<b>Failed connection:</b> The device was unable to connect to the Cloud during its last wake-up, usually due to poor cellular reception.
	<b>Flight mode:</b> The device has detected that it's on a flight. It will temporarily stop attempting to connect to the Cloud.

## Alarm status

	Temperature excursion(s) has occurred in the shipment. If no icon is present, the temperature was within range for the full shipment duration.
---	---

## Service message

 <b>Device needs service</b>	The device requires service. Customers are encouraged to set the device aside and follow the existing process to return it to Controlant. The device can only display this message when its status is Free.
--	---