## CAUTION

## **DRUM/SPINDLE SANDER**

## WEAR APPROPRIATE PERSONAL PROTECTIVE EQUIPMENT

(ie. eye, face, hearing etc.)

- Do not mix incompatible dusts (steel and aluminum).
- Never start machine unless all guards are in place, properly designed and adjusted.
- Beware of moving machinery parts.
- Keep work area clean. Foreign materials may cause poor footing.
- Dust collection system, if provided, is connected and operational.
- Use proper abrasive disk and/or belt for material being processed.
- Beware of contact with the unguarded portion of drum/spindle above and below work table.
- Replace disks if abrasive surface has rips, tears, or worn areas.
- Filler plate opening should not exceed 1/8 inch.
- De-energize and lockout all energy systems before making adjustments/ repairs.
- Do not wear gloves, jewelry, or loose clothing.
- Ensure that operator is properly trained and has read owners operation manual.

## Note: Immediately report all machinery malfunctions to management