


# TWISTER T40/T60 ENGINE



|                                   |           |                           |        |
|-----------------------------------|-----------|---------------------------|--------|
| (1) Coolant Drain Cock            | ATE049    | (10) Oil Drain Fitting    | ATE012 |
| (2) Intake Manifold               | ATE052    | (11) Starter              | ATB002 |
| (3) Fuel Pump                     | ATE013    | (12) Oil Filter Cartridge | ATE028 |
| (4) Oil Level Gauge               | ATE054    | (13) Oil Pressure Switch  | ATB005 |
| (5) Speed Control Lever           | ATE046    | (14) Alternator 40 Amp    | ATB028 |
| (6) Injection Pump                | ATE057    | (14A) Alternator 80 Amp   | ATB080 |
| (7) Engine Stop Lever             | ATE047    | (15) Oil Filler Cap       | ATE050 |
| (8) Cooling Fan                   | ATE038    | (16) Exhaust Manifold     | ATE051 |
| (9) Fan Drive Pulley              | ATE048    | (17) Flywheel             | ATE009 |
| (9A) Drive Coupler<br>Engine Side | ATC018-01 | (18) Overtemp Sensor      | ATB011 |
| (9B) Drive Coupler<br>Insert      | ATC018-02 | (19) Idle Solenoid        | ATB006 |
|                                   |           | (20) Fan Belt             | ATE035 |