


INCLINABLE LYRE EASEL


assembly instructions
For model 51753-1040

BLICK art materials


STEP 1




STEP 2



STEP 3



STEP 4




INCLINABLE LYRE EASEL


assembly instructions
For model 51753-1040

BLICK art materials


STEP 5




STEP 6



STEP 7



STEP 8



G (x2) H (x2)

DICKBLICK.COM

A