


**Bradken Cast Lip GET Assembly options**

<b>EX8000 BH</b> 837 Tonnes									
MACHINE TYPE	APPROX. BUCKET CAPACITY (m³)	BRADKEN REF. NUMBER AND DESCRIPTION	BRADKEN DRAWING	INSIDE LIP WIDTH (mm)	QTY OF NOSE POSITIONS	LIP PROFILE	GET TYPE	LIP ASSY APPROX. MASS (kg)*	LIP SHROUD WIDTH (mm)
EX8000 BH	48.0	PCLP45-430 CAST LIP ASSEMBLY	BKG415-11	4300	6	FULL SPADE	MID-ADAPTER & POINT	11985	423
			BKG415-6				SOLID POINT	11872	

\*Lower wing shroud mass included in lip assembly mass calculation. Upper wing shroud mass NOT included in lip assembly mass calculation.

^Refer to document R00036 for Eclipse cast lip assembly installation, removal and maintenance procedures.

**Bradken Cast Lip Assembly options**



**Eclipse® Mid-Adapter and Point GET**



**Solid Point GET**

Contact your local Bradken representative or visit [bradken.com](http://bradken.com) for further information.

