


Eclipse® Cast Lip and Plate Lip GET Assembly options


EX3600 BH 366 Tonnes										
MACHINE TYPE	BUCKET CAPACITY RANGE (m³)	BRADKEN REF. NUMBER AND DESCRIPTION	BRADKEN DRAWING	INSIDE LIP WIDTH (mm)	PLATE LIP SIZE (mm)	QTY OF NOSE OR ADAPTER POSITIONS	WELD-ON ADAPTER KIT NUMBER	GET TYPE	LIP ASSY APPROX. MASS (kg)*	LIP SHROUD WIDTH (mm)
EX3600 BH	19.0 – 24.0	PCLP10-345 ECLIPSE CAST LIP ASSEMBLY	BKG485-3	3450	NA	6	NA	SOLID POINT	6086	322
		PCLP10-356 ECLIPSE CAST LIP ASSEMBLY	BKG484-6	3560				SOLID POINT	6193	344
			BKG484-7					MID-ADAPTER & POINT	6804	344
		PCLP10-373-5 ECLIPSE CAST LIP ASSEMBLY	BKG504-3	3730				5	MID-ADAPTER & POINT	6725
			BKG504-4			SOLID POINT			6266	
		PCLP10-373 ECLIPSE CAST LIP ASSEMBLY	BKG494-4	3730		6		SOLID POINT	6488	372
			BKG494-5					MID-ADAPTER & POINT	7135	
		BL3730-140PPS9B-1 PLATE LIP ASSEMBLY	PE0003021	3730		140		6	PE0007753	SOLID POINT
BL3560-140PPS9B-1 PLATE LIP ASSEMBLY	-	3560	SOLID POINT	5578	420					

*Lower wing shroud mass included in lip assembly mass calculation. Upper wing shroud mass NOT included in lip assembly mass calculation.

**Wing shroud mass included in lip assembly mass calculation.

^Refer to document R00036 for Eclipse cast lips assembly installation, removal and maintenance procedures.

Eclipse® Cast Lip Assembly options



Mid-Adapter and Point GET



Solid Point GET

Plate Lip Assembly options



Solid Point GET

Contact your local Bradken representative or visit bradken.com for further information.

