



# ergobag

0.5 l

## Drinking Bottle

Suitable for carbonated as well as warm beverages

### Info & care tips

All ergobag drinking bottles are dishwasher-safe and free from harmful substances, don't contain any plasticisers or BPA, don't smell or taste like plastic and are also suitable for warm beverages.

#### Materials used:

- The bottle is composed of polypropylene
- The imprint is made from food-grade dye
- The closure is made out of elastomer

### How to enjoy your ergobag drinking bottle for a really long time:

#### 1 Before use:

- Rinse it with at least 65° C hot water by hand or in the dishwasher
- Clean closure only with hot water up to 70°

#### 2 After each use:

- Clean it and let it dry
- Store the bottle and cap separately and opened
- When using beverages other than water, clean the bottle and the cap the same day with washing-up liquid
- When washing it in the dishwasher, make sure that the drinking bottle doesn't make direct contact with the heating element

### A few extra tips

- The drinking bottles are not suitable for children under 3 years of age
- Turn the bottle over to test if the cap is screwed on tightly.
- Open the cap by twisting (see labelling on the mouthpiece)
- Don't open the bottle with your teeth
- Fill the bottle no higher than 1" (2.5 cm) below the top edge
- With carbonated beverages, do not shake the bottle, if possible
- You can release the initial pressure that can develop from fermenting, carbonated or nutrient-rich beverages by carefully untwisting the cap

### Here's how to change the mouthpiece

- 1 You can separate the mouthpiece of the ergobag drinking bottle by pushing it in and out while at the same time pulling the cap.
- 2 After cleaning, you reintegrate the closure in the cap by pressing it in. Moisten the mouthpiece with some water before inserting so that there is no leakage. Then check the cap from the inside: Does the closure have the correct position again between the margins? If so, you can close the bottle completely.
- 3 For good measure, turn the closure in the OPEN direction and open it by pulling. You close the bottle by pressing and turning in the CLOSE direction. You'll now see inside the cap that the little wings of the mouthpiece are seated firmly behind the barrier.

