



Wii U

Wii U Fun Center

Parts List



100597 - Nunchuk



100599 - Wii Remote



100600 - Wii U GamePad