





Adax ST2:n asennusohje




Käyttöohje
käntöpuolella




Adax ST2:n käyttöohje

5.




230V, 50Hz

6.



7.





Puhdistetaan kuukausittain käyttöaikana

8.



Ylikuumenemissuojan palautinpainike



15 min.

(N)

Service: Adax Fabrikker A/S 3060 SVELVIK, tlf. 33 772920.
NB! Ta vare på kvitteringen for dokumentasjon av kjøpsdato.

(DK)

Service: ARA-EI A/S Håndværkervej 4, DK-4652 HAARLEV, tel. +45 56286550.
NB! Husk kvittering for købsdato.

(S)

Service: El & Digital service AB, Ringvägen 17 S-10273 STOCKHOLM, tel. 08 845180.
OBS! Faktura/kvitto gäller som garantibevis.

(FIN)

Huolto: ABB Asea Skandia Oy Varastokatu 9, 05800 HYVINKÄÄ, puh. 010 222001.
Huom! Säilytä kuitti todistuksena ostopäivästä.

(D)

Service: Adax Fabrikker A/S N-3060 SVELVIK, NORWAY, Tlf. +47 33 772920.
NB! Quittung zum Nachweis des Kaufdatums aufheben.

(GB)

Service: Adax Fabrikker A/S N-3060 SVELVIK, NORWAY, phone +47 33 772920.
NB! Retain the receipt as proof of date of purchase.

Asennusohje
käntöpuolella



Declaration of conformity

We declare under our sole responsibility that this product is in conformity with the following standards:

EN 60 335-1 (1988)+A2+A5+A6+A51+A52+A53+A54, EN 60 335-2-43 (1989)+A1+A54,
following the provisions of Directives 73/23/EEC, 93/68/EEC.

Adax-Fabrikker A/S, SVELVIK, NORWAY December 1996.

Tor Åge Kverne



PISTESARJAT

Karvaamokuja 1 • 00380 Helsinki
p. 010-4238 770 • faksi 09 346 3095