

DFDS Guideline – Used Machine

Gothenburg/Zeebrugge/Gent/Immingham/Rotterdam

Machine Shipment Guidelines

Machines must be clean, functioning, self-drivable and ready to drive.

Showing Instruction:

- How to handle and drive the machine in English attached to the machine is mandatory.
- How to start (location mass switch)
- How to stop
- If there are any buttons that should NOT be pressed
- If there is any other special instruction that is unique to the machine
- Phone number for technical assistance

Marks & Numbers:

- Machines must have a clear labelling that corresponds to the booking.

The machine also:

- Have to be clean from dirt, stones etc
- Have to be free from fluid leaks
- Have enough of fuel and battery power for load and unloading the vessel and from and to park space at the terminals

Failure to provide instruction or follow these guidelines may result that the unit not being shipped and may result in costs for cleaning, standage etc.

DFDS reserve the right to charge accordingly if any mechanical work needs to be carried out the machine at time of unloading from vessel and will not be held liable for any damages.

Customer needs to take notice of the quay rent charges at the Port of Discharge. Collection of the machine needs to be arranged soonest to avoid high quay rent charges.



55345-7638629