
Equipment

Equipment

Navigate to Setup > Equipment > Devices:

Add a Device and License

- 1. Click on the Manage Drop Down
- 2. Select "+ Add Device"
- 3. Enter your Device Serial Number
- 4. Click "Get Device Type"
- 5. Click the "Add License" blue hyperlink
 - a. If you have an available Display Connection License you will see green "Active" text
 - b. If you do not have an available Display Connection, contact your reseller to purchase one
- 6. Click "ADD"
- 7. Your device is licensed and automatically added to the Devices list




Create a Vehicle and Assign Device

Navigate to Setup > Equipment > Vehicles

Add a Vehicle and Assign a Device



- 1. Click on the + Add Drop Down
- 2. Select "Add Vehicle"
- 3. Fill out the vehicle properties and modify the icon as desired
- 4. Click the Display Device Drop Down
 - a. You will see licensed displays from your org in the drop down
- 5. Select the device you would like to associate with this vehicle
- 6. Click the "Save" button
- 7. Your vehicle is automatically added to the Vehicles list




Implements

Navigate to Setup > Equipment > Implements

How to add Implements


- 1. Click "+ Add"
- 2. Select "Add Implement"
- 3. Give the implement a name (required)
- 4. Select Operation Type, Equipment Group and enter Unit Cost (optional)
- 5. Click "Save"





How to edit Implements

- 1. Navigate to Setup > Equipment > Implements
- Click on the edit button next to the implement that you want to edit
 Make any required changes to the implement than click 'Save'



How to retire Implements


- 1. Navigate to Setup > Equipment > Implements
- 2. Click the checkbox next to the implement you want to retire
- 3. Click on the trashcan button
- 4. Click 'Retire' on the pop-up to confirm the retiring of the implement





How to unretire Implements

- 1. Navigate to Setup > Equipment > Implements
- 2. Click the 'Show Retired' checkbox to make the retired implements visible
- 3. Click the checkbox next to the implement you want to unretire
- 4. Click on the unretire button 5 UNRETIRE
- 5. Click 'Unretire' on the pop-up to confirm the unretiring of the implement



How to Import Vehicle and Implement Profiles


Navigate to Setup > Equipment > Vehicles

Import Vehicle Profile

- 1. Click "+ add"
- 2. Select "Import Profiles"
- 3. Select "Choose file"
- 4. Navigate and select zipped AgData file for import
 - a. Note: Only Precision-IQ AgData profiles can be imported
- 5. Click "Open"
- 6. Click the checkbox for vehicles you want to import and select which vehicle to attach the profile to either an existing vehicle in the list or '[New Vehicle]' to create a new vehicle



7. Click "Import"



Navigate to Setup > Equipment > Implements

Import Implement Profile

- 1. Click "+ add"
- 2. Select "Import Profiles"
- 3. Select "Choose file"
- 4. Navigate and select zipped Agdata file for import
- 5. Click "Open"
- 6. Click the checkbox for vehicles you want to import and select which vehicle to attach the profile to either an existing vehicle in the list or '[New Vehicle]' to create a new vehicle
- 7. Click "Import"

